

ULTRA-VOICE® DIGITAL VX2496



User's Manual

Version 1.0 July 2002

ENGLISH



www.behringer.com

ULTRA-VOICE DIGITAL VX2496

SAFETY INSTRUCTIONS



CAUTION: To reduce the risk of electric shock, do not remove the cover (or back). No user serviceable parts inside; refer servicing to qualified personnel.

WARNING: To reduce the risk of fire or electric shock, do not expose this device to rain and moisture.



This symbol, wherever it appears, alerts you to the presence of uninsulated dangerous voltage inside the enclosure—voltage that may be sufficient to constitute a risk of shock.



This symbol, wherever it appears, alerts you to important operating and maintenance instructions in the accompanying literature. Please read the manual.

DETAILED SAFETY INSTRUCTIONS:

All the safety and operation instructions should be read before the device is operated.

Retain Instructions:

The safety and operating instructions should be retained for future reference.

Heed Warnings:

All warnings on the device and in the operating instructions should be adhered to.

Follow instructions:

All operation and user instructions should be followed.

Water and Moisture:

The device should not be used near water (e.g. near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, near a swimming pool etc.).

Ventilation:

The device should be situated so that its location or position does not interfere with its proper ventilation. For example, the device should not be placed on a bed, sofa, rug, or similar surface that may block the ventilation openings, or used in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.

Heat:

The device should be situated away from heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that produce heat.

Power Source:

The device should only be connected to a power supply of the type described in the operating instructions or on the device.

Grounding or Polarization:

This device must be grounded.

Power Cords:

Power cords should be routed so that they are not likely to be walked on or pinched by items placed on or against them, paying particular attention to cords and plugs, sockets, outlets and the point where they exit from the device.

Cleaning:

The device should be cleaned only as recommended by the manufacturer.

Non-use Periods:

The power cord of the device should be unplugged from the outlet when left unused for a long period of time.

Debris and Liquid Entry:

Debris and/or liquids should not be allowed to enter the enclosure through openings.

Damage Requiring Service:

The device should be serviced by qualified service personnel when:


- ▲ The power cord or the plug has been damaged; or
- ▲ Debris or liquid has entered the device; or
- ▲ The device has been exposed to rain; or
- ▲ The device does not appear to operate normally or exhibits a pronounced change in performance; or
- ▲ The device has been dropped, or the enclosure damaged.

Servicing:

The user should not attempt to service the device beyond that which is described in the operating instructions. All other servicing should be referred to qualified service personnel.

ULTRA-VOICE[®] DIGITAL

Professional high-performance mic preamplifier/voice processor with AES/EBU output



- ▲ Ultra low-noise discrete vintage-design mic/line input stage
- ▲ 24-bit AES/EBU output with selectable 44.1, 48, 88.2 and 96 kHz sampling rates or external clocking
- ▲ Authentic tube emulation circuitry for typical tube and tape saturation sounds
- ▲ True RMS expander for extremely smooth noise reduction
- ▲ Opto compressor for inaudible level control and creative sound processing
- ▲ Integrated dynamic enhancer compensates for high-frequencies lost through compression
- ▲ Voice-optimized equalizer specially designed for voice enhancement
- ▲ Opto de-esser for quick removal of excessive sibilance from your vocal track
- ▲ High-performance THAT[®] VCA for ultimate signal purity
- ▲ Ultra low-noise 4580 operational amplifiers for outstanding audio performance
- ▲ Accurate LED metering for crystal-clear level and processor indication
- ▲ Servo-balanced gold-plated XLR connectors for all main inputs and outputs
- ▲ Ultra high-precision ALPS[®] potentiometers for ultimate accuracy and repeatability
- ▲ Illuminated switches ensure perfect operation in dark stage environments
- ▲ High-quality components and exceptionally rugged construction for long life and durability
- ▲ Shielded toroidal power transformer for lowest noise interference
- ▲ Manufactured under ISO9000 certified management system

VX2496

ULTRA-VOICE DIGITAL VX2496

FOREWORD



Dear Customer,

welcome to the team of BEHRINGER users and thank you very much for expressing your confidence in us by purchasing the VX2496. Writing this foreword for you gives me great pleasure, because it represents the culmination of many months of hard work delivered by our engineering team to achieve a very ambitious goal: to offer you a high-quality device whose flexibility makes it suitable for use both in studios and in the P.A. rental market.

The task of designing our new ULTRA-VOICE DIGITAL VX2496 certainly meant a great deal of responsibility which we assumed by focusing on you, the discerning user and musician. Meeting your expectations also meant a lot of work and night shifts. But it was fun, too. Developing a product usually brings a lot of people together, and what a great feeling it is when all who participated in such a project can be proud of what they've achieved.

It is our philosophy to share our enjoyment with you, because you are the most important member of the BEHRINGER team. With your highly competent suggestions for new products you've made a significant contribution to shaping our company and making it successful. In return, we guarantee you uncompromising quality as well as excellent technical and audio properties at an extremely reasonable price. All of this will enable you to give free rein to your creativity without being hampered by budget constraints.

We are often asked how we manage to produce such high-quality devices at such unbelievably low prices. The answer is quite simple: it's you, our customers! Many satisfied customers mean large sales volumes enabling us to get better purchasing terms for components, etc. Isn't it only fair to pass this benefit on to you? Because we know that your success is our success too!

I would like to thank all of you who have made the ULTRA-VOICE DIGITAL possible. You have all made your own personal contributions, from the developers to the many other employees at this company, and to you, the BEHRINGER user.

My friends, it's been worth the effort!

Thank you very much,

Uli Behringer

TABLE OF CONTENTS

1. INTRODUCTION	4
1.1 Before you begin	5
2. CONTROL ELEMENTS	5
2.1 Discrete vintage input section	5
2.2 Expander and tube emulation	5
2.3 Opto compressor	6
2.4 Voice-optimized EQ	6
2.5 Opto de-esser and master section	6
2.6 Rear panel	7
2.7 Digital AES/EBU output and wordclock option	7
3. RECORDING WITH THE ULTRA-VOICE DIGITAL	7
4. MIXING WITH THE ULTRA-VOICE DIGITAL	8
5. LIVE APPLICATIONS WITH THE ULTRA-VOICE DIGITAL	8
6. INTEGRATION INTO A RECORDING SYSTEM	9
7. AUDIO CONNECTIONS	9
8. SPECIFICATIONS	10
9. WARRANTY	11

1. INTRODUCTION

Thank you for the confidence you have placed in us by purchasing the ULTRA-VOICE DIGITAL VX2496. With the ULTRA-VOICE DIGITAL you have acquired an extremely powerful device for creatively processing your music. Its professional design means the VX2496 can produce excellent results, both in the studio and live. Numerous features, such as the opto compressor or the voice-optimized EQ mean you can even process signals with a very wide dynamic range and tailor them to the overall sound of your music. In addition, the VX2496 has a digital AES/EBU output with a high-resolution 24-bit/96 kHz A/D converter and a wordclock input enabling synchronization to external devices.

The BEHRINGER ULTRA-VOICE DIGITAL combines a microphone preamp, control amplifier and equalizer and is ideally suited for connection to a hard disk recording system where you could, for example, record vocals directly onto the hard drive. The highest quality is maintained, as any potential deterioration caused by inserting into a mixing console is eliminated. In addition, the integrated A/D converter ensures optimum conversion of the analog signal with no degradation of sound quality. And, due to its professional signal-processing features, the ULTRA-VOICE DIGITAL is also the ideal tool for optimizing live vocals.

To familiarize yourself with the functions of the VX2496, simply connect any audio signal and try out each individual control. Use a relatively uncompressed signal (for example, one of your own recordings) in order to judge the effect of the opto-compressor. CDs are usually pre-compressed, which makes it difficult to hear how the compressor changes the sound.

Once you have developed a feel for the individual components, you can unleash your creativity by combining individual functions.

ULTRA-VOICE DIGITAL VX2496

 This manual first describes the terminology used, so that you fully understand the VX2496 and its functions. Please read the manual carefully and keep it for future reference.

1.1 Before you begin

Your ULTRA-VOICE DIGITAL was carefully packed in the factory, and the packaging is designed to protect the unit from rough handling. Nevertheless, we recommend that you carefully examine the packaging and its contents for any signs of physical damage, which may have occurred during transit.

 If the unit is damaged, please do NOT return it to BEHRINGER, but notify your dealer and the shipping company immediately. Otherwise, claims for damage or replacement may not be granted.

Be sure that there is enough space around the unit for cooling and, to avoid overheating, please do not place your ULTRA-VOICE DIGITAL on power amplifiers, etc.

The mains connection is via the enclosed power cord and a standard IEC receptacle. It meets all international safety certification requirements.

 Please make sure that all units have a proper ground connection. For your own safety, never remove or disable the ground conductor from the unit or the AC power cord.

Before you connect your ULTRA-VOICE DIGITAL to the mains, please make sure that the voltage setting on your unit matches the local voltage! The fuse holder above the AC power connector has 3 triangular markings. Two of these three triangles are aligned with one another. The VX2496 is set to the voltage shown next to these markings and can be switched over by turning the fuse holder by 180°. **IMPORTANT:** This does not apply to export models designed exclusively for 115 V operation!

2. CONTROL ELEMENTS

2.1 Discrete vintage input stage




Fig. 2.1: Discrete Vintage input stage

This section of the ULTRA-VOICE DIGITAL is a preamp where you regulate the input level of the microphone or line level signal.

- 1 Use the *LINE* button to select the type of input signal (pressed = LINE, not pressed = MIC).
- 2 Press the *+48 V* button to power a condenser microphone. Dynamic microphones do not require this phantom power supply.
- 3 The *GAIN* control sets the input level. The scale -12 to +12 dB relates to the LINE input whereas the scale +10 to +60 dB relates to the MIC input.

- 4 The *SIG* LED above the gain control illuminates when an input signal is present.
- 5 Ensure that the *CLIP* LED lights up only with peak signals. If it is constantly lit or if distortion can be heard, reduce the input level using the *GAIN* control.
- 6 The ULTRA-VOICE DIGITAL has a low-cut filter which can be used to remove low-frequency interference from the microphone signal. This function is activated with the *LO CUT* button. This filter has a slope of 12 dB/oct.
- 7 With the *FREQUENCY* control, you can select the cutoff frequency below which the low-frequency component will be removed (range 15 - 360 Hz).
- 8 The *Ø INV* shifts the input signal phase by 180°. Use this function if the use of multiple microphones results in cancellations of specific frequency ranges.

2.2 Expander and tube emulation




Fig. 2.2: Expander and tube emulation

An expander reduces the volume of a signal in low-level passages. This way, interference such as tape noise and spill can be removed.

- 9 The *IN/OUT* button switches the expander in or out of the signal path.
 - 10 The *THRESHOLD* control determines the level at which the expander cuts in.
 - 11 The amount of gain reduction is determined using the *DEPTH* control. The higher the value, the more the gain is reduced.
 - 12 When the *GATE* button is pressed, the expander functions as a noise gate. This has a more radical effect on the sound, as it not only attenuates but also completely eliminates low-level passages. For this reason the gate function should primarily be used with individual signals, thus not risking any unwanted effect on the existing recording.
 - 13 The four *GAIN REDUCTION* LEDs display the amount of gain reduction from -5 to -30 dB.
- The tube emulation function allows you to enhance vocals with subtle distortion and tape saturation effects, replicating analog tapes and tube amps. In this mode, the VX2496 adds upper harmonics to the signal, thus enhancing its sound in the high-frequency range.
- 14 The *IN/OUT* button activates or deactivates tube emulation.
 - 15 The *DRIVE* control determines the intensity of the saturation effect. The further it is turned to the right (*HOT*), the greater the effect. The amount of upper harmonics generated is also dependent on the level set at the discrete vintage input stage.
 - 16 The *SIG* LED lights up when tube emulation is active.

ULTRA-VOICE DIGITAL VX2496

- [17] To avoid internal overloading, the *CLIP* LED should only light up during peak level passages. It should not be constantly illuminated.
- [18] The *TUNING* control lets you determine the frequency range to be saturated. All other ranges remain unaffected, allowing the effect to be finely tailored.
- [19] To process the whole frequency spectrum, use the *FULL BW* button. This makes the *TUNING* control inoperative.

2.3 Opto compressor




Fig. 2.3: Opto compressor

The opto compressor reduces the dynamic range of the input signal, i.e. the level difference between soft and loud passages. Peaks above a certain value are reduced, smoothing out the sound.

- [20] The *IN/OUT* button activates the compressor. Use this to directly compare compressed and uncompressed signals.
- [21] The *THRESHOLD* control determines the level at which the opto compressor starts to compress the signal. Only if this value is exceeded will the signal be processed. The dynamics of passages whose levels lie below the threshold are not affected. The lower the threshold value, the greater the compression.
- [22] The *HARD RATIO* button sets the amount of signal gain reduction to its maximum. This produces a highly-compressed, flat sound. Do not use this function if you wish to retain the natural dynamics of the sound.
- [23] If the *FAST* button is pressed, the opto compressor starts compressing very quickly after the threshold is exceeded. The overall sound appears significantly more compressed and the result is a very powerful sound.
- [24] The *RELEASE* control determines how quickly the compression stops after the signal falls back below the threshold. The longer the release time, the more compressed the sound will appear to be, but also the more smoother.
- [25] The *OUTPUT* control regulates the output volume of the compressed signal. The compression process reduces the level of signal and this control is used to raise its level again (known as make-up gain).
- [26] Certain frequency ranges may be lost during compression. These can be regained by using the integrated enhancer. The sound is subjectively rounded off and acquires a new brilliance.
- [27] The six *GAIN REDUCTION* LEDs display the amount of compression. The level reduction displayed ranges from -3 to -24 dB.

2.4 Voice-optimized EQ




Fig. 2.4: Voice-optimized EQ

The voice-optimized EQ is a 3-band equalizer used for sound shaping. You can boost or cut frequency ranges in order to equalize weaknesses in the input signal.

- [28] Activate the voice-optimized EQ with the *IN/OUT* button.
- [29] Use the *TUNING* control to select a frequency range (130 Hz to 720 Hz).
- [30] The selected frequency range can be boosted or cut using the *WARMTH* control. Cut employs a narrower bandwidth than that used for boost, enabling you to tailor the filter to your specific needs.
- [31] Use the *PRESENCE* control to add high and upper-mid frequencies to the signal (around 1.7 kHz). This helps to push vocals to the forefront with more presence in the overall sonic image.
- [32] Use the *BREATH* control to boost or cut typical noises associated with the voice (e.g. breathing) at around 8 kHz.
- [33] The *ABSENCE* button cuts the level of those frequencies that cause an unappealing, harsh sound. These lie around the area of 4 kHz.

2.5 Opto de-esser and master section




Fig. 2.5: Opto de-esser and master section

Sibilance is an unwanted effect that can occur with some voices, whereby hissing sounds like that of "s" or "sh" are produced. With the opto de-esser, sibilance can easily be removed from the signal.

- [34] Depress the *IN/OUT* button to activate the opto de-esser.
- [35] The *THRESHOLD* control determines the amount by which sibilance should be suppressed. The lower the value, the more comprehensively sibilance is removed.
- [36] Use the *CUT FREQ* control to select the frequency range to be reduced.
- [37] The *ACTIVE* LED lights when the opto de-esser is functioning. The intensity of the LED reflects how hard the opto de-esser is working.

ULTRA-VOICE DIGITAL VX2496

To avoid coloring the character of the sound, do not set the threshold too low when using the opto de-esser. When the threshold is set at its optimal value, the effect should only be recognizable by direct comparison to the unprocessed signal using the IN/OUT button.

[38] Use the *MASTER FADER* to match the output signal level to the input sensitivity of the following device (e.g. your DAT or hard disk recorder).

Start by tuning the master fader right down and increase it slowly to the desired level. If you start with too high a level, you risk overloading the inputs of the devices that follow!

[39] The six *OUTPUT LEVEL* LEDs show the level of the output over a -10 to +15 dB range. Ensure that the output level does not go into overload otherwise the signal at the DIG OUT output will be too high and cause distortion.

[40] Use the *POWER* button to turn on the ULTRA-VOICE DIGITAL.

2.6 Rear panel connectors




Fig. 2.6: Mains connector and fuse holder

[41] **FUSE HOLDER/VOLTAGE SETTING.** Before connecting the unit to the mains, ensure that the voltage setting matches your local voltage. A blown fuse should only be replaced by a fuse of the same type and rating. On some units, the fuse holder can be switched to one of two positions, i.e. 230 V and 115 V.

Should you desire to operate the unit outside Europe at 115 V, a higher fuse rating is required (see chapter 1.1).

[42] The mains connection is on an *IEC* receptacle. An appropriate power cord is included.

[43] **SERIAL NUMBER.** Please take the time to complete and return the warranty card within 14 days after the date of purchase to benefit from our extended warranty. Or simply register online at www.behringer.com.




Fig. 2.7: ULTRA-VOICE DIGITAL connections

[44] These are the *MAIN* outputs of the ULTRA-VOICE DIGITAL on balanced XLR and 1/4" TRS jacks.

[45] The XLR *RECORDING* output is for connection to a DAT recorder, hard disk recorder or similar device and is sourced pre de-esser.

[46] This is the *INSERT* section with two 1/4" mono jacks as *SEND* and *RETURN* for connecting an additional effects device. The signal is sourced post low-cut filter of the input stage.

[47] The *LINE* input is on a balanced 1/4" TRS jack.

[48] This is the balanced XLR connector for a microphone (MIC) or line source.

2.7 Digital AES/EBU output and wordclock option




Fig. 2.8: The ULTRA-VOICE DIGITAL digital interface

[49] The digitally converted audio signal of the ULTRA-VOICE DIGITAL appears at the *DIG OUT* (AES/EBU) output.

[50] Use the *SAMPLING RATE* switch to select the sampling rate at which the VX2496 analog signal is converted. You can choose a sample rate frequency of 44.1, 48, 88.2 or 96 kHz. If you want to lock to an external wordclock, the *SAMPLING RATE* switch should be set to *EXT*.

[51] Wordclock for synchronization of the VX2496 can be fed from an external device into the *WC IN* input. This connector is a BNC coaxial jack and is only active when the *SAMPLING RATE* switch is set to *EXT*.

The ULTRA-VOICE DIGITAL VX2496 features a 24-bit/96 kHz A/D converter with digital AES/EBU output. This allows you to record the digital output direct onto a digital medium without the need of an external A/D converter. Thus the ULTRA-VOICE DIGITAL can be seamlessly integrated into a hard disk recording system.

When several digital devices are integrated into a digital recording system with, for instance, a digital mixing console, all the digital devices must be synchronized to a common wordclock signal. For this reason the VX2496 has a wordclock input which enables it to be locked to an external device. It supports all sampling rates from 32 to 96 kHz.

3. RECORDING WITH THE ULTRA-VOICE DIGITAL

When recording with the ULTRA-VOICE DIGITAL, you should strive to achieve as natural a sound as possible at the best possible quality. During the mix the signal can then be given any required special treatment, with the original recorded signal always remaining pure.

1) Set an appropriate input level using the discrete vintage input stage's *GAIN* control.

2) Be sure to do everything possible to achieve the best sound before it reaches the ULTRA-VOICE DIGITAL. This includes being especially careful to find the optimal position for the microphone and ensuring that the surrounding acoustics enhance the sound in the desired fashion. Then, turn all the ULTRA-VOICE DIGITAL controls off to initialize the "dry" signal.

3) If necessary you can then smooth out the dynamics of the vocal slightly with the opto compressor. Be sure not to compress the signal too much; the compressor can always be used again after the recording. Also, do not use the hard ratio function at this stage as it makes a very audible difference in the signal. If the vocalist constantly changes his distance from the microphone during recording, extreme dynamic fluctuations may result. In this case, a higher level of compression should be used. Keep the threshold relatively low on the opto compressor to obtain a normal volume level.

ULTRA-VOICE DIGITAL VX2496

 To avoid having to compress the signal too much, try to maintain a constant distance between the vocalist and the microphone while recording.

Backing vocals should be highly compressed so they can be present throughout the recording without volume fluctuations.

4) The voice-optimized EQ allows you to equalize deficiencies in the sound image that could not be corrected in advance. However, do not use extreme settings here either, as you can add more EQ when mixing. The voice-optimized EQ can be used to deal with the following problems:

▲ If the vocals sound muddy in the bass range, you can cut the low-frequency area of the signal by using the WARMTH control. Set the control to full cut and locate the intrusive frequency range with the TUNING control so that the voice sounds more balanced. You should try this in solo mode first. Then, listen to the voice with the rest of the mix and adjust the WARMTH control until the overall sound is right.

▲ If the voice sounds too edgy, use the ABSENCE button on the voice-optimized EQ. This will attenuate these harsh frequencies without compromising the natural quality of the overall sound. In addition, you can boost the low frequencies with the WARMTH control or, if necessary, improve the peaky characteristic of the signal by lowering the BREATH or PRESENCE control.

▲ If the voice is getting lost in the mix, increase the PRESENCE control. Boosting this range will help the voice to cut through more.

▲ If the vocal sound is not brilliant enough, you can add peaks using either the PRESENCE or the BREATH control. Additionally, you can use the opto-compressor enhancer to add upper harmonics artificially.

5) If the signal contains unwanted frequency areas, use the expander and the opto de-esser to remove them. Sibilance can be removed with the opto de-esser, but first you must isolate the intrusive frequency range:

▲ Activate the voice-optimized EQ and turn the BREATH control up to exaggerate sibilant frequencies. If you have already used the EQ, first make a note of the original settings so they can be subsequently reset.

▲ Activate the opto de-esser and, using a low threshold, turn the CUT FREQ control until the sibilance is reduced.

▲ Now turn the voice-optimized EQ off again and reset the BREATH control to its original position.

▲ Now set the threshold so the ACTIVE LED only lights up when sibilance is present.

The expander enables you to remove intrusive noise from quiet passages. To do this, turn the THRESHOLD control to the far left and turn it up slowly with DEPTH set at medium. Find the value at which you notice an audible suppression of the quiet spots without impairing the vocal sound. Only use the gate in exceptional cases—if, for instance, you want to achieve a specific effect. It radically affects the sound and could thus ruin your recording.

6) Use the tube emulation for a “classic” analog tape recording sound.

7) Finally, use the MASTER FADER to regulate the ULTRA-VOICE DIGITAL’s output.

4. MIXING WITH THE ULTRA-VOICE DIGITAL

Go ahead and experiment with the mixing possibilities of the ULTRA-VOICE DIGITAL and push it to its limits. It is often the case that extreme effect and filter settings are needed to optimally integrate a signal into the mix. If a voice ultimately appears as very full and present in the mix, it usually means the signal has been thoroughly and truly “tweaked”.

Vocals usually have reverb added during the mix. If you notice intrusive noise (e.g. sibilance) in the reverb, use the opto de-esser to remove it as follows:

▲ Remove the sibilance from the vocal as previously described in chapter 3.5 and drive the reverb unit via one of the main outputs (not via the INSERT path as it is sourced before the de-esser). Make sure the reverb unit is set to 100% wet, i.e. there is no dry direct signal present.

▲ The reverb signal can now be mixed at the console with the signal from the VX2496’s RECORDING output. This is sourced before the de-esser, and in this way sibilance is removed only from the reverb signal, not the main voice itself.

The expander can be used to remove spill from other instruments which, for example, may have been picked up by the microphone from the vocalist’s headphones. Remember that compression would have the opposite effect, as the signal is limited at the loudest spots. Any spill would then become effectively louder.

Although the ULTRA-VOICE DIGITAL was principally designed to record vocals, you can of course also use it to record and mix other signals.

5. LIVE APPLICATIONS WITH THE ULTRA-VOICE DIGITAL

The ULTRA-VOICE DIGITAL is a versatile problem-solver and sound-shaper both in live and studio environments.

On a small stage, short distances between the microphone and the monitor speaker can lead to unpleasant feedback. In this case the VX2496 opto de-esser could be used to suppress feedback:

▲ Set the THRESHOLD control relatively low.

▲ Use the CUT FREQ control to find the frequency causing the feedback.

▲ Now turn the threshold up far enough to eliminate the feedback while maintaining an unaffected vocal signal as much as possible.

Loud volume can lead to large amounts of spill on stage, i.e. the microphones do not just pick up one signal (e.g. vocal), but many other signals from the stage. This can be a major problem, as the individual signals cannot be easily controlled independently. Use the expander to isolate individual signals and to lessen of spill. The level of the spill is lowered while the louder wanted signal is unaffected. The gate function also lends itself well to this application as unwanted signals can be completely eliminated in this way. You must be careful, however, to ensure that the main signal is not clipped as the gate cuts off when it falls below the threshold. This could even cause quiet passages to disappear even though they are meant to be heard. The gate is also ideally suited to processing impulse sounds (e.g. snare, bass drum, toms etc.) as these are relatively short signals that neither swell nor ring out.

6. INTEGRATION INTO A RECORDING SYSTEM

As mentioned at the beginning of this manual, the ULTRA-VOICE DIGITAL is ideally suited to direct connection to a recording medium, such as a DAT recorder, analog tape machine, or even a hard disk recording system without the use of a mixing console. Furthermore, an extremely clean signal is produced as the potential noise produced by looping through a mixing console is eliminated from the outset. You can integrate the VX2496 into a hard disk recording system without having to use an additional A/D converter. For such cases, the ULTRA-VOICE DIGITAL has a 24-bit/96 kHz A/D converter with digital AES/EBU output. The wordclock input allows the VX2496 to be locked to external devices. Of course, you can also successfully integrate the ULTRA-VOICE DIGITAL into your studio conventionally with a mixing console.

7. AUDIO CONNECTIONS

The BEHRINGER ULTRA-VOICE DIGITAL VX2496 has—except for the insert connectors—standard electronically servo-balanced inputs and outputs. The circuit design has automatic hum suppression with balanced signals and operates problem free even at high levels. Externally-induced mains hum is thus efficiently suppressed. The servo-function automatically detects when connector pins are unbalanced and changes the nominal level internally by 6 dB so that there is no difference in level between input and output signals.

⚠ Please ensure that only qualified persons install and operate the device. During installation and operation the user must have sufficient electrical contact to earth. Electrostatic discharges might affect the operation of the unit.




Fig. 7.1: XLR connections




Fig. 7.2: 1/4" mono jack




Fig. 7.3: 1/4" stereo jack connector

ULTRA-VOICE DIGITAL VX2496

8. SPECIFICATIONS

AUDIO INPUTS

MIC Line	XLR connector, HF shielded, balanced
Line	XLR connector and 1/4" jack HF shielded, balanced
Insert Return	1/4" jack unbalanced
Impedance	
MIC Line	1.3 k Ω unbalanced, 2.6 k Ω balanced
Line	XLR connector and 1/4" jack 10 k Ω unbalanced, 20 k Ω balanced
Insert Return	10 k Ω unbalanced
Max. Input Level	
MIC Line	+11 dBu unbalanced and balanced
Line	XLR and jack +21 dBu balanced and unbalanced
Insert Return	+21 dBu
CMRR	typical 40 dB, >60 dB @ 1 kHz (except Insert Return)

AUDIO OUTPUTS

Recording Out XLR	Electronically controlled servo-balanced output stages
Main Out XLR	Electronically controlled servo-balanced output stages
Main Out Jack	1/4" jack unbalanced
Impedance	
Rec. Out	120 Ω balanced, 60 Ω unbalanced @ 1 kHz
Main Out XLR	120 Ω balanced, 60 Ω unbalanced @ 1 kHz
Main Out Jack	100 Ω unbalanced @ 1 kHz
Insert Send	100 Ω unbalanced @ 1 kHz
Output Level	
Rec. Out	max. +21 dBu balanced and unbalanced
Main Out XLR	max. +21 dBu balanced and unbalanced
Main Out Jack	max. +21 dBu unbalanced
Insert Send	max. +21 dBu unbalanced

SYSTEM DATA

Bandwidth	20 Hz to 20 kHz, +0/-0.6 dB
Frequency Response	Line: <10 Hz to >200 kHz, +0/-1.7 dB -> Main Out MIC: <10 Hz to >200 kHz, +0/-2.5 dB -> Main Out
S/N Ratio	123.6 dB dynamics -> Insert Send 118.5 dB dynamics -> Main Out 122 dB dynamics -> Recording Out 130 dB E.I.N, Mic In -> Insert Send 105 dB Line -> Insert Send @ +4 dBu/1 kHz 0.006% typ. @ -30 dBu, 1 kHz, Gain 30 dB, Mic In -> Insert Send 0.01% typ. @ -30 dBu, 1 kHz, Gain 30 dB, Mic In -> Main Out 0.001% typ. @ +4 dBu, 1 kHz, Unity Gain, Line In -> Insert Send 0.004% typ. @ +4 dBu, 1 kHz, Unity Gain, Line In -> Main Out
THD	

DIGITAL OUTPUT

Type	High-resolution 24-bit AKMA/D converter
Standard	AES/EBU / XLR transformer-balanced
Output Impedance	110 Ω balanced
Nom. Output Level	5 V peak-to-peak

INTERNAL SAMPLING FREQUENCY

44.1 / 48 / 88.2 / 96 kHz (switchable)

WORDCLOCK INPUT

Type	BNC
Frequency Range	31 to 100 kHz
Input Impedance	100 k Ω
Nom. Input Level	2 to 5 V peak-to-peak

EXPANDER/GATE SECTION

Type	RMS Expander
Threshold	variable (OFF to +10 dB)
Ratio	Expander: variable (1:1 to 3:1) Gate: 1: ∞
Attack	<1 msec / 20 dB, fixed
Release	100 msec / 20 dB, fixed

COMPRESSOR SECTION

Type	Opto Compressor
Threshold	variable (-25 to +10 dB)
Ratio	switchable (3:1 / 9:1)
Manual Release Time	variable (10 dB / 10 msec to 10 dB / 1.5 sec)
Manual Attack Time	10 dB / 10 msec
Output	Fast: 20 dB / 10 msec variable (0 bis +20 dB)

DE-ESSER SECTION

Type	VAD (Voice-Adaptive)-De-Esser
Filter Frequency	2.7 to 12 kHz
Filter Quality	program-dependent, max. Q = 4
Attenuation	max. 18 dB

TUBE EMULATION SECTION

Filter Frequency	variable, 800 Hz to 12kHz
Peak Frequency	Full Bandwidth, lower Cut-off Frequency = 200 Hz
Characteristic	Band Pass, 1st Order (6 dB/Oct.) Full Bandwidth: High Pass, 1st Order (6 dB/Oct.)
Boost	variable, max. 20 dB

VOICE OPTIMIZED EQ SECTION

Bands	3
Filter Quality	Boost: 0.4 / Cut: 3
Filter Frequencies	Breath: Type shelving, lower Cut-off Frequency 10 kHz Presence: Type peak, Peak Frequency 1.5 kHz Warmth: Type peak, semiparametric Peak Frequency variable from 130 to 720 Hz

POWER SUPPLY

Mains Voltage	USA/Canada 120 V ~, 60 Hz U.K./Australia 240 V ~, 50 Hz Europe 230 V ~, 50 Hz
General	
Export Model	100 - 120 V ~, 200-240 V ~, 50-60 Hz
Power Consumption	max. 25 W
Fuse	100 - 120 V ~: T 630 mA H 200 - 240 V ~: T 315 mA H
Mains Connection	Standard IEC Receptacle

DIMENSIONS (H x W x D)

approx. 1 3/4" (44.5 mm) x

19" (482.6 mm) x 8 1/2" (217 mm)

WEIGHT

approx. 2.2 kg

SHIPPING WEIGHT

approx. 3.4 kg

BEHRINGER makes every effort to ensure the highest standard of quality. Necessary modifications are carried out without notice. Thus, the specifications and design of the device may differ from the information given in this manual.

9. WARRANTY

§ 1 WARRANTY CARD/ONLINE REGISTRATION

To be protected by the extended warranty, the buyer must complete and return the enclosed warranty card within 14 days of the date of purchase to BEHRINGER Spezielle Studioteknik GmbH, in accordance with the conditions stipulated in § 3. Failure to return the card in due time (date as per postmark) will void any extended warranty claims. Based on the conditions herein, the buyer may also choose to use the online registration option via the Internet (www.behringer.com or www.behringer.de).

§ 2 WARRANTY

1. BEHRINGER (BEHRINGER Spezielle Studioteknik GmbH including all BEHRINGER subsidiaries listed on the enclosed page, except BEHRINGER Japan) warrants the mechanical and electronic components of this product to be free of defects in material and workmanship for a period of one (1) year* from the original date of purchase, in accordance with the warranty regulations described below. If the product shows any defects within the specified warranty period that are not excluded from this warranty as described under § 3 and 4, BEHRINGER shall, at its discretion, either replace or repair the product using suitable new or reconditioned parts. In the case that other parts are used which constitute an improvement, BEHRINGER may, at its discretion, charge the customer for the additional cost of these parts.

2. If the warranty claim proves to be justified, the product will be returned to the user freight prepaid.

3. Warranty claims other than those indicated above are expressly excluded.

§ 3 RETURN AUTHORIZATION NUMBER

1. To obtain warranty service, the buyer (or his authorized dealer) must call BEHRINGER (see enclosed list) during normal business hours **BEFORE** returning the product. All inquiries must be accompanied by a description of the problem. BEHRINGER will then issue a return authorization number.

2. Subsequently, the product must be returned in its original shipping carton, together with the return authorization number to the address indicated by BEHRINGER.

3. Shipments without freight prepaid will not be accepted.

§ 4 WARRANTY REGULATIONS

1. Warranty services will be furnished only if the product is accompanied by a copy of the original retail dealer's invoice. Any product deemed eligible for repair or replacement by BEHRINGER under the terms of this warranty will be repaired or replaced within 30 days of receipt of the product at BEHRINGER.

2. If the product needs to be modified or adapted in order to comply with applicable technical or safety standards on a national or local level, in any country which is not the country for which the product was originally developed and manufactured, this modification/adaptation shall not be considered a defect in materials or workmanship. The warranty does not cover any such modification/adaptation, irrespective of whether it was carried out properly or not. Under the terms of this warranty, BEHRINGER shall not be held responsible for any cost resulting from such a modification/adaptation.

3. Free inspections and maintenance/repair work are expressly excluded from this warranty, in particular, if caused by improper

handling of the product by the user. This also applies to defects caused by normal wear and tear, in particular, of faders, potentiometers, keys/buttons and similar parts.

4. Damages/defects caused by the following conditions are not covered by this warranty:

▲ improper handling, neglect or failure to operate the unit in compliance with the instructions given in BEHRINGER user or service manuals.

▲ connection or operation of the unit in any way that does not comply with the technical or safety regulations applicable in the country where the product is used.

▲ damages/defects caused by force majeure or any other condition that is beyond the control of BEHRINGER.

5. Any repair or opening of the unit carried out by unauthorized personnel (user included) will void the warranty.

6. If an inspection of the product by BEHRINGER shows that the defect in question is not covered by the warranty, the inspection costs are payable by the customer.

7. Products which do not meet the terms of this warranty will be repaired exclusively at the buyer's expense. BEHRINGER will inform the buyer of any such circumstance. If the buyer fails to submit a written repair order within 6 weeks after notification, BEHRINGER will return the unit C.O.D. with a separate invoice for freight and packing. Such costs will also be invoiced separately when the buyer has sent in a written repair order.

§ 5 WARRANTY TRANSFERABILITY

This warranty is extended exclusively to the original buyer (customer of retail dealer) and is not transferable to anyone who may subsequently purchase this product. No other person (retail dealer, etc.) shall be entitled to give any warranty promise on behalf of BEHRINGER.

§ 6 CLAIM FOR DAMAGES

Failure of BEHRINGER to provide proper warranty service shall not entitle the buyer to claim (consequential) damages. In no event shall the liability of BEHRINGER exceed the invoiced value of the product.

§ 7 OTHER WARRANTY RIGHTS AND NATIONAL LAW

1. This warranty does not exclude or limit the buyer's statutory rights provided by national law, in particular, any such rights against the seller that arise from a legally effective purchase contract.

2. The warranty regulations mentioned herein are applicable unless they constitute an infringement of national warranty law.

* Customers in the European Union please contact BEHRINGER Germany Support for further details.

The information contained in this manual is subject to change without notice. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording of any kind, for any purpose, without the express written permission of BEHRINGER Spezielle Studioteknik GmbH.

BEHRINGER and ULTRA-VOICE are registered trademarks. ALL RIGHTS RESERVED.

© 2002 BEHRINGER Spezielle Studioteknik GmbH.

BEHRINGER Spezielle Studioteknik GmbH, Hanns-Martin-Schleyer-Str. 36-38, 47877 Willich-Münchheide II, Germany

Tel. +49 (0) 21 54 / 92 06-0, Fax +49 (0) 21 54 / 92 06-30