



Installation Instructions for the



PortaBass Transport Handle Kit

Please read the entire instructions before you begin.



PortaBass Transport Handle Kit

Preparation:

Unpack the Kit and inspect the contents. You should find the following items:

- A: 1 each: Telescoping Transport Handle (#51-090-20)
- B: 2 each: Attachment Brackets (#51-090-21)
- C: 2 each: Rubber Feet (#81-203-01)
- D: 6 each: 6-19 x 1" PPH screw (#30-619-01)
- E: 2 each: #9-10 x 1" PPH screw (#30-819-10)
- * 1 each Instructions (47-350-03, not shown)

You will need a ruler or tape measure and a #2 phillips screwdriver to install the transport handle kit.



Installation:

- 1** Gently lay the cabinet face down. Install the two rubber feet (C) using the two #9-10 x 1" screws (E) in the locations shown. The feet are to be mounted on centers 1" up from the bottom of the cabinet and 9" apart (4-1/2" on either side of the cabinet's centerline. Use the center screws on the jackplate as a reference for the centerline.)



- 2** Install one of the brackets (B) using three of the 6-19 x 1" screws (D) in the location shown. The "tab" should point towards the top of the cabinet. The bottom edge of the bracket is to be 2-1/8" from the bottom of the cabinet. Center the bracket horizontally by using the center screws on the jackplate as a reference.



- 3** Install the remaining bracket (B) using the three remaining 6-19 x 1" screws (D) in the location shown. The "tab" should point towards the bottom of the cabinet. The top edge of the bracket is to be 13" from the bottom edge of the other bracket. Center the bracket horizontally by using the center screws on the jackplate as a reference.





PortaBass Transport Handle Kit

- 4** Attach the handle (A) to the brackets as follows:
First, line up the upper lip of the handle with the slot over the upper bracket. Slide the lip completely into the slot. The notch in the lip of the handle will mate with the tab in the bracket.



- 5** Next, press down on the spring-loaded tab on the bottom lip of the handle. While holding the tab down, line up the bottom lip underneath the lower bracket. When the handle is flush with the back of the cabinet, release the spring-loaded tab. The bottom lip will slide into the lower bracket.



The installation is now complete!

- 6** Press down on the spring-loaded tab on the top of the handle and raise the handle until it locks into its fully extended position. Pull back on the handle to tilt the cabinet onto the rollers, and GO!



To lower the handle, press the spring-loaded tab on the top of the handle and push the handle down until it locks in its fully collapsed position.

To remove the handle from the cabinet, press the spring-loaded tab on the lower lip of the handle to free it from the lower bracket. Swing the bottom of the handle away from the back of the cabinet (far enough to clear the lower bracket) and lift the handle straight up.





THE POWER OF BASS

www.ampeg.com



Made with Pride in the U.S.A. by Ampeg • ©2002 SLM Electronics, 1400 Ferguson Avenue, St. Louis, MO 63133 U.S.A.

P/N 47-744-01 • 091302