

Squier Classic Vibe 50's Tele


Maple-

m/n 0303025xxx




<u>Loc #</u>	<u>Description</u>	<u>Part Number</u>
1	Neck (maple)	N/A
1a	Vintage Fret Wire (24)	099-2014-000
2	Vintage Tuners (set of 6)	007-4936-000
3	Bone Nut (blank)	099-4920-000
4	String Guide	099-4912-000
5	Body	N/A
6	Strap Buttons (2)	099-4915-000
7	50's Tele Neck Pickup (import)	007-4934-000
8	50's J Tele Bridge Pickup (import)	007-4935-000
9	Pickguard	007-7345-000
9a	Pickguard Screws (24)	099-4923-000
10	Control Plate	007-4914-000
11-12	250K Pot (w/ mtg. hardware)	007-7348-000
13	Chrome Knobs (ea)	007-4921-000
14	3 Way Switch	007-4910-000
15	Switch Tip (black)	007-4922-000
16	Output Jack	004-7329-049
17	Jack Plate	007-7341-000
18	Bridge Assembly	007-4944-000
18a	Bridge mounting screws (ea)	007-7337-000
19	String Ferrules (ea)	007-7334-000
20	Truss Rod Wrench	007-4911-000

Wiring Diagram



Control Function



3 WAY SWITCH POSITION			
 3	 2	 1	← 3 WAY SWITCH POSITION
			← NECK PICKUP
			← BRIDGE PICKUP
	PICKUP IS ON		
	PICKUP IS OFF		
A	PICKUP (NECK)	INDICATES POSITION OF 3 WAY SWITCH 1	
B	PICKUP (BRIDGE)		
NT	NO TONE		