


QUICKSTART GUIDE

EUROGRAND EG2080-RW/BK



EDIT PARAMETERS

Category	Abbreviated name	Description	Function	Values	Default setting
Tuning	Fine tuning	General fine tuning in 1/5-Hz steps	E 1	427 - 453	440
Tuning	Tuning	Selection of temperament (scale)	E2.1	i→7 (equal temper)	i
	Basic note	Selection of basic note of temperament	E2.2	c→b c	c
Layer mode	Volume	Volume ratio of voice #1 vs. voice #2	E3.1	0→20	-*
	Detune	Detuning of voice#1 vs. voice #2	E3.2	-10→10	-*
	Octave transposition voice #1	Octave position of voice #1	E3.3	-1, 0, 1	-*
	Octave transposition voice #2	Octave position of voice #2	E3.4	-1, 0, 1	-*
	Effect intensity voice #1	Portion of voice #1 volume channeled to the effect	E3.5	0→20	-*
	Effect intensity voice #2	Portion of voice #2 volume channeled to the effect	E3.6	0→20	-*
	Reset	Reset of layer mode settings	E3.7	-	-
Soft pedal	Function	Function of soft pedal: 1) soft pedal, 2) music sequencer	E4.1	1, 2	i
	Effect	Intensity of soft pedal on sound	E4.2	i→5	3
Metronome	Volume	Volume of metronome click	E5	i→20	10
Sequencer	Dimmed volume	Volume of the muted track in music sequencer mode	E6	0→20	5
MIDI	Transmit channel	MIDI channel on which MIDI data are transmitted	E7.1	i→16, off	i
	Receive channel	MIDI channel on which MIDI data are received	E7.2	ALL, 1-2, i→16	ALL
	Sound generator (Local on/off)	Enables/disables the built-in sound generator for keyboard data	E7.3	on, off	on
	Program change	Accept or ignore program change data (send/receive)	E7.4	on, off	on
	Controller commands	Accept or ignore controller commands (send/receive)	E7.5	on, off	on
	Transposition	Transposition of notes during MIDI transmission	E7.6	-12→12	0
	Control panel settings	MIDI transmission of all current settings (dump)	E7.7	-	-
	Music sequencer data	MIDI transmission of music sequencer data (dump)	E7.8	-	-
Save	Sounds	Permanent saving of sound settings	E8.1	on, off	off
	MIDI	Permanent saving of MIDI settings	E8.2	on, off	off
	Tuning	Permanent saving of transposition and tunings	E8.3	on, off	off
	Soft pedal	Permanent saving of soft pedal settings	E8.4	on, off	off

* Default settings depend on the selected sound combination.

