

GENZ·BENZ

GB 212 G-FLEX GUITAR ENCLOSURE

MONO OPERATION -

- Mono 16 ohm Jack: Use this jack for mono 16 ohm operation.
- Mono 4 ohm Jack: Use this jack for mono 4 ohm operation.
- Mono Extension Jack: Use this jack to connect another extension cabinet when using either of the mono input jacks (daisy chaining).

STEREO OPERATION -

Note: Two amplifier sections or channels are required for stereo operation.

- Left 8 ohm Jack: Use this jack to connect one amplifier section or channel to the left 8 ohm speaker.
- Right 8 ohm Jack: Use this jack to connect a second amplifier section or channel to the right 8 ohm speaker.

