

Instamic Pro Plus C | Quick Setup Guide

Modified on: Mon, 12 Aug, 2024 at 5:18 AM


Here's our latest **Instamic Pro Plus Quick Setup Guide**.

Click on the image to download the digital version (pdf).

MOBILE APPLICATION


REMOTE CONTROL YOUR INSTAMIC

THE APP Download the Instamic Remote on Android or iOS, and load it on your smartphone or tablet.





Download on the
App Store


GET IT ON
Google play




MENU


Connect


Capture


Settings


More

CONNECT PAGE

CONNECT Tap one time on the Instamic you want to control. A green check appears once connected.


DISCONNECT Long tap on Instamic to disconnect. The green check disappears.

MULTI CONTROL PANEL Connect, Master-Sync Timecode, Record, Lock, Turn off all your Instamics with one tap.

CAPTURE PAGE If you are already connected to Instamic, tap one more time on it to jump to its related Capture page.

SETTINGS

CAPTURE PAGE



RECORD Tap on the **Recording** button to start capturing. If auto-gain is on, Instamic starts recording after measuring the input gain on the first 8 secs.

STOP Tap on the **Recording** button to stop. Instamic will save your take to its internal memory.

GAIN Tap on the input gain or use the input gain fader to change value manually.

MONITOR Tap on **Monitor** to check the Instamic's audio feed. Press again to stop monitoring. Recording is disabled while monitoring.

VU METER Check the VU Meter to input the optimal level. For an interview, 10db is a good starting point.

LEDS Toggle the LEDs on / off from your phone. While recording, the LEDs work as a VU meter.

https://cdn.shopify.com/s/files/1/2073/8239/files/Instamic_Pro_Plus_C_Quick_Start_Guide_WEB.pdf?v=1723463392

For any further questions, do not hesitate to email us at support@instamic.io.

#happyrecording,
The Instamic Team