




## MPC4000 USB ASCII Keyboard Commands



\* ESC key doesn't work as CANCEL while recording  
\*\* During Data entry of a numeric field, - / + keys work as - / + sign entry