## **NSL7200** Hennessey<sup>™</sup> Strap Locks


### FEATURES AND BENEFITS

**GUITAR PARTS** 

Jump! Swing your guitar! Be alive on stage! Push your axe in any direction and your strap will always remain locked on to your guitar. The Hennessey<sup>™</sup> Strap lock, with its safe & easy-compress and release-action system, allows for easy removal of your strap and for a secure connection every time! We offer the strap locks in three different finishes.








- 1. Unscrew the strap pin that came with your guitar.
- 2. Remove the pin (1) from the lock (2).
- 3. Screw the Hennessey  $\mathbb{T}$  pin and felt washer (1) on the guitar.
- 4. Remove the fastening nut (3) from the back (2).
- 5. Slide the lock (2) through the hole on your strap.
- 6. Take the fastening nut (3), insert into the lock (2). Hold the lock by its lip (2) and tighten to the fastening nut (3).

# Call The Music People today to place your order

Visit us on the web @ www.musicpeopleinc.com or www.onstagestands.com On-Stage Stands® is a registered trademark of The Music People Inc. Prices and Specifications subject to change.



### PRODUCT SPECIFICATIONS

> Construction: Die-Cast Steel

STRAP LOCKS

HENNESSE

Colors: Chrome, Black or Gold

Chrome Strap Lock Model#: NSL7200C Inv#: 49768 List Price: \$29.00

#### **Black Strap Lock** Model#: NSL7200B Inv#: 49756

List Price: \$36.00

**Gold Strap Lock** Model#: NSL7200G

Inv#: 49782 List Price: \$41.00

**NOTE: PACKAGED AND SOLD IN PAIRS** 

