

electro-harmonix

# PULSAR

## VARIABLE SHAPE TREMOLO

Congratulations on your purchase of the Pulsar, a multi-functional variable shape tremolo pedal.

### – CONTROLS –

**WAVE SHAPE Switch** - Selects between the Wave Triangle Mode and the Square Wave Mode.

**SHAPE Knob** - Changes the shape of the wave form that modulates the Tremolo.

**Wave Triangle Mode** - As the SHAPE knob is turned from the Counter-Clockwise (minimum) position to the Center (middle) position, the wave starts as a rising Sawtooth and becomes a Triangle. From the Center position to the Clockwise (maximum) position, the wave changes from a Triangle to a falling Sawtooth.

**Square Wave Mode** - As the SHAPE knob is turned from the Counter-Clockwise (minimum) position to the Center (middle) position, the wave starts as a Small Pulse Width Wave and becomes a Square Width Wave. From the Center position to the Clockwise (maximum) position, the wave changes from a Square Width Wave to a Large Pulse Width Wave.

**DEPTH Knob** - Adjusts the amount of Tremolo that will be applied to your signal. As the INTENSITY knob is turned from the Counter-Clockwise (minimum) position to the Clockwise (maximum) position, the amount of the effect will increase.

**RATE Knob** - Adjusts the speed of modulation for the effect. As the RATE knob is turned from the Counter-Clockwise (minimum) position to the Clockwise (maximum) position, the rate of modulation will increase.

**RATE/STATUS LED** - If the effect is engaged, the LED will blink at the same rate that the effect modulates. If the LED is off, The Pulsar is in bypass mode. The footswitch engages/disengages the effect.

**– WARRANTY INFORMATION –**

Please complete and return the enclosed warranty card within 10 days of purchase. We will repair the unit for free within one year of date of purchase. If you should need to return your unit for service within the warranty period, please include a brief description of the problem as well as your name, address, telephone number, copy of your receipt, and a check or money order for \$5.00 shipping and handling to:

Electro-Harmonix  
C/O New Sensor Corporation  
32-33 47th Avenue  
Long Island City, NY 11101  
Att: Service Department

Please make checks/money orders payable to New Sensor Corporation.

To hear demos by rock stars on all EH pedals visit us on the web at [www.ehx.com](http://www.ehx.com).  
Email us at [info@ehx.com](mailto:info@ehx.com)

