



Operation Manual

CSP105 '75 VINTAGE PHASE 45

DESCRIPTION

- Hand-wired circuit board built with original-spec 1975 components
- Original high-quality Switchcraft Input/Output jacks and Carling bypass switch
- Hand-selected FETs, matched to produce deep and rich phasing
- All analog circuitry for warm analog tone

POWER

The MXR Phase 45 is powered by one 9 volt battery, accessed by removing the bottom plate of the pedal.

CONTROLS

- Footswitch toggles effect on/bypass
- Speed knob regulates overall effect rate

DIRECTIONS

- Run a cable from your guitar to the Vintage Phase 45's Input jack and run another cable from the Vintage Phase 45's Output jack to your amplifier.
- Set the Vintage Phase 45's Speed control knob to the 12 o'clock position.
- Turn the effect on by depressing the footswitch.
- Rotating the Speed knob in a clockwise motion results in a faster phase effect, counterclockwise for a slower effect.

SAMPLE SETTINGS

"DIAMOND LUCY" 60'S PSYCHEDELIC

4:00

"PHASE OF SIGHS" 70'S STONER

1:007

SPECIFICATIONS

Input Impedance $500 \text{ k}\Omega$ $5 \text{ k}\Omega$ Output Impedance -5 dBV Max Input Level > 96 dBSignal to Noise Ratio* Phase Shift Range 360° **Bypass** Hardwire **Current Draw** < 1 mAPower Supply 9 volt battery

*All controls at mid position, A-weighted, $V_{REF} = 1V_{RMS}$

"GRAFFITI PHYSICALLY"
CLASSIC ROCK

9:30 SPEED "NASHVILLE"
CLASSIC COUNTRY

1:00 7 SPEED

