





1 **Unpack / Déballer** **Auspacken / Disimballare il contenuto** **Desembalaje / パッケージを開く**



2 **Auto Mode / Mode Auto** **Auto-Modus / Auto Mode** **Modo automático / オートモード**




3 **Manual Mode / Mode manuel** **Manuel Modus / Modalità manuale** **Modo manual / 手動モード**




For Mackie Control / HUI






Cubase






Abelton Live








Samplitude






Studio One








Logic Pro







Reaper






Pro Tools



Reason



Nuendo



Bitwig

