



# HWY 1™ TELECASTER, 011-1200/02

## SWITCH & CONTROL FUNCTIONS



DETAIL  
3 WAY SWITCH

3 WAY SWITCH POSITION				
			← 3 WAY SWITCH POSITION	
T1	T1	T1	← TONE CONTROL	
			← NECK PICKUP	
			← BRIDGE PICKUP	
	PICKUP IS ON			PICKUP IS OFF



*Fender*®