


SWITCH & CONTROL FUNCTIONS

5 WAY SWITCH POSITION					
					← 5 WAY SWITCH POSITION
T1	T1&T2	T2	T2	NT	← TONE CONTROL
					← NECK PICKUP (A)
					← MIDDLE PICKUP (B)
					← BRIDGE PICKUP (C)
					PICKUP IS ON
					PICKUP IS OFF
					A PICKUP (NECK)
					B PICKUP (MIDDLE)
					C PICKUP (BRIDGE)
					NT NO TONE



Fender[®]