

Before using this unit, carefully read the sections entitled: “USING THE UNIT SAFELY” and “IMPORTANT NOTES” (p. 2; p. 4). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, Owner’s manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.

この機器を正しくお使いいただくために、ご使用前に「安全上のご注意」(P.3)と「使用上のご注意」(P.4)をよくお読みください。また、この機器の優れた機能を十分ご理解いただくためにも、この取扱説明書をよくお読みください。取扱説明書は必要ときにすぐに見ることができるよう、手元に置いてください。

Thank you, and congratulations on your choice of the SRX-09 “SR-JV80 Collection Vol.4 World Collection” Wave Expansion Board.

This expansion board contains all of the waveforms in the SR-JV80-05 World, SR-JV80-14 World Collection “Asia,” and SR-JV80-18 World Collection “LATIN,” along with specially selected titles from waveforms contained in the 17 Country Collection. This board contains new Patches and Rhythm Sets which combine the waveforms in a manner that highlights the benefits of SRX Effects and Matrix Control. This board contains all kinds of unique string, wind, and percussion instrument sounds, used in ethnic music from Africa, Asia, the Middle East, South and North America, Australia, and Europe.

- Patches: 414
- Rhythm Sets: 12
- Waveforms: 873

Some of the waveforms used on this board are specially selected from waveforms found on the CD-ROM “Whole Lotta Country,” produced by SAMPLEHEADS, creator of many high-quality sound libraries.

* The parameter settings for Patches and Rhythm Sets are optimized for the Fantom series, XV series, MX-200, RD series with SRX slots, MC-909, VR-760, and G-70 models, so there are some minor differences in the sounds each instrument produces.

The included CD-ROM contains data reproducing the original sounds of the SR-JV80-05, SR-JV80-14, and SR-JV80-18. (Compatible models: Fantom, XV-5080, XV-5050, XV-3080, XV-88, XV-2020)

This expansion board utilizes a new format. Check the system program version for your instrument, and if a relevant upgrade is available, upgrade your instrument using the appropriate system update program on the included CD-ROM. (See p. 23.)

This program applies to the SRX-01~09.

このたびは、ウェーブ・エクスペンション・ボード SRX-09 「SR-JV80 Collection Vol.4 World Collection」をお買い上げいただき、まことにありがとうございます。

このエクスペンション・ボードは SR-JV80-05 World、14 World Collection “Asia”、18 World Collection “LATIN” に搭載されていたウェーブフォームを完全収録、17 Country Collection に搭載されていたウェーブフォームから一部タイトルを厳選して収録しています。これらのウェーブフォームを組み合わせた SRX 仕様の Effect、Matrix Control を生かした新規 パッチ、リズム・セットを搭載しています。

アフリカ、アジア、中近東、南米、北米、オーストラリア、ヨーロッパ等、世界中のユニークで様々な弦楽器、管楽器、打楽器などの各種民族楽器の音色を収録しています。

- パッチ 414 種類
- リズム・セット 12 種類
- ウェーブフォーム 873 種類

本製品のウェーブフォームの一部は高品位なサウンドライブラリーを数多く製作している SAMPLEHEADS 社の CD-ROM 「Whole Lotta Country」の中からセレクトしたウェーブフォームを使用しています。

※ 各パッチ/リズム・セットは Fantom シリーズ、XV シリーズ、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760 の各機種ごとに最適なパラメーター設定を行っていますので、それぞれ出音が異なることがあります。

付属の CD-ROM に SR-JV80-05、14、18 のオリジナル音色を再現するデータが収録されています。(対応機種：Fantom、XV-5080、XV-5050、XV-3080、XV-88、XV-2020)



このエクスペンション・ボードは新フォーマットを採用しています。お使いの機種ごとのシステム・プログラム・バージョンをご確認の上、バージョン・アップ対象の場合は、付属 CD-ROM に収録されているシステム・アップデート・プログラムでバージョン・アップしてからご使用ください。(P.23 をご覧ください。)

このアップデートプログラムは SRX-01 ~ 09 で使用出来ます。







USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About  WARNING and  CAUTION Notices








 WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
 CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols





	The  symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The  symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The  symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING




WARNING

- Before using this unit, make sure to read the instructions below, and the Owner's Manual. 
- Do not open or perform any internal modifications on the unit. 
- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page. 
- Never use or store the unit in places that are:
 - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are 
 - Damp (e.g., baths, washrooms, on wet floors); or are 
 - Humid; or are
 - Exposed to rain; or are
 - Dusty; or are
 - Subject to high levels of vibration.
- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit. 


WARNING

- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit. 
- Protect the unit from strong impact. (Do not drop it!) 
- Before installing the SRX-09, you must first always turn off the Fantom series/XV series/MX-200/RD series with SRX slots/MC-909/VR-760/G-70 and unplug its power cord. 
- DO NOT play a CD-ROM disc on a conventional audio CD player. The resulting sound may be of a level that could cause permanent hearing loss. Damage to speakers or other system components may result. 

CAUTION



- Never climb on top of, nor place heavy objects on the unit. 
- Install the circuit board only into the specified unit (Fantom series/XV series/MX-200/RD series with SRX slots/MC-909/VR-760/G-70). Remove only the specified screws during the installation. 
- Should you remove screws, make sure to put them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally. 

* In the interest of product improvement, the specifications and/or contents of this package are subject to change without prior notice.




安全上のご注意

火災・感電・傷害を防止するには

⚠ 警告と ⚠ 注意の意味について








 警告	取扱いを誤った場合に、使用者が死亡または重傷を負う可能性が想定される内容を表わしています。
 注意	取扱いを誤った場合に、使用者が傷害を負う危険が想定される場合および物的損害のみの発生が想定される内容を表わしています。 ※物的損害とは、家屋・家財および家畜・ペットにかかわる拡大損害を表わしています。

図記号の例





	△は、注意（危険、警告を含む）を表わしています。 具体的な注意内容は、△の中に描かれています。 左図の場合は、「一般的な注意、警告、危険」を表わしています。
	⊘は、禁止（してはいけないこと）を表わしています。 具体的な禁止内容は、⊘の中に描かれています。 左図の場合は、「分解禁止」を表わしています。
	●は、強制（必ずすること）を表わしています。 具体的な強制内容は、●の中に描かれています。 左図の場合は、「電源プラグをコンセントから抜くこと」を表わしています。

----- 以下の指示を必ず守ってください -----




警告

- この機器を使用する前に、以下の指示と取扱説明書をよく読んでください。 
- この機器を分解したり、改造したりしないでください。 
- 修理／部品の交換などで、取扱説明書に書かれていないことは、絶対にしないでください。必ずお買い上げ店またはローランド・サービスに相談してください。 
- 次のような場所での使用や保存はしないでください。
 - 温度が極端に高い場所（直射日光の当たる場所、暖房機器の近く、発熱する機器の上など） 
 - 水気の近く（風呂場、洗面台、濡れた床など）や湿度の高い場所 
 - 雨に濡れる場所
 - ホコリの多い場所
 - 振動の多い場所
- この機器に、異物（燃えやすいもの、硬貨、針金など）や液体（水、ジュースなど）を絶対に入れないでください。 


警告

- お子様のいるご家庭で使用する場合、お子様の取り扱いやいたずらに注意してください。必ず大人のかたが、監視／指導してあげてください。 
- この機器を落としたり、この機器に強い衝撃を与えないでください。 
- SRX-09 を取り付ける前に、Fantom シリーズ、XV シリーズ、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760 の電源を切って電源プラグをコンセントから外してください。 
- CD-ROM を、一般のオーディオ CD プレーヤーで再生しないで下さい。大音量によって耳を痛めたり、スピーカーを破損する恐れがあります。 

注意

- この機器の上に乗ったり、機器の上に重いものを置かないでください。 
- 指定の機器（Fantom シリーズ、XV シリーズ、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760）だけに取り付け、取り付け時には指定されたネジだけを外してください。 
- ネジを外した場合は、小さなお子様が誤って飲み込んだりすることのないようお子様の手の届かないところへ保管してください。 

※ 製品の仕様および内容は、改良のため予告なく変更することがあります。

IMPORTANT NOTES

When you purchase the SRX-09 expansion board from an authorized Roland dealer, the included sounds and samples are licensed, not sold, to you by Roland Corporation, for commercial use in music production, public performance, broadcast, etc.

You may use any of the included phrases and/or samples in a commercial or non-commercial recording without paying any additional license fees. However, you must strictly adhere to the following crediting guidelines on any music recording that utilize material from SRX-09.

Reproduction or duplication of this collection or any of the sound recording contained in the SRX-09, either as they exist on this expansion board or by any means of reformatting, mixing, filtering, re-synthesizing, processing or otherwise editing for use in another product or for re-sale, is strictly prohibited without the express written consent of Roland. All unauthorized giving, trading, lending, renting, re-issue, re-distribution or re-sale of the sounds included in the SRX-09 are expressly prohibited.

In Plain English: Be creative in your application of the SRX-09 sounds, and keep this library for your use only. DO NOT COPY IT. Roland constantly monitors other Soundware releases to check for copyright infringements, and will prosecute all piracy and copyright violations to the fullest extent of the law. THIS LIBRARY IS GUARANTEED TO BE 100% COPYRIGHT CLEAN.

In addition to the items listed under "USING THE UNIT SAFELY" on page 2, please read and observe the following:

Handling CD-ROMs

- * Avoid touching or scratching the shiny underside (encoded surface) of the disc. Damaged or dirty CD-ROM discs may not be read properly. Keep your discs clean using a commercially available CD cleaner.

Handling the Board

To avoid the risk of damage to internal components that can be caused by static electricity, please carefully observe the following whenever you handle the board.

- * Before you touch the board, always first grasp a metal object (such as a water pipe), so you are sure that any static electricity you might have been carrying has been discharged.
- * When handling the board, grasp it only by its edges. Avoid touching any of the electronic components or connectors.
- * Save the bag in which the board was originally shipped, and put the board back into it whenever you need to store or transport it.

French language for Canadian Safety Standard

Veillez suivre attentivement les instructions suivantes quand vous manipulez la carte afin d'éviter tout risque d'endommagement des pièces internes par l'électricité statique.

- * Toujours toucher un objet métallique relié à la terre (comme un tuyau par exemple) avant de manipuler la carte pour vous décharger de l'électricité statique que vous auriez pu accumuler.
- * Lorsque vous manipulez la carte, la tenir par les côtés. Évitez de toucher aux composants ou aux connecteurs.
- * Conservez le sachet d'origine dans lequel était la carte lors de l'envoi et remettez la carte dedans si vous devez la ranger ou la transporter.

使用上のご注意

お客様がSRX-09 エクスパンション・ボード（以下、「本製品」といいます）をローランドの正規販売店からお買い上げになった時点で、本製品に含まれる音やサンプルは、ローランド株式会社から、お客様に対して、音楽制作、公共の場での演奏、放送などの商用目的のための使用を許諾したものであって、著作権を譲渡したものではありません。

お客様は、いかなる追加料金を支払うこともなく、本製品に含まれるあらゆるフレーズやサンプルを、商用あるいは非商用目的の録音に使用できます。ただし、お客様が本製品を使用して音楽の録音を行う際は、以下のことにご注意ください。

本製品に含まれるいかなる録音物も、そのままの状態であれ、いかなる手段によって再構成、ミキシング、フィルター加工、再合成、加工処理、その他の編集作業をした状態であれ、ローランドの書面による許可なく、他の製品に含めたり再販売するために複製・複写することを禁止します。また、本製品に含まれるいかなる音も、許可なく贈与、取引、貸与、賃貸、再発行、再配布、再販売することを禁止します。

従って、本製品の音色は音楽制作の範囲でお使いいただくようお願いいたします。そして、本製品のライブラリーはお客様ご自身の個人的使用の目的の範囲でお使いください。本製品の音色データの複製・複写は禁止します。

ローランドは、著作権侵害がないかどうか、常時他のサウンド・ライブラリーの発売を把握しており、著作権侵害に対しては法的手段を行使する場合があります。

なお、本製品のライブラリーは第三者の著作権を一切侵害していないことを保証します。

3 ページに記載されている「安全上のご注意」以外に、次のことに注意してください。

修理について

- * お客様がこの機器を分解、改造された場合、以後の性能について保証できなくなります。また、修理をお断りする場合があります。
- * 当社では、この製品の補修用性能部品（製品の機能を維持するために必要な部品）を、製造切後 6 年間保有しています。この部品保有期間を修理可能の期間とさせていただきます。なお、保有期間が経過した後も、故障箇所によっては修理可能の場合がありますので、お買い上げ店、または最寄りのローランド・サービスにご相談ください。

CD-ROM の取り扱い

- * ディスクの裏面（信号面）に触れたり、傷をつけたりしないでください。データの読み出しがうまくいかないことがあります。ディスクの汚れは、市販の CD 専用クリーナーでクリーニングしてください。

基板の取り扱い

この基板は、静電気により部品が破壊される恐れがあります。基板を取り扱うときは、次の点に注意してください。

- * 基板を持つときは、あらかじめ何らかの金属に触れて、体や衣類にたまっている静電気を放電してください。
- * 基板を持つときは、基板の縁を持ち、部品やコネクタの部分に直接手を触れないでください。
- * 基板を保管するとき、または輸送するときなどは、購入時に基板が入っていた袋（導電袋）に入れてください。

INSTALLING THE WAVE EXPANSION BOARD

* Turn off your instrument.

1. Remove the cover located on the top (or rear) of your instrument.
 - * When turning the unit upside-down, get a bunch of newspapers or magazines, and place them under the four corners or at both ends to prevent damage to the buttons and controls. Also, you should try to orient the unit so no buttons or controls get damaged.
 - * When turning the unit upside-down, handle with care to avoid dropping it, or allowing it to fall or tip over.
2. Insert the Wave Expansion Board connector into a connector for an SRX Series slot, while simultaneously inserting the board holders into the holes in the Wave Expansion Board.
 - * Do not touch any of the printed circuit pathways or connection terminals.
 - * Never use excessive force when installing a circuit board. If it doesn't fit properly on the first attempt, remove the board and try again.
3. Use the supplied Installation Tool to turn the holders in the LOCK direction, so the board will be fastened in place. (To remove the Wave Expansion Board, turn the board holders in the UNLOCK direction, and lift up the board.)
 - * When circuit board installation is complete, double-check your work.
4. Using the screws removed in Step 1, refasten the cover in its original position.
5. Check if the Wave Expansion Board is correctly installed.
 - * If the "EXP" display cannot be selected (doesn't appear) in the Waveform Selection Screen (refer to the owner's manual of the instrument you use), remove the Wave Expansion Board and install it properly.


French language for Canadian Safety Standard

* Éteindre l'instrument.

1. Retirer le couvercle situé sur le dessus (ou à l'arrière) de l'instrument.
2. Insérer le connecteur de la carte dans un des creneaux pour la serie SRX tout en enfonçant les supports à carte dans les trous de celle-ci.
 - * Ne pas toucher aux circuits imprimés ou aux connecteurs.
 - * Ne jamais forcer lors de l'installation de la carte de circuits imprimés. Si la carte s'ajuste mal au premier essai, enlevez la carte et recommencez l'installation.
3. Utiliser l'outil d'installation fourni pour tourner les clips de retenue vers la position de blocage (LOCK) de façon à ce que la carte soit retenue en place.



(Pour retirer la carte d'expansion Wave, tourner les clips de retenue de la carte vers la position déblocage (UNLOCK) et retirer la carte en la soulevant.)

 - * Quand l'installation de la carte de circuits imprimés est terminée, revérifiez si tout est bien installé.
4. Remettre la plaque à sa place et la fixer à l'aide des vis enlevées à l'étape 1.
5. S'assurer que la carte d'expansion Wave est installée correctement.
 - * S'il est impossible de sélectionner l'affichage "EXP" (il n'apparaît pas) à l'écran de sélection Waveform (se reporter au guide du propriétaire de l'instrument utilisé), retirer la carte d'expansion Wave et la réinstaller correctement.



1 Screwdriver
Tournevis
ドライバー

2 Wave Expansion Board (SRX series)
Carte d'extension Wave (serie SRX)
ウェーブ・エクスパンション・ボード (SRXシリーズ)



Position them as shown before you install the board.
Avant l'installation, orienter les supports à carte tel qu'indiqué sur le schéma.
取り付ける前に図のような向きに合わせます

ウェーブ・エクスパンション・ボードの取り付けかた

※ 使用機器の電源スイッチをオフにしてください。

1. 使用機器の上部、または背面にあるカバーをはずします。
 - ※ 本体を裏返す際は、ボタン、つまみなどを破損しないように、新聞や雑誌などを重ねて本体の四隅や両端に敷いてください。また、その際、ボタン、つまみなどが破損しないような位置に配置してください。
 - ※ 本体を裏返す際は、落下や転倒を引き起こさないよう取扱いにご注意ください。
2. SRX シリーズ用のスロットのコネクターにウェーブ・エクスパンション・ボードのコネクターを差し込み、同時に基板ホルダーをウェーブ・エクスパンション・ボードの穴にはめ込みます。
 - ※ 回路部やコネクター部には手を触れないでください。
 - ※ 基板を無理に押し込まないでください。装着しにくい場合、いったん基板を外してやり直してください。
3. 付属の固定用具で基板ホルダーを LOCK 方向に回し、ウェーブ・エクスパンション・ボードを固定します。(ウェーブ・エクスパンション・ボードを取り外すには、基板ホルダーを UNLOCK 方向に回してから取り外します。)
 - ※ 取り付けを終えたら、正しく取り付けられていることを再度確認してください。
4. 手順 1 で外したネジで、カバーを元通りに取り付けます。
5. ウェーブ・エクスパンション・ボードの取り付けが正しく行われたかを確認します。
 - ※ ウェーブフォームの選択画面(使用機器の取扱説明書参照)で“EXP”が選べない(表示されない)ときは、もう一度ウェーブ・エクスパンション・ボードをつけ直してください。

Patch List (1)

For Fantom series/XV series/MX-200

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category
1	World Sounds	1	BEAT&GROOVE
2	Go2China /C2	2	COMBINATION #
3	Go2India /C2	2	COMBINATION #
4	The Great W	6	FLUTE
5	Yuehchin+	4	PLUCKED
6	Sweet Nylon	2	AC.GUITAR
7	Tele R&F	3	EL.GUITAR
8	Tubby Baby	3	BASS
9	HeavenGender	5	BELL
10	Gamelan Ems	4	MALLET
11	Childwood	4	MALLET
12	La Musette	1	ACCORDION
13	Essence	4	WIND
14	Zampona /	1	FLUTE
15	GipsyTrumpt/	1	AC.BRASS
16	We Dream	4	SOFT PAD
17	Fun WithPerc	1	PERCUSSION
18	GuZheng arp	2	SYNTH FX
19	Feets	4	SOUND FX
20	World Radio	5	BEAT&GROOVE
21	ClanAdvances	3	BEAT&GROOVE
22	Eastern Tour	4	BEAT&GROOVE
23	Enough!STOP!	3	BEAT&GROOVE
24	Banjo Phrs	1	BEAT&GROOVE
25	Guitar Phrs1	1	BEAT&GROOVE
26	Guitar Phrs2	1	BEAT&GROOVE
27	PdIstl Phrs	1	BEAT&GROOVE
28	Asia UFO	4	BEAT&GROOVE
29	UBeenSoBaa	8	BEAT&GROOVE
30	Didgeri /	1	BEAT&GROOVE
31	WorldGroove	3	BEAT&GROOVE #
32	LoopPhrase 1	5	BEAT&GROOVE #
33	LoopPhrase 2	5	BEAT&GROOVE #
34	TABLA groove	2	BEAT&GROOVE
35	JasonGoEast	5	COMBINATION #
36	Flu&AcompSRX	3	COMBINATION
37	Split Floot	2	COMBINATION #
38	Hot Salsa	2	COMBINATION #
39	TempBassSolo	2	COMBINATION #
40	CherryFlower	4	COMBINATION
41	SplitThisSRX	1	COMBINATION
42	Crane Dance	4	COMBINATION
43	LostInMists	1	COMBINATION
44	Qu DiEnsembl	3	COMBINATION
45	NasalBlossom	6	COMBINATION
46	Meditation 1	4	PLUCKED
47	Art Of Feng	4	PLUCKED
48	Orient xPres	4	PLUCKED
49	Padded Sitar	5	PLUCKED
50	No Worries	4	PLUCKED
51	IntarMelSRX	4	PLUCKED
52	Ode 2 An Oud	5	PLUCKED
53	Fugi-man	6	PLUCKED
54	China pluck	2	PLUCKED
55	Yuehchin SRX	1	PLUCKED
56	Kayakeum	1	PLUCKED
57	Asian Pizz	3	PLUCKED
58	PiPa SRX	3	PLUCKED
59	Koto SRX	1	PLUCKED
60	Shamisen SRX	2	PLUCKED
61	Sanshin SRX	1	PLUCKED
62	Yang Qin trm	1	PLUCKED
63	Yang Qin/Mod	3	PLUCKED
64	SultanPalace	4	PLUCKED
65	Marco Polo	3	PLUCKED
66	Bandolim SRX	1	PLUCKED
67	K.Bandolim	2	PLUCKED
68	Afro Harp	3	PLUCKED
69	Ethnhit!	8	PLUCKED
70	OctaHarp+	2	PLUCKED
71	St.GuZhngSRX	2	PLUCKED
72	Zheng Zither	4	PLUCKED
73	Distance	5	PLUCKED
74	Mandolin/Mod	4	PLUCKED
75	Mandolin	2	PLUCKED
76	Mando Club	3	PLUCKED
77	MdlnTrmStSRX	4	PLUCKED
78	Drone Sitar	1	PLUCKED
79	Conch&Sitar	6	PLUCKED
80	Punjab Rocks	4	PLUCKED
81	Pas2IndiaSRX	3	PLUCKED
82	Rain Drone	3	PLUCKED
83	SitarGlisSRX	1	PLUCKED
84	Tambura SRX	2	PLUCKED
85	TambDroneSRX	1	PLUCKED
86	St.SanturSRX	2	PLUCKED
87	SanturTrmSRX	1	PLUCKED
88	Santur /Mod	2	PLUCKED
89	Canton	3	PLUCKED
90	HamrDulcimer	2	PLUCKED

No.	Name	Voices	Category
91	3D Dulcimer	3	PLUCKED
92	Zither	1	PLUCKED
93	Magic Pluck	3	PLUCKED
94	Biwa SRX	2	PLUCKED
95	Biwa Menu	1	PLUCKED
96	BerimbauMenu	1	PLUCKED
97	Berimbau	2	PLUCKED
98	JawHarp Menu	1	PLUCKED
99	Steel Rhythm	1	AC.GUITAR
100	SoloSteelGtr	3	AC.GUITAR
101	N'Ville Soft	3	AC.GUITAR
102	Spruce Top	2	AC.GUITAR
103	Procssd AGtr	4	AC.GUITAR
104	High Strung	1	AC.GUITAR
105	Compresd D18	1	AC.GUITAR
106	12 String	2	AC.GUITAR
107	Mixed 12Str1	2	AC.GUITAR
108	Mixed 12Str2	3	AC.GUITAR
109	Ac Gtr 12stg	2	AC.GUITAR
110	No Borders	4	AC.GUITAR
111	Loose 12Str	3	AC.GUITAR
112	Living R.Gtr	4	AC.GUITAR
113	Dobro Modro	2	AC.GUITAR
114	ResonatorGtr	2	AC.GUITAR
115	Ac.Gtrs SRX	2	AC.GUITAR
116	2 Players	4	AC.GUITAR
117	Solo RequGtr	4	AC.GUITAR
118	Loose Nylon	4	AC.GUITAR
119	AcousticBros	4	AC.GUITAR
120	So Sad Nylon	5	AC.GUITAR
121	Chinese Duo	4	AC.GUITAR
122	ChugRunTrSRX	3	AC.GUITAR
123	Chung Ruan	1	AC.GUITAR
124	ChungRuanSRX	1	AC.GUITAR
125	Bottom Ruan	2	AC.GUITAR
126	KuangGtr SRX	3	AC.GUITAR
127	Oud SRX	1	AC.GUITAR
128	BugrsSldSRX	1	AC.GUITAR
129	Guitar SRX	2	AC.GUITAR
130	Natural Tele	2	EL.GUITAR
131	Psyche Tele	1	EL.GUITAR
132	Coral	2	EL.GUITAR
133	Chorus Twang	4	EL.GUITAR
134	Pick Licker	3	EL.GUITAR
135	CleanStrtSRX	2	EL.GUITAR
136	Velo 335 SRX	2	EL.GUITAR
137	Right Funky	4	EL.GUITAR
138	Comp Muted	2	EL.GUITAR
139	E.GtrMt SRX	1	EL.GUITAR
140	335VelMt SRX	2	EL.GUITAR
141	Wide Guitar	1	EL.GUITAR
142	Dob-Compress	2	EL.GUITAR
143	Nice Twelvey	4	EL.GUITAR
144	RotaryCrunch	2	EL.GUITAR
145	FastRotrySRX	3	EL.GUITAR
146	EGDynaPikSRX	2	EL.GUITAR
147	BackingEGSRX	2	EL.GUITAR
148	Room Slide	1	EL.GUITAR
149	Pedal Steel	1	EL.GUITAR
150	Phased P.Stl	3	EL.GUITAR
151	PureSteelSRX	1	EL.GUITAR
152	Muted Ambient	4	EL.GUITAR
153	GtrFX Menu	1	EL.GUITAR
154	LP Gtr SRX	1	DIST.GUITAR
155	Tele-Funfken	2	DIST.GUITAR
156	335 &Cabinet	3	DIST.GUITAR
157	Tele Licker	3	DIST.GUITAR
158	Short & Long	2	DIST.GUITAR
159	NewBeginning	4	FRETTED
160	Bouzouki	2	FRETTED
161	Bousoukhit!	8	FRETTED
162	3ChdStrumSRX	1	FRETTED
163	Strum Poetic	4	FRETTED
164	Strum Away	4	FRETTED
165	Banjo-Mando	3	FRETTED
166	5StringBanjo	1	FRETTED
167	Banjo SRX 1	2	FRETTED
168	Banjo SRX 2	1	FRETTED
169	Banjo SRX 3	1	FRETTED
170	Fiddle	2	STRINGS
171	Fiddle 2002	2	STRINGS
172	FiddleSwitch	1	STRINGS
173	Fiddle Sect.	4	STRINGS
174	FiddleStacto	4	STRINGS
175	AsianOrcPizz	6	STRINGS
176	AJapaneseln	3	STRINGS
177	Deep Blue	4	STRINGS
178	Ethnic Ens	4	STRINGS
179	ChinesOrcSRX	4	STRINGS
180	ErHu / SRX	1	STRINGS

No.	Name	Voices	Category
181	ErHuSolo SRX	1	STRINGS
182	ErHu Ld SRX	2	STRINGS
183	FiddleFXmenu	1	STRINGS
184	ViolnSoloSRX	1	STRINGS
185	Comp BabyBss	2	BASS
186	Baby Bass	1	BASS
187	Comp Fingerd	2	BASS
188	Jazz Fing.BS	1	BASS
189	Live Bass	2	BASS
190	Flango Bass	3	BASS
191	Bass Oddesy	2	BASS
192	6Str Bs SRX1	1	BASS
193	Muted Bass	1	BASS
194	6Str/Mt SRX	3	BASS
195	PickBsHd SRX	1	BASS
196	PickedBs SRX	1	BASS
197	Tub Bass	2	BASS
198	GuitarnBsSRX	2	BASS
199	GtrmOct SRX	3	BASS
200	PacificDream	4	BELL
201	Meditation 2	3	BELL
202	HybridKemong	3	BELL
203	Purify	4	BELL
204	Asia Bells	2	BELL
205	Rama Cym SRX	2	BELL
206	Bell Orchest	5	BELL
207	Sacred Bells	2	BELL
208	Spokes	3	BELL
209	Winter Bells	2	BELL
210	Wind Bells	1	BELL
211	BelAngk SRX	2	MALLET
212	Tcheekolyna	2	MALLET
213	Wood EPiano	3	MALLET
214	Kalimba	3	MALLET
215	Kalimbatch	2	MALLET
216	VelAfro SRX1	2	MALLET
217	BsKalimbaSRX	3	MALLET
218	LogDetumrSRX	2	MALLET
219	Baateri SRX	3	MALLET
220	Balafon SRX	3	MALLET
221	Asian Wood	2	MALLET
222	Mellow tone	2	MALLET
223	Glas Mlt SRX	2	MALLET
224	SteelDr SRX1	1	MALLET
225	SteelDr SRX2	2	MALLET
226	Gendrous SRX	3	MALLET
227	BonangGamSRX	1	MALLET
228	VelAfro SRX2	2	MALLET
229	TemleMetlSRX	3	MALLET
230	Kemong / SRX	3	MALLET
231	Kane / SRX	1	MALLET
232	JeGong / SRX	3	MALLET
233	Jegogn / SRX	1	MALLET
234	Jublag / SRX	1	MALLET
235	Reyong / SRX	1	MALLET
236	Pemade / SRX	1	MALLET
237	Cajun	2	ACCORDION
238	D.Accordion	4	ACCORDION
239	SqueezeBoxSRX	2	ACCORDION
240	Squeeze Box	2	ACCORDION
241	St.AccOp SRX	2	ACCORDION
242	AccionOp SRX	1	ACCORDION
243	Acid fOp SRX	2	ACCORDION
244	St.AccCl SRX	2	ACCORDION
245	Bluesy	1	HARMONICA
246	HarmonicaSRX	2	HARMONICA
247	CuntryHrpSRX	2	HARMONICA
248	Sessn HrpSRX	1	HARMONICA
249	Esraj&Mizmar	3	WIND
250	Before Time	1	WIND
251	Gagaku Ems	4	WIND
252	Mizmar solo	1	WIND
253	PiriSolo SRX	2	WIND
254	Shahnai SRX	1	WIND
255	HichirikSRX	2	WIND
256	Bagpipes SRX	2	WIND
257	Sheng / SRX	1	WIND
258	Suona / SRX	1	WIND
259	VillageDance	4	FLUTE
260	Indian Ens	4	FLUTE
261	Nature Loves	4	FLUTE
262	PanPipes SRX	2	FLUTE
263	Sad Pipe	1	FLUTE
264	Shell blow	1	FLUTE
265	Desert Flute	2	FLUTE
266	Zampona	2	FLUTE
267	Isolation	2	FLUTE
268	Ocarina	2	FLUTE
269	New IndFlute	1	FLUTE
270	Qu Di Vib	2	FLUTE

Patch List (2)

For Fantom series/XV series/MX-200

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category
271	Bang Di Vib	2	FLUTE
272	New Kawala	1	FLUTE
273	BreathyIndia	3	FLUTE
274	New Shaku	2	FLUTE
275	Shakuhachi	2	FLUTE
276	DreamInColor	4	FLUTE
277	TwinHillyLd	2	FLUTE
278	Snake Eyes	3	AC.BRASS
279	Latin Trumplt	1	AC.BRASS
280	MariachiTpts	3	AC.BRASS
281	Trumpets	3	AC.BRASS
282	GrowlWah/Mod	2	AC.BRASS
283	Muted-Grw /	1	AC.BRASS
284	SoloTuba SRX	1	AC.BRASS
285	LatinTubaSRX	1	AC.BRASS
286	World Orch	7	AC.BRASS
287	Stab&Hold	4	AC.BRASS
288	Indian Radio	8	AC.BRASS
289	Wide Brass	3	AC.BRASS
290	Trombones	4	AC.BRASS
291	Brass Snapz	4	AC.BRASS
292	Brass sfzzz	6	AC.BRASS
293	2Tp+Tbn SRX	1	AC.BRASS
294	MemphisHORNS	1	AC.BRASS
295	SectStactSRX	1	AC.BRASS
296	LatinBrasses	2	AC.BRASS
297	Hit & Fall	2	AC.BRASS
298	BrsChd13 SRX	3	AC.BRASS
299	BrsChdMj9SRX	3	AC.BRASS
300	BrsChdMj9SRX	3	AC.BRASS
301	Blow Pad	2	BRIGHT PAD
302	Ceremony	4	BRIGHT PAD
303	Glasses	3	BRIGHT PAD
304	Ambicordian	6	BRIGHT PAD
305	DroneFlanger	3	BRIGHT PAD
306	Rock Gods	5	BRIGHT PAD
307	ScotlandLass	4	BRIGHT PAD
308	Dry Fishes	6	BRIGHT PAD
309	SteroidBrass	4	BRIGHT PAD
310	Soul revived	4	SOFT PAD
311	Rain Pad	3	SOFT PAD
312	Rising Sun	4	SOFT PAD
313	Ethnopad	3	SOFT PAD
314	Ethno Strngs	6	SOFT PAD
315	& 40 Thieves	5	SOFT PAD
316	TromboSynthy	5	OTHER SYNTH
317	GrandExaltd1	3	OTHER SYNTH
318	Sun Dog	4	OTHER SYNTH
319	TechnoSpirit	4	TECHNO SYNTH
320	Play Softly	4	TECHNO SYNTH
321	WorkerBeetle	3	TECHNO SYNTH
322	Glass Cut	3	TECHNO SYNTH
323	GuruTronics	4	PULSATING
324	DubJazz Trip	4	PULSATING
325	Meditation 2	4	PULSATING
326	Political	4	PULSATING
327	G'day Mate	4	PULSATING
328	Mission	4	ORGAN
329	Jegorgan	3	ORGAN
330	Dyno Conga 1	1	PERCUSSION

No.	Name	Voices	Category
331	Dyno Conga 2	1	PERCUSSION
332	Congas+Bongo	1	PERCUSSION
333	DynTimbale 1	1	PERCUSSION
334	DynTimbale 2	1	PERCUSSION
335	TimbaleCuica	1	PERCUSSION
336	Dyno Surdo	1	PERCUSSION
337	Rhythm Sect	4	PERCUSSION
338	Rainstick	1	PERCUSSION
339	Clap & Snap	4	PERCUSSION
340	CowbellRandm	1	PERCUSSION
341	Karachi-Man	4	PERCUSSION
342	That Was Zen	4	PERCUSSION
343	StreetParade	4	PERCUSSION
344	BUK	1	PERCUSSION
345	Gongs	2	PERCUSSION
346	Chenchen /	2	PERCUSSION
347	WisdomWithin	4	PERCUSSION
348	Tabla+	4	PERCUSSION
349	DrumsScene	3	PERCUSSION
350	Doholla Fun	1	PERCUSSION
351	AfricanRhtms	2	PERCUSSION
352	Big Logs SRX	2	PERCUSSION
353	WarDrums SRX	4	PERCUSSION
354	Samba Menu	1	PERCUSSION
355	Shaker Menu	1	PERCUSSION
356	Caixa Menu	1	PERCUSSION
357	Cowbell Menu	1	PERCUSSION
358	JapanPrcMenu	1	PERCUSSION
359	Kabuki Menu	1	PERCUSSION
360	KwangwariSRX	2	PERCUSSION
361	Tuzumi / SRX	1	PERCUSSION
362	KoreaPrcMenu	1	PERCUSSION
363	ChinaPrcMenu	1	PERCUSSION
364	China Menu	1	PERCUSSION
365	ChinaGongSRX	3	PERCUSSION
366	Sanba / SRX	3	PERCUSSION
367	St.ShouBoSRX	4	PERCUSSION
368	AsiaCym Menu	1	PERCUSSION
369	Gong Menu	1	PERCUSSION
370	Gamelan Menu	1	PERCUSSION
371	GamlnPrcMenu	1	PERCUSSION
372	BigBazar SRX	1	PERCUSSION
373	Udu Pot Menu	1	PERCUSSION
374	TablaBy Menu	1	PERCUSSION
375	Rek Menu	1	PERCUSSION
376	Dholak Menu1	1	PERCUSSION
377	Dholak Menu2	1	PERCUSSION
378	Dhol Menu	1	PERCUSSION
379	Egypt Tablah	1	PERCUSSION
380	Madal Menu	1	PERCUSSION
381	AfropercMenu	1	PERCUSSION
382	CommSatelite	6	SYNTH FX
383	Amazone	1	SYNTH FX
384	Tasman Sea	3	SYNTH FX
385	Ethnic FX 1	4	SYNTH FX
386	Ethnic FX 2	4	SYNTH FX
387	SpacetalBoy	4	SYNTH FX
388	Crystal	1	SYNTH FX
389	SpaceLuvSick	6	SYNTH FX
390	HitAscension	4	SYNTH FX

No.	Name	Voices	Category
391	Nervous Man	1	SYNTH FX
392	Silk Stream	1	SYNTH FX
393	DerangedMind	3	SYNTH FX
394	PolyDrone	4	SYNTH FX
395	TequillaWorm	5	SYNTH FX
396	GlistenToYou	4	SYNTH FX
397	Dream Harp	2	SYNTH FX
398	Waterfall	2	SYNTH FX
399	Gender 3D	4	SYNTH FX
400	Doom Drum	5	SYNTH FX
401	Stalker	3	SYNTH FX
402	PlasticBones	4	SYNTH FX
403	PakistanVibe	4	SYNTH FX
404	ThusSpokeZtr	5	SYNTH FX
405	Kalissando	4	SYNTH FX
406	Rain Forest	2	SOUND FX
407	AfropunchSRX	4	SOUND FX
408	Dance Tape	8	SOUND FX
409	Zaghruta SRX	2	VOX
410	1,2,3,4! SRX	4	VOX
411	Voices SRX	2	VOX
412	Voice Menu 1	1	VOX
413	Voice Menu 2	1	VOX
414	Voice Menu 3	1	VOX

/: Alternate sound obtained with Key Velocity
/Mod: Alternate sound obtained with Modulation (CC:01)

#: Patches using Phrase Loop Waveforms. The numbers included in the Patch name represent the recommended tempo (B.P.M.).

When playing patches on the expansion board, we recommend that you set all the EFFECTS ON/OFF settings on the Fantom series/XV series to "ON." If such settings are set to "OFF," you may not obtain the intended sound.

- * Note that the Release Time has been set to a fairly long value for some of the patches. As a result, if your sound generator has been set so "Patch Remain" is "ON," the release portion of a previously sounding patch may continue to be heard even after switching to a new patch.
- * Some of the patches use waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.
- * Refer to the owner's manual for your instrument for specific instructions on how to play Patches on the expansion board.
- * On the Fantom series/XV series/MX-200, you can not select only the patches which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

/: Key Velocity による切替え音色
/Mod: Modulation (CC:01) による切替え音色

#: フレーズ・ループのウェーブフォームを使用したパッチです。パッチ・ネームに付いている数字は推奨テンポ (B.P.M.) です。

エキスパンション・ボードのパッチを発音させるときは、Fantom シリーズ/XV シリーズの EFFECTS ON/OFF の設定をすべて ON にして使用することをお勧めいたします。OFF に設定した場合、意図した音色にならないことがあります。

- ※ パッチの中にはリリース・タイムが長く設定してあるパッチもありますので、音源のパッチ・リメインが ON になっていると音色を切り替えても前のパッチのリリースが残る場合があります。
- ※ パッチの中には SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。
- ※ エキスパンション・ボードのパッチを発音させるときは、使用機器の取扱説明書にしたがって、実行してください。
- ※ Fantom シリーズ/XV シリーズ/MX-200 では、RD シリーズ (SRX 対応) /MC-909/VR-760 専用のパッチを選ぶことはできません。

Patch List (3)

For RD series (with SRX slots)/MC-909/VR-760/G-70

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category	No.	Name	Voices	Category	No.	Name	Voices	Category
1	World Sounds	1	BEAT&GROOVE	91	3D Dulcimer	3	PLUCKED	181	ErHuSolo SRX	1	STRINGS
2	Go2China /C2	2	COMBINATION #	92	Zither	1	PLUCKED	182	ErHu Ld SRX	2	STRINGS
3	Go2India /C2	2	COMBINATION #	93	Magic Pluck	3	PLUCKED	183	FiddleFXmenu	1	STRINGS
4	The Great W	6	FLUTE	94	Biwa SRX	2	PLUCKED	184	ViolnSoloSRX	1	STRINGS
5	Yuehchin+	4	PLUCKED	95	Biwa Menu	1	PLUCKED	185	Comp BabyBss	2	BASS
6	Sweet Nylon	2	AC.GUITAR	96	BerimbauMenu	1	PLUCKED	186	Baby Bass	1	BASS
7	Tele R&F	3	EL.GUITAR	97	Berimbau	2	PLUCKED	187	Comp Fingerd	2	BASS
8	Tubby Baby	3	BASS	98	JawHarp Menu	1	PLUCKED	188	Jazz Fing.BS	1	BASS
9	HeavenGender	5	BELL	99	Steel Rhythm	1	AC.GUITAR	189	Live Bass	2	BASS
10	Gamelan Ems	4	MALLET	100	SoloSteelGtr	3	AC.GUITAR	190	Flango Bass	3	BASS
11	Childwood	4	MALLET	101	N'Ville Soft	3	AC.GUITAR	191	Bass Oddesy	2	BASS
12	La Musette	1	ACCORDION	102	Spruce Top	2	AC.GUITAR	192	6Str Bs SRX1	1	BASS
13	Essence	4	WIND	103	Procssd AGtr	4	AC.GUITAR	193	Muted Bass	1	BASS
14	Zampona /	1	FLUTE	104	High Strung	1	AC.GUITAR	194	6Str/Mt SRX	3	BASS
15	GipsyTrumpt/	1	AC.BRASS	105	Compresd D18	1	AC.GUITAR	195	PickBsHd SRX	1	BASS
16	We Dream	4	SOFT PAD	106	12 String	2	AC.GUITAR	196	PickedBs SRX	1	BASS
17	Fun WithPerc	1	PERCUSSION	107	Mixed 12Str1	2	AC.GUITAR	197	Tub Bass	2	BASS
18	GuZheng arp	2	SYNTH FX	108	Mixed 12Str2	3	AC.GUITAR	198	GuitarnBsSRX	2	BASS
19	Feets	4	SOUND FX	109	Ac Gtr 12stg	2	AC.GUITAR	199	GtrmOct SRX	3	BASS
20	World Radio	5	BEAT&GROOVE	110	No Borders	4	AC.GUITAR	200	PacificDream	4	BELL
21	ClanAdvances	3	BEAT&GROOVE	111	Loose 12Str	3	AC.GUITAR	201	Meditation 2	3	BELL
22	Eastern Tour	4	BEAT&GROOVE	112	Living R.Gtr	4	AC.GUITAR	202	HybridKemong	3	BELL
23	Enough!STOP!	2	BEAT&GROOVE	113	Dobro Modro	2	AC.GUITAR	203	Purify	4	BELL
24	Banjo Phrs	1	BEAT&GROOVE	114	ResonatorGtr	2	AC.GUITAR	204	Asia Bells	2	BELL
25	Guitar Phrs1	1	BEAT&GROOVE	115	Ac.Gtrs SRX	2	AC.GUITAR	205	Rama Cym SRX	2	BELL
26	Guitar Phrs2	1	BEAT&GROOVE	116	2 Players	4	AC.GUITAR	206	Bell Orchest	5	BELL
27	PdlStl Phrs	1	BEAT&GROOVE	117	Solo RequGtr	4	AC.GUITAR	207	Sacred Bells	2	BELL
28	Asia UFO	4	BEAT&GROOVE	118	Loose Nylon	4	AC.GUITAR	208	Spokes	3	BELL
29	UBeenSoBaa	7	BEAT&GROOVE	119	AcousticBros	4	AC.GUITAR	209	Winter Bells	2	BELL
30	Didgeri /	1	BEAT&GROOVE	120	So Sad Nylon	5	AC.GUITAR	210	Wind Bells	1	BELL
31	WorldGroove	3	BEAT&GROOVE #	121	Chinese Duo	4	AC.GUITAR	211	BelAngk SRX	2	MALLET
32	LoopPhrase 1	5	BEAT&GROOVE #	122	ChugRunTrSRX	3	AC.GUITAR	212	Tcheekolyna	2	MALLET
33	LoopPhrase 2	5	BEAT&GROOVE #	123	Chung Ruan	1	AC.GUITAR	213	Wood EPiano	3	MALLET
34	TABLA groove	2	BEAT&GROOVE	124	ChungRuanSRX	1	AC.GUITAR	214	Kalimba	3	MALLET
35	JasonGoEast	6	COMBINATION #	125	Bottom Ruan	2	AC.GUITAR	215	Kalimbatach	2	MALLET
36	Flu&AcompSRX	4	COMBINATION	126	KuangGtr SRX	2	AC.GUITAR	216	VelAfro SRX1	2	MALLET
37	Split Floot	2	COMBINATION #	127	Oud SRX	1	AC.GUITAR	217	BsKalimbaSRX	3	MALLET
38	Hot Salsa	2	COMBINATION #	128	BuglrsSldSRX	1	AC.GUITAR	218	LogDetumrSRX	2	MALLET
39	TempBassSolo	2	COMBINATION #	129	Guitar SRX	2	AC.GUITAR	219	Baateri SRX	3	MALLET
40	CherryFlower	4	COMBINATION	130	Natural Tele	2	EL.GUITAR	220	Balafon SRX	3	MALLET
41	SplitThisSRX	1	COMBINATION	131	Psyche Tele	1	EL.GUITAR	221	Asian Wood	2	MALLET
42	Crane Dance	5	COMBINATION	132	Coral	2	EL.GUITAR	222	Mellow tone	2	MALLET
43	LostInMists	2	COMBINATION	133	Chorus Twang	4	EL.GUITAR	223	Glas Mlt SRX	2	MALLET
44	Qu DiEnsembl	3	COMBINATION	134	Pick Licker	3	EL.GUITAR	224	SteelDr SRX1	1	MALLET
45	NasalBlossom	6	COMBINATION	135	CleanStrtSRX	1	EL.GUITAR	225	SteelDr SRX2	2	MALLET
46	Meditation 1	4	PLUCKED	136	Velo 335 SRX	2	EL.GUITAR	226	Gendrous SRX	3	MALLET
47	Art Of Feng	4	PLUCKED	137	Right Funky	4	EL.GUITAR	227	BonangGamSRX	1	MALLET
48	Orient xPres	4	PLUCKED	138	Comp Muted	2	EL.GUITAR	228	VelAfro SRX2	2	MALLET
49	Padded Sitar	5	PLUCKED	139	E.GtrMt SRX	1	EL.GUITAR	229	TemleMetlSRX	3	MALLET
50	No Worries	4	PLUCKED	140	335VelMt SRX	2	EL.GUITAR	230	Kemong / SRX	3	MALLET
51	IntarMel SRX	4	PLUCKED	141	Wide Guitar	1	EL.GUITAR	231	Kane / SRX	1	MALLET
52	Ode 2 An Oud	5	PLUCKED	142	Dob-Compress	2	EL.GUITAR	232	JeGong / SRX	3	MALLET
53	Fugi-man	6	PLUCKED	143	Nice Twelvey	4	EL.GUITAR	233	Jegogn / SRX	1	MALLET
54	China pluck	2	PLUCKED	144	RotaryCrunch	2	EL.GUITAR	234	Jublag / SRX	1	MALLET
55	Yuehchin SRX	1	PLUCKED	145	FastRotrySRX	3	EL.GUITAR	235	Reyong / SRX	1	MALLET
56	Kayakeum	1	PLUCKED	146	EGDynaPikSRX	2	EL.GUITAR	236	Pemade / SRX	1	MALLET
57	Asian Pizz	3	PLUCKED	147	BackingEGSRX	2	EL.GUITAR	237	Cajun	2	ACCORDION
58	PiPa SRX	3	PLUCKED	148	Room Slide	1	EL.GUITAR	238	D.Accordion	4	ACCORDION
59	Koto SRX	1	PLUCKED	149	Pedal Steel	1	EL.GUITAR	239	SqueezeBoxSRX	2	ACCORDION
60	Shamisen SRX	2	PLUCKED	150	Phased P.Stl	3	EL.GUITAR	240	Squeeze Box	2	ACCORDION
61	Sanshin SRX	1	PLUCKED	151	PureSteelSRX	1	EL.GUITAR	241	St.AccOp SRX	2	ACCORDION
62	Yang Qin trm	1	PLUCKED	152	Muted Ambient	4	EL.GUITAR	242	AccionOp SRX	1	ACCORDION
63	Yang Qin/Mod	3	PLUCKED	153	GtrFX Menu	1	EL.GUITAR	243	Acid fOp SRX	2	ACCORDION
64	SultanPalace	4	PLUCKED	154	LP Gtr SRX	1	DIST.GUITAR	244	St.AccCl SRX	2	ACCORDION
65	Marco Polo	3	PLUCKED	155	Tele-Funfken	2	DIST.GUITAR	245	Bluesy	1	HARMONICA
66	Bandolim SRX	1	PLUCKED	156	335 &Cabinet	3	DIST.GUITAR	246	HarmonicaSRX	2	HARMONICA
67	K.Bandolim	2	PLUCKED	157	Tele Licker	3	DIST.GUITAR	247	CuntryHrpSRX	2	HARMONICA
68	Afro Harp	3	PLUCKED	158	Short & Long	2	DIST.GUITAR	248	Sessn HrpSRX	1	HARMONICA
69	Ethnhit!	8	PLUCKED	159	NewBeginning	4	FRETTED	249	Esraj&Mizmar	3	WIND
70	OctaHarp+	3	PLUCKED	160	Bouzouki	2	FRETTED	250	Before Time	1	WIND
71	St.GuZhngSRX	2	PLUCKED	161	Bousoukhit!	8	FRETTED	251	Gagaku Ems	4	WIND
72	Zheng Zither	4	PLUCKED	162	3ChdStrumSRX	1	FRETTED	252	Mizmar solo	1	WIND
73	Distance	5	PLUCKED	163	Strum Poetic	4	FRETTED	253	PiriSolo SRX	2	WIND
74	Mandolin/Mod	4	PLUCKED	164	Strum Away	4	FRETTED	254	Shahnai SRX	1	WIND
75	Mandolin	2	PLUCKED	165	Banjo-Mando	3	FRETTED	255	HichirikSRX	2	WIND
76	Mando Club	3	PLUCKED	166	5StringBanjo	1	FRETTED	256	Bagpipes SRX	2	WIND
77	MdlnTrmStSRX	4	PLUCKED	167	Banjo SRX 1	2	FRETTED	257	Sheng / SRX	1	WIND
78	Drone Sitar	1	PLUCKED	168	Banjo SRX 2	1	FRETTED	258	Suona / SRX	1	WIND
79	Conch&Sitar	6	PLUCKED	169	Banjo SRX 3	1	FRETTED	259	VillageDance	4	FLUTE
80	Punjab Rocks	4	PLUCKED	170	Fiddle	2	STRINGS	260	Indian Ens	4	FLUTE
81	Pas2IndiaSRX	3	PLUCKED	171	Fiddle 2002	2	STRINGS	261	Nature Loves	4	FLUTE
82	Rain Drone	3	PLUCKED	172	FiddleSwitch	1	STRINGS	262	PanPipes SRX	2	FLUTE
83	SitarGlsSRX	1	PLUCKED	173	Fiddle Sect.	4	STRINGS	263	Sad Pipe	1	FLUTE
84	Tambura SRX	2	PLUCKED	174	FiddleStacto	4	STRINGS	264	Shell blow	1	FLUTE
85	TambDroneSRX	1	PLUCKED	175	AsianOrcPizz	6	STRINGS	265	Desert Flute	2	FLUTE
86	St.SanturSRX	2	PLUCKED	176	AJapaneseln	3	STRINGS	266	Zampona	2	FLUTE
87	SanturTrmSRX	1	PLUCKED	177	Deep Blue	4	STRINGS	267	Isolation	3	FLUTE
88	Santur /Mod	2	PLUCKED	178	Ethnic Ens	4	STRINGS	268	Ocarina	2	FLUTE
89	Canton	3	PLUCKED	179	ChinesOrcSRX	4	STRINGS	269	New IndFlute	1	FLUTE
90	HamrDulcimer	2	PLUCKED	180	ErHu / SRX	1	STRINGS	270	Qu Di Vib	2	FLUTE

Patch List (4)

For RD series (with SRX slots)/MC-909/VR-760/G-70

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category	No.	Name	Voices	Category	No.	Name	Voices	Category
271	Bang Di Vib	2	FLUTE	321	WorkerBeetle	3	TECHNO SYNTH	371	GamlnPrcMenu	1	PERCUSSION
272	New Kawala	1	FLUTE	322	Glass Cut	3	TECHNO SYNTH	372	BigBazar SRX	1	PERCUSSION
273	BreathyIndia	3	FLUTE	323	GuruTronics	4	PULSATING	373	Udu Pot Menu	1	PERCUSSION
274	New Shaku	2	FLUTE	324	DubJazz Trip	4	PULSATING	374	TablaBy Menu	1	PERCUSSION
275	Shakuhachi	2	FLUTE	325	Meditation 2	4	PULSATING	375	Rek Menu	1	PERCUSSION
276	DreamInColor	4	FLUTE	326	Political	4	PULSATING	376	Dholak Menu1	1	PERCUSSION
277	TwinHillyLd	2	FLUTE	327	G`day Mate	4	PULSATING	377	Dholak Menu2	1	PERCUSSION
278	Snake Eyes	3	AC.BRASS	328	Mission	4	ORGAN	378	Dhol Menu	1	PERCUSSION
279	Latin Trumprt	1	AC.BRASS	329	Jegorgan	3	ORGAN	379	Egypt Tablah	1	PERCUSSION
280	MariachiTpts	3	AC.BRASS	330	Dyno Conga 1	1	PERCUSSION	380	Madal Menu	1	PERCUSSION
281	Trumpets	3	AC.BRASS	331	Dyno Conga 2	1	PERCUSSION	381	AfropercMenu	1	PERCUSSION
282	GrowlWah/Mod	2	AC.BRASS	332	Congas+Bongo	1	PERCUSSION	382	CommSatelite	6	SYNTH FX
283	Muted-Grw /	1	AC.BRASS	333	DynTimbale 1	1	PERCUSSION	383	Amazon	1	SYNTH FX
284	SoloTuba SRX	1	AC.BRASS	334	DynTimbale 2	1	PERCUSSION	384	Tasman Sea	4	SYNTH FX
285	LatinTubaSRX	1	AC.BRASS	335	TimbaleCuica	1	PERCUSSION	385	Ethnic FX 1	4	SYNTH FX
286	World Orch	7	AC.BRASS	336	Dyno Surdo	1	PERCUSSION	386	Ethnic FX 2	4	SYNTH FX
287	Stab&Hold	5	AC.BRASS	337	Rhythm Sect	4	PERCUSSION	387	SpacetualBoy	3	SYNTH FX
288	Indian Radio	8	AC.BRASS	338	Rainstick	1	PERCUSSION	388	Crystal	1	SYNTH FX
289	Wide Brass	3	AC.BRASS	339	Clap & Snap	4	PERCUSSION	389	SpaceLuvSick	6	SYNTH FX
290	Trombones	4	AC.BRASS	340	CowbellRandm	1	PERCUSSION	390	HitAscension	3	SYNTH FX
291	Brass Snapz	4	AC.BRASS	341	Karachi-Man	4	PERCUSSION	391	Nervous Man	1	SYNTH FX
292	Brass sfzzz	6	AC.BRASS	342	That Was Zen	4	PERCUSSION	392	Silk Stream	1	SYNTH FX
293	2Tp+Tbn SRX	1	AC.BRASS	343	StreetParade	4	PERCUSSION	393	DerangedMind	3	SYNTH FX
294	MemphisHORNS	1	AC.BRASS	344	BUK	1	PERCUSSION	394	PolyDrone	5	SYNTH FX
295	SectStactSRX	1	AC.BRASS	345	Gongs	2	PERCUSSION	395	TequillaWorm	4	SYNTH FX
296	LatinBrasses	2	AC.BRASS	346	Chenchen /	2	PERCUSSION	396	GlistenToYou	5	SYNTH FX
297	Hit & Fall	2	AC.BRASS	347	WisdomWithin	4	PERCUSSION	397	Dream Harp	2	SYNTH FX
298	BrsChd13 SRX	3	AC.BRASS	348	Tabla+	4	PERCUSSION	398	Waterfall	2	SYNTH FX
299	BrsChdMj9SRX	3	AC.BRASS	349	DrumsScene	3	PERCUSSION	399	Gender 3D	4	SYNTH FX
300	BrsChdMj9SRX	3	AC.BRASS	350	Doholla Fun	1	PERCUSSION	400	Doom Drum	5	SYNTH FX
301	Blow Pad	2	BRIGHT PAD	351	AfricanRhtms	2	PERCUSSION	401	Stalker	3	SYNTH FX
302	Ceremony	4	BRIGHT PAD	352	Big Logs SRX	2	PERCUSSION	402	PlasticBones	4	SYNTH FX
303	Glasses	3	BRIGHT PAD	353	WarDrums SRX	4	PERCUSSION	403	PakistanVibe	4	SYNTH FX
304	Ambiccordian	6	BRIGHT PAD	354	Samba Menu	1	PERCUSSION	404	ThusSpokeZtr	6	SYNTH FX
305	DroneFlanger	3	BRIGHT PAD	355	Shaker Menu	1	PERCUSSION	405	Kalissando	4	SYNTH FX
306	Rock Gods	5	BRIGHT PAD	356	Caixa Menu	1	PERCUSSION	406	Rain Forest	2	SOUND FX
307	ScotlandLass	4	BRIGHT PAD	357	Cowbell Menu	1	PERCUSSION	407	AfropunchSRX	4	SOUND FX
308	Dry Fishes	6	BRIGHT PAD	358	JapanPrcMenu	1	PERCUSSION	408	Dance Tape	8	SOUND FX
309	SteroidBrass	4	BRIGHT PAD	359	Kabuki Menu	1	PERCUSSION	409	Zaghruta SRX	2	VOX
310	Soul revived	4	SOFT PAD	360	KwangwariSRX	2	PERCUSSION	410	1,2,3,4! SRX	4	VOX
311	Rain Pad	3	SOFT PAD	361	Tuzumi / SRX	1	PERCUSSION	411	Voices SRX	2	VOX
312	Rising Sun	4	SOFT PAD	362	KoreaPrcMenu	1	PERCUSSION	412	Voice Menu 1	1	VOX
313	Ethnopad	3	SOFT PAD	363	ChinaPrcMenu	1	PERCUSSION	413	Voice Menu 2	1	VOX
314	Ethno Strngs	6	SOFT PAD	364	China Menu	1	PERCUSSION	414	Voice Menu 3	1	VOX
315	& 40 Thieves	5	SOFT PAD	365	ChinaGongSRX	3	PERCUSSION				
316	TromboSynthy	3	OTHER SYNTH	366	Sanba / SRX	3	PERCUSSION				
317	GrandExaltd1	2	OTHER SYNTH	367	St.ShouBoSRX	4	PERCUSSION				
318	Sun Dog	4	OTHER SYNTH	368	AsiaCym Menu	1	PERCUSSION				
319	TechnoSpirit	4	TECHNO SYNTH	369	Gong Menu	1	PERCUSSION				
320	Play Softly	4	TECHNO SYNTH	370	Gamelan Menu	1	PERCUSSION				

- /: Alternate sound obtained with Key Velocity
 /Mod: Alternate sound obtained with Modulation (CC:01)
 #: Patches using Phrase Loop Waveforms. The numbers included in the Patch name represent the recommended tempo (B.P.M.).
- * With some tones, tempos may change suddenly or noise may be produced. This occurs when the tempo is being synchronized, for example to multi-effects or chorus delay times. If the noise becomes noticeable, change the delay time value settings to something other than times corresponding to beats.
 - * Some of the patches use waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.
 - * On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the patches which are designed to be used with the Fantom series/XV series/MX-200.

- /: Key Velocity による切替え音色
 /Mod: Modulation (CC:01) による切替え音色
 #: フレーズ・ループのウェーブフォームを使用したパッチです。パッチ・ネームに付いている数字は推奨テンポ (B.P.M.) です。
- ※ 音色によっては、テンポを急激に変化させるとノイズが出る場合があります。これは、マルチエフェクトやコーラスのディレイ・タイムなどがテンポに同期している場合に発生します。ノイズが気になる場合は、ディレイ・タイムなどの設定を音符以外の値に変更してください。
 - ※ パッチの中には SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。
 - ※ SRX 対応の RD シリーズ /MC-909/VR-760 では、Fantom シリーズ /XV シリーズ /MX-200 専用のパッチを選ぶことはできません。

Rhythm Set List

For All Instruments

(BANK SELECT MSB: 92; LSB: 19)

No.	RhythmName	No.	RhythmName	No.	RhythmName
1	LatinDrmKit	5	World Phrase	9	Latin Menu3
2	AsiaDrm Kit	6	Gtr Phrase	10	Asia Menu
3	IndiaDrmKit	7	Latin Menu1	11	India Menu
4	MidEastDrKit	8	Latin Menu2	12	MidEast Menu

Rhythm Set Key Assign (1)

For Fantom series/XV series/MX-200

Note No.	1. LatinDrmKit	2. AsiaDrm Kit	3. IndiaDrmKit	4. MidEastDrKit	5. World Phrase	6. Gtr Phrase
28	SectChd m9	Tsuzumi 2 Hi	--	--	--	--
29	SectChd Mj9	Tsuzumi 2 mf	--	--	--	--
30	TimbalesFil4	Tsuzumi 2 p	--	--	--	--
31	TimbalesFil3	Tsuzumi Hi	--	--	--	--
32	TimbalesFil2	Tsuzumi Lo	--	--	--	--
33	TimbalesFil1	Hyoshigi 2	--	--	--	--
34	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	--	--
35	Fat BD	Maple Kick	Fat BD	Maple Kick	--	--
C2 36	Room Kick 2	Warm Kick	Room Kick 2	Warm Kick	180:LatinPt2	120:Bnjo G
37	Cross Stick2	Cross Stick2	Cross Stick2	Cross Stick2	192:LatinPt1	120:Bnjo A
38	Maple Lo Snr	NaturlHardSN	Maple Lo Snr	NaturlHardSN	96:Cng6/8 1	120:Bnjo B
39	Hand Clap 2	Claps Real	Claps Real	Claps Real	96:Cng6/8 2	120:Bnjo Cm
40	MapleSoft SN	NaturlRimSht	MapleSoft SN	NaturlRimSht	144:CgBolero	120:Bnjo Cm+
41	Studio Tom 4	Studio Tom 4	Studio Tom 4	Studio Tom 4	88:CgCumbia	120:Bnjo G-C
42	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	168:CgChacha	120:BnjoG-C+
43	Studio Tom 3	Studio Tom 3	Studio Tom 3	Studio Tom 3	160:CgMambo	95:EGtr1 G
44	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	104:CgMriach	95:EGtr1 C
45	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	138:CgMarinr	95:EGtr1 D
46	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	126:CgWonwn	95:EGtr2 G
47	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	100:TmblPtn3	95:EGtr2 D
C3 48	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	120:TmblPtn4	140:EGtr3 G
49	Crash Cymbal	Crash Cymbal	Crash Cymbal	Crash Cymbal	132:TmblPtn1	140:EGtr3 C
50	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	132:TmblPtn2	140:EGtr3 D
51	Rock RdCym1	Rock RdCym1	Rock RdCym1	Rock RdCym1	80:PndrPtn1	140:EGtr3 G+
52	Crash 1	Crash 1	Crash 1	Crash 1	108:PndrPtn2	140:EGtr3 C+
53	Bongo 1 Hi	Ban Gu 1	Dhol 2	Rek Dom	138:PndrPtn3	140:EGtr3 D+
54	Tambrin Hit	Asian Gong 3	R8 Tamb	R8 Tamb	132:AgogoPtn	120:PdSt1 C
55	Bongo 1 Lo	Ban Gu 2	Dholak 1	Rek Open	132:BotlePtn	120:PdSt1 D
56	Cowbell Op 1	Mokugyo 1	VDrum Cowbell	VDrum Cowbell	104:BomboPtn	120:PdSt1 G
57	BongoHiSlap1	Ban Gu 3	Dholak 8	Rek Tek	126:SurdoPt1	140:PdSt2 D
58	Cowbell 3	Mokugyo 2	VDrum Cowbell	VDrum Cowbell	108:SurdoPt2	140:PdSt2 G
59	Bongo LoSlap	Ban Gu 4	Dholak 9	Rek Trill	138:CaixaPtn	140:PdSt2 D+
C4 60	Conga Hi Mt	Wadaiko	TablaBaya 1	Afro Feet 1	Samba 1	140:PdSt2 G+
61	Conga Lo Mt	Wadaiko Rim	TablaBayaSld	Slit Drum	Samba 2	Gtr Strum 1
62	Conga Slap	Shimedaiko 2	TablaBaya 3	Afro Feet 2	132:TambrmPt	Gtr Strum 2
63	Conga Hi Op	Sime Taiko	TablaBaya 6	Afro Clap	108:RepnqPt1	Nyln GtrNz 1
64	CongaLoOp f	Taiko	TablaBaya 5	Bendir 1	144:RepnqPt2	Nyln GtrNz 2
65	Timbles HiMt	Tang Gu Mt	TablaBaya Na	Bendir 2	96:Salsa	Bouzki Chd 1
66	Timbles LoOp	Tang Gu Op	TablaBayaTin	Dawul	96:Cumbia	Bouzki Chd 2
67	Agogo 2 Hi	Buk	TablaBayaTun	Sagat Close	116:Mariachi	Bouzki Chd 3
68	Agogo 2 Lo	Buk Rim	TablaBaya 8	Sagat Open	Cuica 2	EG C Bend 1
69	Real Cabasa2	Changgo	VDrumCabasaUp	VDrumCabasaUp	Shaker 1	EG C Bend 2
70	Maracas 2	Ohkawa	VDrum Maracas	VDrum Maracas	Shaker 2	EG D Bend 1
71	ApitoHiShort	Ohkawa 2	VDrumCabasDwn	VDrumCabasDwn	104:Shakin'	EG D Bend 2
C5 72	ApitoLoShort	Kwaengwari f	Madal Da	AfroDrum Flm	Shaker 3	EG D Bend 3
73	Guiro Short2	HuYinLuoH Op	Madal Din	AfroDrum Op1	Didgeridoo 1	EG E Bend 1
74	Guiro Long2	HuYinLuoL Op	Madal Ta	AfroDrum Op2	Didgeridoo 3	EG E Bend 2
75	Claves Lo 2	Shou Luo 1	VDrum Claves	AfroDrum Rat	78:Korea Ph	EG E Bend 3
76	Berimbau Up	Shou Luo 2	VDrum Woodblk	VDrum Woodblk	Korean Ens	EG Slide 1
77	Berimbau Dn	BaliCym Opn	VDrum Woodblk	VDrum Woodblk	Er Hu Phrase	EG Slide 2
78	Cuica Hi 1	BaliCym Cls	FingerSnaps4	TalkingDr Dn	GuZhengArpUp	EG Slide 3
79	Cuica Lo 2	Chenchen Cls	Udu Pot1 Acc	TalkingDr Up	GuZhengArpDn	EG Slide 4
80	Caixa Mute	Chenchen Opn	Udu Pot1 Hi	Doholla Dom	118:ChinaPh1	EG Slide 5
81	Caixa Open2	Kopyak Op	Udu Pot1 Lo	Doholla Roll	132:ChinaPh2	EG Slide 6
82	Caixa Rim	Finger Cym	Udu Pot1 Slp	Doholla Sak	78:GamelnP2	EG Slide 7
83	Caixa Roll2	Ramacymbal	Udu Pot2 Lng	Doholla Stop	122:GamelnP1	EG Rake 1
C6 84	Cajon Rol Hi	Gameran 1	Udu Pot2 Mut	Doholla Tak	Chenchen Ptn	EG Rake 2
85	Cajon Rol Lo	Gameran 2	Udu Pot2 Sht	Doira Dun	Udu Pot MENU	EG Mute
86	Surdo Mute2	Gameran 3	Udu Pot MENU	Doira Tik	92:DholakPh	Fdl 5th 1
87	Surdo Open2	Gameran 4	118:TablaByP	Sarna Bell	118:TablaByP	Fdl 5th 2
88	PandeiroL Hi	Gameran 5	TablaBY 3	Sitar Gliss	Tablah 1	Fdl Riff 1
89	PandeiroL Lo	Gameran 6	Tablah 1	ZaghrutaStop	Tablah 2	Fdl Riff 2
90	PandeiroOpen	Gameran 7	Tablah 2	Yoh Tribe	Tablah 3	--
91	PandeiroMute	Gameran 8	Tablah 3	How Tribe	Tablah 4	--
92	PandeiroL Rm	Gameran 9	Tablah 4	92:DholakPh	Tablah Bend	--
93	PandeiroL Sp	Gameran 10	TablaBY 1	120:Dhol Ph	TablaBY 1	--
94	Quijada	Gameran 11	TablaBY 2	African Ens	TablaBY 2	--
95	Rainstick	Gameran 12	Tablah Bend	Morocco Ens	TablaBY 3	--
C7 96	Metronome 2	Metronome 2	Metronome 2	Metronome 2	120:Dhol Ph	--
97	R8 Click	R8 Click	R8 Click	R8 Click	African Ens	--
98	Metronome 1	Metronome 1	Metronome 1	Metronome 1	Morocco Ens	--
99	180:LatinPt2	78:Korea Ph	--	--	--	--
100	160:CgMambo	132:ChinaPh2	--	--	--	--
101	132:TmblPtn1	78:GamelnP2	--	--	--	--
102	132:AgogoPtn	122:GamelnP1	--	--	--	--
103	104:Shakin'	Chenchen Ptn	--	--	--	--

* On the Fantom series/XV series/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

※ Fantomシリーズ/XVシリーズ/MX-200では、RDシリーズ(SRX対応)/MC-909/VR-760専用のリズム・セットを選ぶことはできません。

Rhythm Set Key Assign (2)

For Fantom series/XV series/MX-200

Note No.	7. Latin Menu1	8. Latin Menu2	9. Latin Menu3	10. Asia Menu	11. India Menu	12. MidEast Menu
28	--	--	--	--	--	--
29	--	--	--	--	--	--
30	--	--	--	--	--	--
31	--	--	--	--	--	--
32	--	--	--	--	--	--
33	--	--	--	--	--	--
34	--	--	--	--	--	--
35	--	--	--	--	--	--
C2 36	Agogo 2 Hi	Cuica 3	Surdo Hard	Hyoshigi	Bebarongan 1	Boomerang
37	Agogo 2 Lo	Cuica Hi 1	Surdo Mute	Hyoshigi 2	Bebarongan 2	Clapstick
38	Agogo 3 Hi	Cuica Hi 2	Surdo Mute2	Kane	Bebarongan 3	Afro Zither
39	Agogo 3 Lo	Cuica Lo 1	Surdo Open H	Kane Side	Pelegongan 1	Afro Clap
40	ApitoHiShort	Cuica Lo 2	Surdo Open L	Atarigane	Pelegongan 2	Afro Feet 1
41	ApitoLoShort	Ganza Hard	Surdo Open1	Kwaengwari f	Pelegongan 3	Afro Feet 2
42	Berimbau Dn	Ganza Soft	Surdo Open2	Kwaengwari p	Wadon 1	AfroDrum Flm
43	Berimbau Mut	Guiro Long	Surdo Rim	KwaengwariMt	Wadon 2	AfroDrum Op1
44	Berimbau Opn	Guiro Long2	Surdo Rim 2	Mokugyo 1	Wadon 3	AfroDrum Op2
45	Berimbau Up	Guiro Short	Surdo Soft	Mokugyo 2	Wadon 4	AfroDrum Rat
46	Bongo 1 Hi	Guiro Short2	Tamborim Mut	Ohkawa	Wadon 5	Slit Drum
47	Bongo 1 Lo	Hand Clap 2	Tamborim Opn	Ohkawa 2	Wadon 6	TalkingDr Dn
C3 48	Bongo 2 Hi	MamboBell Mt	Tamborim Slp	Shimedaiko 2	Wadon 7	TalkingDr Up
49	Bongo 2 Lo	MamboBell Op	TamborimMute	Sime Taiko	Dhol 1	Yoh Tribe
50	Bongo Hi Hrd	Maracas 2	TamborimOpen	Taiko	Dhol 2	How Tribe
51	Bongo HiOp f	MaracasUpDwn	TamborimRim	Tsuzumi 2 Hi	Dhol 3	Bendir 1
52	Bongo Lo Hrd	MtlGuiroLng	TamborimRoll	Tsuzumi 2 mf	Dhol 4	Bendir 2
53	Bongo Lo Sft	MtlGuiroSht	Tambrin Hit	Tsuzumi 2 p	Dhol 5	Dawul
54	Bongo LoOp f	PandeiroCrsh	TambrinShake	Tsuzumi Hi	Dholak 1	Doholla Dom
55	Bongo LoOpmf	PandeiroHit	Timbale Hi	Tsuzumi Lo	Dholak 2	Doholla Roll
56	Bongo LoSlap	PandeiroL Hi	Timbale Lo	Wadaiko	Dholak 3	Doholla Sak
57	BongoBell Mt	PandeiroL Lo	Timbale Side	Wadaiko Rim	Dholak 4	Doholla Stop
58	BongoBell Op	PandeiroL Rm	Timbales Rim	Ho	Dholak 5	Doholla Tak
59	BongoHiSlap1	PandeiroL Sp	TimbalesFil1	Yoh	Dholak 6	Doira Dun
C4 60	BongoHiSlap2	PandeiroMute	TimbalesFil2	iYooh	Dholak 7	Doira Tik
61	Cabasa Roll	PandeiroOpen	TimbalesFil3	Yyoo Dude	Dholak 8	Rek Dom
62	Caixa Mute	PandeiroRim	TimbalesFil4	Buk	Dholak 9	Rek Open
63	Caixa Mute2	PandeiroRoll	TimbalesHand	Buk Rim	Dholak Ga	Rek Tek
64	Caixa Open1	PandeiroS Op	Timbles HiMt	Changgo	Dholak Na	Rek Trill
65	Caixa Open2	PandeiroS Rm	Timbles HiOp	Asian Gong 1	Dholak Ta	Sagat Close
66	Caixa Open3	PandeiroS Sp	Timbles LoMt	Asian Gong 2	Dholak Tun	Sagat Open
67	Caixa Rim	Quide Long	Timbles LoOp	Gamelan Gong	Madal Da	Sarna Bell
68	Caixa Roll	Quide Short	TmbSideStick	Asian Gong 3	Madal Din	Sitar Gliss
69	Caixa Roll2	Quijada	SectChd 13th	Asian Gong 4	Madal Ta	Tablah Dom
70	Cajon Hi	Rainstick	SectChd m9	Asian Gong 6	TablaBaya 1	Tablah Rim
71	Cajon Lo	Real Cabasa1	SectChd Mf9	Asian Gong 7	TablaBaya 2	Tablah Roll
C5 72	Cajon Rol Hi	Real Cabasa2	Sabor!	Ban Gu 1	TablaBaya 3	Tablah Tak
73	Cajon Rol Lo	RecoRecoLng	Arriba!	Ban Gu 2	TablaBaya 4	ZaghrutaLoop
74	Caxixi	RecoRecoSht	Ole!	Ban Gu 3	TablaBaya 5	ZaghrutaStop
75	Chekere 1	Repinique1	Uno!	Ban Gu 4	TablaBaya 6	Bull Scream
76	Chekere 2	Repinique2	Dos!	Gu Hi	TablaBaya 7	--
77	Chekere 3	RepiniqueHrd	Tres!	Gu Roll	TablaBaya 8	--
78	Clave!	RepiniqueSft	Quatro!	HuYinLuoH Mt	TablaBaya Ge	--
79	Claves Lo 2	Repique Open	Grito-Hahaha	HuYinLuoH Op	TablaBaya Ka	--
80	Conga Hi Mt	Repique Rim	Grito-Ahaha!	HuYinLuoL Mt	TablaBaya Na	--
81	Conga Hi Op	Repique Roll	Grito-Haahai	HuYinLuoL Op	TablaBaya Te	--
82	Conga Link	SambaBateria	Grito-Rrrrr!	Nao Bo	TablaBaya Ti	--
83	Conga Lo Mt	SambaWhistle	Tiquitito!	Xiao Bo	TablaBayaGin	--
C6 84	Conga Roll	Shaker 1	Grito-Oa Oa!	Asian Gong 5	TablaBayaSlid	--
85	Conga Slap	Shaker 2	Grito-Eh Eh!	Shou Luo 1	TablaBayaTin	--
86	Conga Thumb	Shaker Long	Ama ya ahi!	Shou Luo 2	TablaBayaTun	--
87	CongaLoOp f	Shaker Short	Fuego!	Shu Ban 1	Udu Pot1 Acc	--
88	CongaLoOp mf	--	Hey Brazil	Shu Ban 2	Udu Pot1 Hi	--
89	Cowbell 1	--	--	Shu Gu	Udu Pot1 Lo	--
90	Cowbell 2	--	--	Shu Gu Rim	Udu Pot1 Slp	--
91	Cowbell 3	--	--	Tang Gu Mt	Udu Pot2 Lng	--
92	Cowbell Mt 1	--	--	Tang Gu Op	Udu Pot2 Mut	--
93	Cowbell Mt 2	--	--	BaliCym Cls	Udu Pot2 Sht	--
94	Cowbell Op 1	--	--	BaliCym Opn	--	--
95	Cowbell Op 2	--	--	Ceng Ceng	--	--
C7 96	--	--	--	Chenchen Cls	--	--
97	--	--	--	Chenchen Opn	--	--
98	--	--	--	Kopyak Mt	--	--
99	--	--	--	Kopyak Op	--	--
100	--	--	--	Finger Cym	--	--
101	--	--	--	Ramacymbal	--	--
102	--	--	--	Jaw Harp Opn	--	--
103	--	--	--	Jaw Harp Wow	--	--

* On the Fantom series/XV series/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

※ Fantomシリーズ/XVシリーズ/MX-200では、RDシリーズ(SRX対応)/MC-909/VR-760専用のリズム・セットを選ぶことはできません。

Rhythm Set Key Assign (3)

For RD series (with SRX slots)/MC-909/VR-760/G-70

Note No.	1. LatinDrmKit	2. AsiaDrm Kit	3. IndiaDrmKit	4. MidEastDrKit	5. World Phrase	6. Gtr Phrase
28	SectChd m9	Tsuzumi 2 Hi	--	--	--	--
29	SectChd Mj9	Tsuzumi 2 mf	--	--	--	--
30	TimbalesFil4	Tsuzumi 2 p	--	--	--	--
31	TimbalesFil3	Tsuzumi Hi	--	--	--	--
32	TimbalesFil2	Tsuzumi Lo	--	--	--	--
33	TimbalesFil1	Hyoshigi 2	--	--	--	--
34	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	--	--
35	Fat BD	Maple Kick	Fat BD	Maple Kick	--	--
C2 36	Room Kick 2	Warm Kick	Room Kick 2	Warm Kick	180:LatinPt2	120:Bnjo G
37	Cross Stick2	Cross Stick2	Cross Stick2	Cross Stick2	192:LatinPt1	120:Bnjo A
38	Maple Lo Snr	NaturlHardSN	Maple Lo Snr	NaturlHardSN	96:Cng6/8 1	120:Bnjo B
39	Hand Clap 2	Claps Real	Claps Real	Claps Real	96:Cng6/8 2	120:Bnjo Cm
40	MapleSoft SN	NaturlRimSht	MapleSoft SN	NaturlRimSht	144:CgBolero	120:Bnjo Cm+
41	Studio Tom 4	Studio Tom 4	Studio Tom 4	Studio Tom 4	88:CgCumbia	120:Bnjo G-C
42	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	168:CgChacha	120:BnjoG-C+
43	Studio Tom 3	Studio Tom 3	Studio Tom 3	Studio Tom 3	160:CgMambo	95:EGtr1 G
44	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	104:CgMriach	95:EGtr1 C
45	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	138:CgMarinr	95:EGtr1 D
46	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	126:CgWonwn	95:EGtr2 G
47	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	100:TmblPtn3	95:EGtr2 D
C3 48	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	120:TmblPtn4	140:EGtr3 G
49	--	--	--	--	132:TmblPtn1	140:EGtr3 C
50	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	132:TmblPtn2	140:EGtr3 D
51	--	--	--	--	80:PndrPtn1	140:EGtr3 G+
52	--	--	--	--	108:PndrPtn2	140:EGtr3 C+
53	Bongo 1 Hi	Ban Gu 1	Dhol 2	Rek Dom	138:PndrPtn3	140:EGtr3 D+
54	Tambrin Hit	Asian Gong 3	R8 Tamb	R8 Tamb	132:AgogoPtn	120:PdSt1 C
55	Bongo 1 Lo	Ban Gu 2	Dholak 1	Rek Open	132:BotlePtn	120:PdSt1 D
56	Cowbell Op 1	Mokugyo 1	VDrm Cowbell	VDrm Cowbell	104:BomboPtn	120:PdSt1 G
57	BongoHiSlap1	Ban Gu 3	Dholak 8	Rek Tek	126:SurdoPt1	140:PdSt2 D
58	Cowbell 3	Mokugyo 2	VDrm Cowbell	VDrm Cowbell	108:SurdoPt2	140:PdSt2 G
59	Bongo LoSlap	Ban Gu 4	Dholak 9	Rek Trill	138:CaixaPtn	140:PdSt2 D+
C4 60	Conga Hi Mt	Wadaiko	TablaBaya 1	Afro Feet 1	Samba 1	140:PdSt2 G+
61	Conga Lo Mt	Wadaiko Rim	TablaBayaSld	Slit Drum	Samba 2	Gtr Strum 1
62	Conga Slap	Shimedaiko 2	TablaBaya 3	Afro Feet 2	132:TambrmPt	Gtr Strum 2
63	Conga Hi Op	Sime Taiko	TablaBaya 6	Afro Clap	108:RepnqPt1	Nyln GtrNz 1
64	CongaLoOp f	Taiko	TablaBaya 5	Bendir 1	144:RepnqPt2	Nyln GtrNz 2
65	Timbles HiMt	Tang Gu Mt	TablaBaya Na	Bendir 2	96:Salsa	Bouzki Chd 1
66	Timbles LoOp	Tang Gu Op	TablaBayaTin	Dawul	96:Cumbia	Bouzki Chd 2
67	Agogo 2 Hi	Buk	TablaBayaTun	Sagat Close	116:Mariachi	Bouzki Chd 3
68	Agogo 2 Lo	Buk Rim	TablaBaya 8	Sagat Open	Cuica 2	EG C Bend 1
69	Real Cabasa2	Changgo	VDrmCabasaUp	VDrmCabasaUp	Shaker 1	EG C Bend 2
70	Maracas 2	Ohkawa	VDrm Maracas	VDrm Maracas	Shaker 2	EG D Bend 1
71	ApitoHiShort	Ohkawa 2	VDrmCabasDwn	VDrmCabasDwn	104:Shakin'	EG D Bend 2
C5 72	ApitoLoShort	Kwaengwari f	Madal Da	AfroDrum Flm	Shaker 3	EG D Bend 3
73	Guiro Short2	HuYinLuoH Op	Madal Din	AfroDrum Op1	Didgeridoo 1	EG E Bend 1
74	Guiro Long2	HuYinLuoL Op	Madal Ta	AfroDrum Op2	Didgeridoo 3	EG E Bend 2
75	Claves Lo 2	Shou Luo 1	VDrm Claves	AfroDrum Rat	78:Korea Ph	EG E Bend 3
76	Berimbau Up	Shou Luo 2	VDrm Woodblk	VDrm Woodblk	Korean Ens	EG Slide 1
77	Berimbau Dn	BaliCym Opn	VDrm Woodblk	VDrm Woodblk	Er Hu Phrase	EG Slide 2
78	Cuica Hi 1	BaliCym Cls	FingerSnaps4	TalkingDr Dn	GuZhengArpUp	EG Slide 3
79	Cuica Lo 2	Chenchen Cls	Udu Pot1 Acc	TalkingDr Up	GuZhengArpDn	EG Slide 4
80	Caixa Mute	Chenchen Opn	Udu Pot1 Hi	Doholla Dom	118:ChinaPh1	EG Slide 5
81	Caixa Open2	Kopyak Op	Udu Pot1 Lo	Doholla Roll	132:ChinaPh2	EG Slide 6
82	Caixa Rim	Finger Cym	Udu Pot1 Slp	Doholla Sak	78:GamelnP2	EG Slide 7
83	Caixa Roll2	Ramacymbal	Udu Pot2 Lng	Doholla Stop	122:GamelnP1	EG Rake 1
C6 84	Cajon Rol Hi	Gameran 1	Udu Pot2 Mut	Doholla Tak	Chenchen Ptn	EG Rake 2
85	Cajon Rol Lo	Gameran 2	Udu Pot2 Sht	Doira Dun	Udu Pot MENU	EG Mute
86	Surdo Mute2	Gameran 3	Udu Pot MENU	Doira Tik	92:DholakPh	Fdl 5th 1
87	Surdo Open2	Gameran 4	118:TablaByP	Sarna Bell	118:TablaByP	Fdl 5th 2
88	PandeiroL Hi	Gameran 5	TablaBY 3	Sitar Gliss	Tablah 1	Fdl Riff 1
89	PandeiroL Lo	Gameran 6	Tablah 1	ZaghrutaStop	Tablah 2	Fdl Riff 2
90	PandeiroOpen	Gameran 7	Tablah 2	Yoh Tribe	Tablah 3	--
91	PandeiroMute	Gameran 8	Tablah 3	How Tribe	Tablah 4	--
92	PandeiroL Rm	Gameran 9	Tablah 4	92:DholakPh	Tablah Bend	--
93	PandeiroL Sp	Gameran 10	TablaBY 1	120:Dhol Ph	TablaBY 1	--
94	Quijada	Gameran 11	TablaBY 2	African Ens	TablaBY 2	--
95	Rainstick	Gameran 12	Tablah Bend	Morocco Ens	TablaBY 3	--
C7 96	--	--	--	--	120:Dhol Ph	--
97	--	--	--	--	African Ens	--
98	--	--	--	--	Morocco Ens	--
99	180:LatinPt2	78:Korea Ph	--	--	--	--
100	160:CgMambo	132:ChinaPh2	--	--	--	--
101	132:TmblPtn1	78:GamelnP2	--	--	--	--
102	132:AgogoPtn	122:GamelnP1	--	--	--	--
103	104:Shakin'	Chenchen Ptn	--	--	--	--

* On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the rhythm sets which are designed to be used with the Fantom series/XV series/MX-200.

* On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).

※ SRX 対応のRD シリーズ /MC-909/VR-760 では、Fantom シリーズ /XV シリーズ /MX-200 専用のリズム・セットを選ぶことはできません。

※ MC-909 では、Note No. 35 (B1) から 50 (D3) までの 16 鍵分のリズム・トーンのみ使用できます。

Rhythm Set Key Assign (4)

For RD series (with SRX slots)/MC-909/VR-760/G-70

Note No.	7. Latin Menu1	8. Latin Menu2	9. Latin Menu3	10. Asia Menu	11. India Menu	12. MidEast Menu
28	--	--	--	--	--	--
29	--	--	--	--	--	--
30	--	--	--	--	--	--
31	--	--	--	--	--	--
32	--	--	--	--	--	--
33	--	--	--	--	--	--
34	--	--	--	--	--	--
35	--	--	--	--	--	--
C2 36	Agogo 2 Hi	Cuica 3	Surdo Hard	Hyoshigi	Bebarongan 1	Boomerang
37	Agogo 2 Lo	Cuica Hi 1	Surdo Mute	Hyoshigi 2	Bebarongan 2	Clapstick
38	Agogo 3 Hi	Cuica Hi 2	Surdo Mute2	Kane	Bebarongan 3	Afro Zither
39	Agogo 3 Lo	Cuica Lo 1	Surdo Open H	Kane Side	Pelegongan 1	Afro Clap
40	ApitoHiShort	Cuica Lo 2	Surdo Open L	Atarigane	Pelegongan 2	Afro Feet 1
41	ApitoLoShort	Ganza Hard	Surdo Open1	Kwaengwari f	Pelegongan 3	Afro Feet 2
42	Berimbau Dn	Ganza Soft	Surdo Open2	Kwaengwari p	Wadon 1	AfroDrum Flm
43	Berimbau Mut	Guiro Long	Surdo Rim	KwaengwariMt	Wadon 2	AfroDrum Op1
44	Berimbau Opn	Guiro Long2	Surdo Rim 2	Mokugyo 1	Wadon 3	AfroDrum Op2
45	Berimbau Up	Guiro Short	Surdo Soft	Mokugyo 2	Wadon 4	AfroDrum Rat
46	Bongo 1 Hi	Guiro Short2	Tamborim Mut	Ohkawa	Wadon 5	Slit Drum
47	Bongo 1 Lo	Hand Clap 2	Tamborim Opn	Ohkawa 2	Wadon 6	TalkingDr Dn
C3 48	Bongo 2 Hi	MamboBell Mt	Tamborim Slp	Shimedaiko 2	Wadon 7	TalkingDr Up
49	Bongo 2 Lo	MamboBell Op	TamborimMute	Sime Taiko	Dhol 1	Yoh Tribe
50	Bongo Hi Hrd	Maracas 2	TamborimOpen	Taiko	Dhol 2	How Tribe
51	Bongo HiOp f	MaracasUpDwn	TamborimRim	Tsuzumi 2 Hi	Dhol 3	Bendir 1
52	Bongo Lo Hrd	MtlGuiroLng	TamborimRoll	Tsuzumi 2 mf	Dhol 4	Bendir 2
53	Bongo Lo Sft	MtlGuiroSht	Tambrin Hit	Tsuzumi 2 p	Dhol 5	Dawul
54	Bongo LoOp f	PandeiroCrsh	TambrinShake	Tsuzumi Hi	Dholak 1	Doholla Dom
55	Bongo LoOpmf	PandeiroHit	Timbale Hi	Tsuzumi Lo	Dholak 2	Doholla Roll
56	Bongo LoSlap	PandeiroL Hi	Timbale Lo	Wadaiko	Dholak 3	Doholla Sak
57	BongoBell Mt	PandeiroL Lo	Timbale Side	Wadaiko Rim	Dholak 4	Doholla Stop
58	BongoBell Op	PandeiroL Rm	Timbales Rim	Ho	Dholak 5	Doholla Tak
59	BongoHiSlap1	PandeiroL Sp	TimbalesFil1	Yoh	Dholak 6	Doira Dun
C4 60	BongoHiSlap2	PandeiroMute	TimbalesFil2	iYooh	Dholak 7	Doira Tik
61	Cabasa Roll	PandeiroOpen	TimbalesFil3	Yyoo Dude	Dholak 8	Rek Dom
62	Caixa Mute	PandeiroRim	TimbalesFil4	Buk	Dholak 9	Rek Open
63	Caixa Mute2	PandeiroRoll	TimbalesHand	Buk Rim	Dholak Ga	Rek Tek
64	Caixa Open1	PandeiroS Op	Timbles HiMt	Changgo	Dholak Na	Rek Trill
65	Caixa Open2	PandeiroS Rm	Timbles HiOp	Asian Gong 1	Dholak Ta	Sagat Close
66	Caixa Open3	PandeiroS Sp	Timbles LoMt	Asian Gong 2	Dholak Tun	Sagat Open
67	Caixa Rim	Quide Long	Timbles LoOp	Gamelan Gong	Madal Da	Sarna Bell
68	Caixa Roll	Quide Short	TmbSideStick	Asian Gong 3	Madal Din	Sitar Gliss
69	Caixa Roll2	Quijada	SectChd 13th	Asian Gong 4	Madal Ta	Tablah Dom
70	Cajon Hi	Rainstick	SectChd m9	Asian Gong 6	TablaBaya 1	Tablah Rim
71	Cajon Lo	Real Cabasa1	SectChd Mf9	Asian Gong 7	TablaBaya 2	Tablah Roll
C5 72	Cajon Rol Hi	Real Cabasa2	Sabor!	Ban Gu 1	TablaBaya 3	Tablah Tak
73	Cajon Rol Lo	RecoRecoLng	Arriba!	Ban Gu 2	TablaBaya 4	ZaghrutaLoop
74	Caxixi	RecoRecoSht	Ole!	Ban Gu 3	TablaBaya 5	ZaghrutaStop
75	Chekere 1	Repinique1	Uno!	Ban Gu 4	TablaBaya 6	Bull Scream
76	Chekere 2	Repinique2	Dos!	Gu Hi	TablaBaya 7	--
77	Chekere 3	RepiniqueHrd	Tres!	Gu Roll	TablaBaya 8	--
78	Clave!	RepiniqueSft	Quatro!	HuYinLuoH Mt	TablaBaya Ge	--
79	Claves Lo 2	Repique Open	Grito-Hahaha	HuYinLuoH Op	TablaBaya Ka	--
80	Conga Hi Mt	Repique Rim	Grito-Ahaha!	HuYinLuoL Mt	TablaBaya Na	--
81	Conga Hi Op	Repique Roll	Grito-Haahai	HuYinLuoL Op	TablaBaya Te	--
82	Conga Link	SambaBateria	Grito-Rrrrr!	Nao Bo	TablaBaya Ti	--
83	Conga Lo Mt	SambaWhistle	Tiquiti!	Xiao Bo	TablaBayaGin	--
C6 84	Conga Roll	Shaker 1	Grito-Oa Oa!	Asian Gong 5	TablaBayaSlid	--
85	Conga Slap	Shaker 2	Grito-Eh Eh!	Shou Luo 1	TablaBayaTin	--
86	Conga Thumb	Shaker Long	Ama ya ahi!	Shou Luo 2	TablaBayaTun	--
87	CongaLoOp f	Shaker Short	Fuego!	Shu Ban 1	Udu Pot1 Acc	--
88	CongaLoOp mf	--	Hey Brazil	Shu Ban 2	Udu Pot1 Hi	--
89	Cowbell 1	--	--	Shu Gu	Udu Pot1 Lo	--
90	Cowbell 2	--	--	Shu Gu Rim	Udu Pot1 Slp	--
91	Cowbell 3	--	--	Tang Gu Mt	Udu Pot2 Lng	--
92	Cowbell Mt 1	--	--	Tang Gu Op	Udu Pot2 Mut	--
93	Cowbell Mt 2	--	--	BaliCym Cls	Udu Pot2 Sht	--
94	Cowbell Op 1	--	--	BaliCym Opn	--	--
95	Cowbell Op 2	--	--	Ceng Ceng	--	--
C7 96	--	--	--	Chenchen Cls	--	--
97	--	--	--	Chenchen Opn	--	--
98	--	--	--	Kopyak Mt	--	--
99	--	--	--	Kopyak Op	--	--
100	--	--	--	Finger Cym	--	--
101	--	--	--	Ramacymbal	--	--
102	--	--	--	Jaw Harp Opn	--	--
103	--	--	--	Jaw Harp Wow	--	--

* On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the rhythm sets which are designed to be used with the Fantom series/XV series/MX-200.

* On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).

※ SRX 対応のRD シリーズ /MC-909/VR-760 では、Fantom シリーズ /XV シリーズ /MX-200 専用のリズム・セットを選ぶことはできません。

※ MC-909 では、Note No. 35 (B1) から 50 (D3) までの 16 鍵分のリズム・トーンのみ使用できます。

Waveform List (1)

No.	Name	No.	Name	No.	Name	No.	Name
1	World Tour	61	140:EGtr3 G+ # **	121	Ac.Guitar B	181	Yang Qin 2 B
2	Korean Ens	62	140:EGtr3 G # **	122	Ac.Guitar C	182	Yang Qin 2 C
3	Morocco Ens	63	140:EGtr3 C+ # **	123	Reso.Gtr 2 A #	183	YangQinTrm A
4	African Ens	64	140:EGtr3 C # **	124	Reso.Gtr 2 B #	184	YangQinTrm B
5	Asia Phrase	65	140:EGtr3 D+ # **	125	Reso.Gtr 2 C #	185	YangQinTrm C
6	122:GamelnP1 **	66	140:EGtr3 D # **	126	Reso.Gtr 3pA	186	Chung Ruan A
7	78:GamelnP2 **	67	PdlSteelMenu # *	127	Reso.Gtr 3pB	187	Chung Ruan B
8	78:Korea Ph **	68	120:PdSt1 C # **	128	Reso.Gtr 3pC	188	Chung Ruan C
9	118:ChinaPh1 **	69	120:PdSt1 D # **	129	Reso.Gtr 3fA	189	Gu Zheng A
10	132:ChinaPh2 **	70	120:PdSt1 G # **	130	Reso.Gtr 3fB	190	Gu Zheng B
11	118:TablaByP **	71	140:PdSt2 D # **	131	Reso.Gtr 3fC	191	Gu Zheng C
12	92:DholakPh **	72	140:PdSt2 D+ # **	132	MandolinDn A #	192	Kanoun
13	120:Dhol Ph **	73	140:PdSt2 G # **	133	MandolinDn B #	193	Koto
14	96:Salsa **	74	140:PdSt2 G+ # **	134	MandolinDn C #	194	Kayakeum
15	116:Mariachi **	75	E.Gtr Sus A #	135	MandolinUp A #	195	Sanshin A
16	96:Cumbia **	76	E.Gtr Sus B #	136	MandolinUp B #	196	Sanshin B
17	192:LatinPt1 **	77	E.Gtr Sus C #	137	MandolinUp C #	197	Sanshin C
18	180:LatinPt2 **	78	Strat Rear A	138	MandlnTrem A #	198	Pi Pa A
19	96:Cng6/8 1 **	79	Strat Rear B	139	MandlnTrem B #	199	Pi Pa B
20	96:Cng6/8 2 **	80	Strat Rear C	140	MandlnTrem C #	200	Pi Pa C
21	144:CgBolero **	81	LP Clean A	141	Banjo 2 A	201	Biwa MENU *
22	168:CgChacha **	82	LP Clean B	142	Banjo 2 B	202	Biwa 1
23	88:CgCumbia **	83	LP Clean C	143	Banjo 2 C	203	Biwa 2
24	160:CgMambo **	84	Tele Front A	144	Banjo 3 A	204	Biwa 3
25	104:CgMriach **	85	Tele Front B	145	Banjo 3 B	205	Shamisen 2
26	138:CgMarinr **	86	Tele Front C	146	Banjo 3 C	206	Shami Attack
27	126:CgWonwn **	87	Tele Rear A	147	Bouzouki 2fA	207	BerimbauMENU *
28	132:TmbIPtn1 **	88	Tele Rear B	148	Bouzouki 2fB	208	Berimbau Opn
29	132:TmbIPtn2 **	89	Tele Rear C	149	Bouzouki 2fC	209	Berimbau Up
30	100:TmbIPtn3 **	90	335Pick A	150	Bandolim	210	Berimbau Dn
31	120:TmbIPtn4 **	91	335Pick B	151	Cavaquinho	211	Berimbau Mut
32	104:Shakin' **	92	335Pick C	152	Oud A	212	Oct Harp
33	80:PndrPtn1 **	93	E.Gtr Mute A #	153	Oud B	213	Afro Harp
34	108:PndrPtn2 **	94	E.Gtr Mute B #	154	Oud C	214	JawHarp MENU *
35	138:PndrPtn3 **	95	E.Gtr Mute C #	155	Sitar/Drone	215	Jaw Harp Opn
36	132:AgogoPtn **	96	335Mute A	156	Sitar A	216	Jaw Harp Wow
37	132:BotlePtn **	97	335Mute B	157	Sitar B	217	Gtr Strum 1
38	104:BomboPtn **	98	335Mute C	158	Sitar C	218	Gtr Strum 2
39	126:SurdoPt1 **	99	PdlSteel 1 A #	159	Sitar 2 A	219	Nyln GtrNz 1
40	108:SurdoPt2 **	100	PdlSteel 1 B #	160	Sitar 2 B	220	Nyln GtrNz 2
41	138:CaixaPtn **	101	PdlSteel 1 C #	161	Sitar 2 C	221	Guitarron Nz
42	132:TambrmPt **	102	PdlSteel 2 A	162	SitarDrone	222	EG Bend Menu # *
43	108:RepnqPt1 **	103	PdlSteel 2 B	163	Tambura A	223	EG C Bend 1 #
44	144:RepnqPt2 **	104	PdlSteel 2 C	164	Tambura B	224	EG C Bend 2 #
45	Samba MENU *	105	PdlSteel 3 A	165	Tambura C	225	EG D Bend 1 #
46	BnjoPhs Menu # *	106	PdlSteel 3 B	166	TamburaDrone	226	EG D Bend 2 #
47	120:Bnjo G # **	107	PdlSteel 3 C	167	Zither A	227	EG D Bend 3 #
48	120:Bnjo A # **	108	RequintoGtrA	168	Zither B	228	EG E Bend 1 #
49	120:Bnjo B # **	109	RequintoGtrB	169	Zither C	229	EG E Bend 2 #
50	120:Bnjo Cm # **	110	RequintoGtrC	170	Santur 2 A	230	EG E Bend 3 #
51	120:Bnjo Cm+ # **	111	Nylon Gtr 3A	171	Santur 2 B	231	EG SlideMenu # *
52	120:Bnjo G-C # **	112	Nylon Gtr 3B	172	Santur 2 C	232	EG Slide 1 #
53	120:BnjoG-C+ # **	113	Nylon Gtr 3C	173	Santur Trm A	233	EG Slide 2 #
54	EG Phs Menu1 # *	114	AcGtr Pick A #	174	Santur Trm B	234	EG Slide 3 #
55	95:EGtr1 G # **	115	AcGtr Pick B #	175	Santur Trm C	235	EG Slide 4 #
56	95:EGtr1 C # **	116	AcGtr Pick C #	176	HmrDulcimer	236	EG Slide 5 #
57	95:EGtr1 D # **	117	AcGtr Fngr A #	177	Afro Zither	237	EG Slide 6 #
58	95:EGtr2 G # **	118	AcGtr Fngr B #	178	Yuehchin	238	EG Slide 7 #
59	95:EGtr2 D # **	119	AcGtr Fngr C #	179	Yangchin	239	EG Fx Menu # *
60	EG Phs Menu2 # *	120	Ac.Guitar A	180	Yang Qin 2 A	240	EG Rake 1 #

Waveform List (2)

No. Name	No. Name	No. Name	No. Name
241 EG Rake 2	301 SoloTp Vib1C	361 IndFlute H C	421 Musette 4 C
242 EG Mute	302 SoloTp Vib2A	362 Bang Di A	422 D.AccordionA
243 BzkiChd Menu *	303 SoloTp Vib2B	363 Bang Di B	423 D.AccordionB
244 Bouzki Chd 1	304 SoloTp Vib2C	364 Bang Di C	424 D.AccordionC
245 Bouzki Chd 2	305 Tp RomanticA	365 BangDi Vib A	425 Harmonica2 A
246 Bouzki Chd 3	306 Tp RomanticB	366 BangDi Vib B	426 Harmonica2 B
247 Sitar Gliss	307 Tp RomanticC	367 BangDi Vib C	427 Harmonica2 C
248 GuZhengArpUp	308 Tp Vib MariA	368 Qu Di A	428 Harmonica3 A
249 GuZhengArpDn	309 Tp Vib MariB	369 Qu Di B	429 Harmonica3 B
250 Baby Bass ff	310 Tp Vib MariC	370 Qu Di C	430 Harmonica3 C
251 6Str Bass A	311 Tp Shake A	371 Qu Di Vib A	431 Harmonica4 A
252 6Str Bass B	312 Tp Shake B	372 Qu Di Vib B	432 Harmonica4 B
253 6Str Bass C	313 Tp Shake C	373 Qu Di Vib C	433 Harmonica4 C
254 FingerdBs 2A	314 Tp Grrwah A	374 Zampona 1	434 Voice MENU 1 *
255 FingerdBs 2B	315 Tp Grrwah B	375 Zampo Attack	435 Yoh Tribe
256 FingerdBs 2C	316 Tp Grrwah C	376 Zampo Trem A	436 How Tribe
257 Pick Bass 2	317 MuteTp 2 A	377 Zampo Trem B	437 Hey Brazil
258 6StBs Mute A	318 MuteTp 2 B	378 Zampo Trem C	438 Yyoo Dude
259 6StBs Mute B	319 MuteTp 2 C	379 Sicu Pipe	439 ZaghrutaLoop
260 6StBs Mute C	320 Tbns ff A	380 Quena	440 ZaghrutaStop
261 Tub Bass	321 Tbns ff B	381 Ocarina	441 Bull Scream
262 Guitarron	322 Tbns ff C	382 Kawala A	442 Voice MENU 2 *
263 GuitarronOct	323 Fat Tbns A	383 Kawala B	443 Sabor!
264 Baby Bass Nz	324 Fat Tbns B	384 Kawala C	444 Arriba!
265 Violin 2 A	325 Fat Tbns C	385 Shakuhachi 2	445 Ole!
266 Violin 2 B	326 Tbn Accent A	386 Shaku Attack	446 Uno!
267 Violin 2 C	327 Tbn Accent B	387 Shaku Ornam	447 Dos!
268 Fiddle 1 A	328 Tbn Accent C	388 Hunt Pipe	448 Tres!
269 Fiddle 1 B	329 Trombone3mfA	389 Hunt Noise	449 Quatro!
270 Fiddle 1 C	330 Trombone3mfB	390 Bagpipes 1	450 Grito-Hahaha
271 Fiddle 2 A	331 Trombone3mfC	391 Bagpipes 2	451 Grito-Ahaha!
272 Fiddle 2 B	332 Trombone3 fA	392 Bagpipes 3	452 Grito-Haahai
273 Fiddle 2 C	333 Trombone3 fB	393 Bagpipes 4	453 Grito-Rrrrr!
274 Fdl Pizz 1 A	334 Trombone3 fC	394 Hichiriki	454 Voice MENU 3 *
275 Fdl Pizz 1 B	335 Tbn Alto A	395 Hichiriki Lp	455 Tiquitito!
276 Fdl Pizz 1 C	336 Tbn Alto B	396 Sheng A	456 Grito-Oa Oa!
277 Fdl Stac 1 A	337 Tbn Alto C	397 Sheng B	457 Grito-Eh Eh!
278 Fdl Stac 1 B	338 Tuba f A	398 Sheng C	458 Ama ya ahi!
279 Fdl Stac 1 C	339 Tuba f B	399 Suona A	459 Fuego!
280 Erhu	340 Tuba f C	400 Suona B	460 SambaBateria
281 Er Hu 2 A	341 2Tp+Tbn A	401 Suona C	461 AsiaGng MENU *
282 Er Hu 2 B	342 2Tp+Tbn B	402 Shahnai	462 Asian Gong 1
283 Er Hu 2 C	343 2Tp+Tbn C	403 Mizmar	463 Asian Gong 2
284 Esraj 1	344 2Tp+TbAltTnA	404 Mizmar Lp	464 Asian Gong 3
285 Esraj 2	345 2Tp+TbAltTnB	405 Piri	465 Asian Gong 4
286 Kemanche	346 2Tp+TbAltTnC	406 Piri Lp	466 Asian Gong 5
287 FiddleFxmenu *	347 Sect Fall A	407 Conch Shell1	467 Asian Gong 6
288 Fdl 5th 1	348 Sect Fall B	408 Conch Shell2	468 Asian Gong 7
289 Fdl 5th 2	349 Sect Fall C	409 Didge MENU *	469 REV Gong 5
290 Fdl Riff 6	350 Sect Stact A	410 Didgeridoo 1	470 REV Gong 7
291 Fdl Riff 8	351 Sect Stact B	411 Didgeridoo 2	471 Gong MENU *
292 Er Hu Phrase	352 Sect Stact C	412 Didgeridoo 3	472 Gamelan Gong
293 Trumpets f A	353 SectChd 13th	413 Accrd ff OpA	473 Kempur
294 Trumpets f B	354 SectChd m9	414 Accrd ff OpB	474 Kajar
295 Trumpets f C	355 SectChd Mj9	415 Accrd ff OpC	475 Kelontuk
296 Tp Ambient A	356 IndFlute L A	416 Accrd Cls A	476 Kelontuk Mt
297 Tp Ambient B	357 IndFlute L B	417 Accrd Cls B	477 Kelontuk Sid
298 Tp Ambient C	358 IndFlute L C	418 Accrd Cls C	478 Kemong
299 SoloTp Vib1A	359 IndFlute H A	419 Musette 4 A	479 Ceng Ceng
300 SoloTp Vib1B	360 IndFlute H B	420 Musette 4 B	480 Kopyak Op

Waveform List (3)

No. Name	No. Name	No. Name	No. Name
481 Kopyak Mt	541 Sarna Bell	601 Dhol 1	661 iYooh
482 Kane	542 Wind Bell	602 Dhol 2	662 Taiko
483 Kane Side	543 Blossom Bell	603 Dhol 3	663 Wadaiko
484 Korea MENU *	544 Agogo MENU *	604 Dhol 4	664 Wadaiko Rim
485 Ching Open	545 Agogo 2 Lo	605 Dhol 5	665 Sime Taiko
486 Ching Mute	546 Agogo 2 Hi	606 Udu Pot MENU *	666 Shimedaiko 2
487 Kwaengwari p	547 Agogo 3 Lo	607 Udu Pot1 Lo	667 Buk
488 Kwaengwari f	548 Agogo 3 Hi	608 Udu Pot1 Hi	668 Buk Rim
489 KwaengwariMt	549 AggoCwblMenu *	609 Udu Pot1 Slp	669 Tsuzumi Lo
490 Bonang	550 BongoBell Op	610 Udu Pot1 Acc	670 Tsuzumi Hi
491 Spokes	551 BongoBell Mt	611 Udu Pot2 Lng	671 Tsuzumi 2 p
492 Satellite Dr	552 MamboBell Op	612 Udu Pot2 Sht	672 Tsuzumi 2 mf
493 Atarigane	553 MamboBell Mt	613 Udu Pot2 Mut	673 Tsuzumi 2 Hi
494 China MENU *	554 Cowbell 1	614 Kendang MENU *	674 Mokugyo 1
495 Xiao Bo	555 Cowbell 2	615 Wadon 1	675 Mokugyo 2
496 Nao Bo	556 Cowbell 3	616 Wadon 2	676 Ohkawa
497 Shou Luo 1	557 VDrum Cowbell	617 Wadon 3	677 Ohkawa 2
498 Shou Luo 2	558 Cowbell Op 1	618 Wadon 4	678 Hyoshigi
499 HuYinLuoL Op	559 Cowbell Mt 1	619 Wadon 5	679 Hyoshigi 2
500 HuYinLuoL Mt	560 Cowbell Op 2	620 Wadon 6	680 Clapstick
501 HuYinLuoH Op	561 Cowbell Mt 2	621 Wadon 7	681 VDrum Woodblk
502 HuYinLuoH Mt	562 TablaByMENU1 *	622 Bebarongan 1	682 Boomerang
503 Ban Gu 1	563 TablaBaya 1	623 Bebarongan 2	683 Changgo
504 Ban Gu 2	564 TablaBaya 2	624 Bebarongan 3	684 Tang Gu Op
505 Ban Gu 3	565 TablaBaya 3	625 Pelegongan 1	685 Tang Gu Mt
506 Gender	566 TablaBaya 4	626 Pelegongan 2	686 Shu Gu
507 Saron	567 TablaBaya 5	627 Pelegongan 3	687 Shu Gu Rim
508 Jegogan A	568 TablaBaya 6	628 TalkingDr Up	688 Shu Ban 1
509 Jegogan B	569 TablaBaya 7	629 TalkingDr Dn	689 Shu Ban 2
510 Jegogan C	570 TablaBaya 8	630 AfroDrum MENU *	690 Ban Gu 4
511 Jublag A	571 TablaByMENU2 *	631 AfroDrum Op1	691 ChinaPrcMENU *
512 Jublag B	572 TablaBayaSld	632 AfroDrum Op2	692 Gu Roll
513 Jublag C	573 TablaBayaGin	633 AfroDrum Flm	693 Gu Hi
514 Pemade A	574 TablaBaya Ge	634 AfroDrum Rat	694 Rot Drum
515 Pemade B	575 TablaBaya Ka	635 Tablah MENU *	695 Log Drum 2
516 Pemade C	576 TablaBaya Na	636 Tablah Bend	696 Slit Drum
517 Reyong A	577 TablaBayaTin	637 Tablah Dom	697 Bongo MENU 1 *
518 Reyong B	578 TablaBayaTun	638 Tablah Tak	698 Bongo 1 Lo
519 Reyong C	579 TablaBaya Te	639 Tablah Rim	699 Bongo 1 Hi
520 Reyong Sid A	580 TablaBaya Ti	640 Tablah Roll	700 Bongo 2 Lo
521 Reyong Sid B	581 Dholak MENU1 *	641 Doira Dun	701 Bongo 2 Hi
522 Reyong Sid C	582 Dholak 1	642 Doira Tik	702 Bongo MENU 2 *
523 Steel Dr 2	583 Dholak 2	643 Doholla MENU *	703 Bongo LoOp f
524 Kalimba 1	584 Dholak 3	644 Doholla Dom	704 Bongo Lo Hrd
525 Kalimba 2	585 Dholak 4	645 Doholla Sak	705 Bongo Lo Sft
526 Kalimba 3	586 Dholak 5	646 Doholla Tak	706 Bongo LoOpmf
527 Kalimba Glis	587 Dholak 6	647 Doholla Roll	707 Bongo LoSlap
528 Kalim Gls Lp	588 Dholak 7	648 Doholla Stop	708 Bongo Hi Hrd
529 Balaphone 1	589 Dholak 8	649 Rek MENU *	709 Bongo HiOp f
530 Balaphone 2	590 Dholak 9	650 Rek Dom	710 BongoHiSlap1
531 AsiaCym MENU *	591 Dholak MENU2 *	651 Rek Tek	711 BongoHiSlap2
532 Chenchen Ptn	592 Dholak Ga	652 Rek Open	712 Conga Menu *
533 Chenchen Opn	593 Dholak Ta	653 Rek Trill	713 CongaLoOp f
534 Chenchen Cls	594 Dholak Tun	654 Bendir 1	714 CongaLoOp mf
535 BaliCym Opn	595 Dholak Na	655 Bendir 2	715 Conga Lo Mt
536 BaliCym Cls	596 Madal MENU *	656 Dawul	716 Conga Slap
537 Finger Cym	597 Madal Da	657 JapanPrcMENU *	717 Conga Hi Op
538 Ramacymbal	598 Madal Din	658 Japan MENU *	718 Conga Hi Mt
539 Sagat Open	599 Madal Ta	659 Ho	719 Conga Thumb
540 Sagat Close	600 Dhol MENU *	660 Yoh	720 Conga Link

Waveform List (4)

No. Name	No. Name	No. Name	No. Name
721 Conga Roll	771 VDrum Claves	821 PandeiroOpen	871 Dixie HH Cls
722 Timbale MENU *	772 Cuica 2	822 PandeiroMute	872 Dixie HH Hlf
723 Timbale Lo	773 Cuica 3	823 PandeiroHit	873 Dixie HH Opn
724 Timbale Hi	774 Cuica Lo 1	824 PandeiroRim	
725 Timbale Side	775 Cuica Lo 2	825 PandeiroCrsh	
726 TimbalesMenu *	776 Cuica Hi 1	826 PandeiroRoll	
727 Timbles LoOp	777 Cuica Hi 2	827 TamborimMENU *	
728 Timbles LoMt	778 MrcsShkrMenu *	828 Tamborim Opn	
729 Timbles HiOp	779 Maracas 2	829 Tamborim Mut	
730 Timbles HiMt	780 MaracasUpDwn	830 Tamborim Slp	
731 TimbalesHand	781 VDrum Maracas	831 TamborimOpen	
732 Timbales Rim	782 Shaker MENU *	832 TamborimRim	
733 TmbSideStick	783 Shaker Ptn	833 TamborimMute	
734 TimbalesFil1	784 Shaker 1	834 TamborimRoll	
735 TimbalesFil2	785 Shaker 2	835 Tambrin Hit	
736 TimbalesFil3	786 Shaker Long	836 TambrinShake	
737 TimbalesFil4	787 Shaker Short	837 R8 Tamb	
738 Surdo MENU 1 *	788 Angklung 2	838 Others Menu *	
739 Surdo Open L	789 Rainstick	839 ApitoHiShort	
740 Surdo Open H	790 Guiro Long	840 ApitoLoShort	
741 Surdo Mute	791 Guiro Short	841 SambaWhistle	
742 Surdo Rim	792 Guiro Menu *	842 Quijada	
743 Surdo MENU 2 *	793 Quide Long	843 Chekere 3	
744 Surdo Hard	794 Quide Short	844 CajonClpMenu *	
745 Surdo Open1	795 Guiro Long2	845 Cajon Lo	
746 Surdo Open2	796 Guiro Short2	846 Cajon Hi	
747 Surdo Mute2	797 RecoRecoLng	847 Cajon Rol Hi	
748 Surdo Rim 2	798 RecoRecoSht	848 Cajon Rol Lo	
749 Surdo Soft	799 MtlGuiroLng	849 Afro Feet 1	
750 Caixa MENU 1 *	800 MtlGuiroSht	850 Afro Feet 2	
751 Caixa Open1	801 CbsCxGnzMenu *	851 Afro Clap	
752 Caixa Open2	802 Real Cabasa1	852 Hand Clap 2	
753 Caixa Roll	803 Real Cabasa2	853 Claps Real	
754 Caixa Mute	804 Cabasa Roll	854 FingerSnaps4	
755 Caixa MENU 2 *	805 VDrumCabasaUp	855 BomboBbnMenu *	
756 Caixa Open3	806 VDrumCabasDwn	856 SoftSet Menu *	
757 Caixa Mute2	807 Caxixi	857 HardSet Menu *	
758 Caixa Roll2	808 Ganza Soft	858 Fat BD	
759 Caixa Rim	809 Ganza Hard	859 Room Kick 2	
760 Rpnq&RpqMenu *	810 Chekere 1	860 Maple Kick	
761 RepiniqueHrd	811 Chekere 2	861 Warm Kick	
762 RepiniqueSft	812 PandeiroMENU *	862 Maple Lo Snr	
763 Repinique1	813 PandeiroL Lo	863 MapleSoft SN	
764 Repinique2	814 PandeiroL Hi	864 NaturlHardSN	
765 Repique Open	815 PandeiroL Sp	865 NaturlRimSht	
766 Repique Rim	816 PandeiroL Rm	866 Cross Stick2	
767 Repique Roll	817 PandeiroS Op	867 StudioLo Tom	
768 Clv&CucaMenu *	818 PandeiroS Sp	868 StudioMidTom	
769 Clave!	819 PandeiroS Rm	869 StudioHi Tom	
770 Claves Lo 2	820 PandTambMenu *	870 Dixie HH Pdl	

*: These are menu waveforms. Include multiple waveforms assigned to keys individually.

**: These are the phrase loop waveforms. The numbers included in the wave name represent the recommended tempo (B.P.M.). And these waveforms can be synchronized to a device such as a sequencer.

#: This waveform was selected from the CD-ROM "Whole Lotta Country" from Sampleheads.

When you create a Patch using the waveforms stored in the Expansion Board, observe the following points:

- * If you make a Patch with a single voice and then later play it in a chord, the sound may be distorted with certain settings for the Effects and TVA. If this happens, adjust the level of the Effects and TVA.
- * This product uses waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.

*: メニュー・ウェーブフォームです。複数のウェーブフォームが、各キーに割り当てられています。

**: フレーズ・ループのウェーブフォームです。ウェーブ・ネームに付いている数字は推奨テンポ (B.P.M.) です。また、これらのウェーブフォームはシーケンサー等との同期が可能です。

#: このウェーブフォームは Sampleheads 社 CD-ROM 「WHOLE Lotta Country」からセレクトされています。

このエクステンション・ボードに収められているウェーブフォームを使ってパッチを作るときには、次の点に注意してください。

- ※ 単音でパッチを作ったとき、エフェクトや TVA の設定状態によって、その音を和音で演奏すると音が歪む場合があります。このようなときは、エフェクトや TVA のレベルを調整してください。
- ※ 本製品のウェーブフォームは SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。

Waveform List (1) (By Region 地域別)

India (インド)

No.	Name
156	Sitar A
157	Sitar B
158	Sitar C
159	Sitar 2 A
160	Sitar 2 B
161	Sitar 2 C
247	Sitar Gliss
162	SitarDrone
155	Sitar/Drone
170	Santur 2 A
171	Santur 2 B
172	Santur 2 C
173	Santur Trm A
174	Santur Trm B
175	Santur Trm C
163	Tambura A
164	Tambura B
165	Tambura C
166	TamburaDrone
284	Esraj 1
285	Esraj 2
402	Shahnai
356	IndFlute L A
357	IndFlute L B
358	IndFlute L C
359	IndFlute H A
360	IndFlute H B
361	IndFlute H C
541	Sarna Bell
11	118:TablaByP
571	TablaBYMENU2
572	TablaBayaSld
573	TablaBayaGin
574	TablaBaya Ge
575	TablaBaya Ka
576	TablaBaya Na
577	TablaBayaTin
578	TablaBayaTun
579	TablaBaya Te
580	TablaBaya Ti
562	TablaByMENU1
563	TablaBaya 1
564	TablaBaya 2
565	TablaBaya 3
566	TablaBaya 4
567	TablaBaya 5
568	TablaBaya 6
569	TablaBaya 7
570	TablaBaya 8
606	Udu Pot MENU
607	Udu Pot1 Lo
608	Udu Pot1 Hi
609	Udu Pot1 Slp
610	Udu Pot1 Acc
611	Udu Pot2 Lng
612	Udu Pot2 Sht
613	Udu Pot2 Mut
12	92:DholakPh
591	Dholak MENU1
592	Dholak Ga
593	Dholak Ta
594	Dholak Tun

595	Dholak Na
581	Dholak MENU2
582	Dholak 1
583	Dholak 2
584	Dholak 3
585	Dholak 4
586	Dholak 5
587	Dholak 6
588	Dholak 7
589	Dholak 8
590	Dholak 9
13	120:Dhol Ph
600	Dhol MENU
601	Dhol 1
602	Dhol 2
603	Dhol 3
604	Dhol 4
605	Dhol 5
596	Madal MENU
597	Madal Da
598	Madal Din
599	Madal Ta

Middle East (中近東)

No.	Name
152	Oud A
153	Oud B
154	Oud C
286	Kemanche
382	Kawala A
383	Kawala B
384	Kawala C
403	Mizmar
404	Mizmar Lp
404	Mizmar Lp
539	Sagat Open
540	Sagat Close
635	Tablah MENU
636	Tablah Bend
637	Tablah Dom
638	Tablah Tak
639	Tablah Rim
640	Tablah Roll
641	Doira Dun
642	Doira Tik
643	Doholla MENU
644	Doholla Dom
645	Doholla Sak
646	Doholla Tak
647	Doholla Roll
648	Doholla Stop
649	Rek MENU
650	Rek Dom
651	Rek Tek
652	Rek Open
653	Rek Trill
654	Bendir 1
655	Bendir 2
656	Dawul
439	ZaghrutaLoop
440	ZaghrutaStop
3	Morocco Ens

Japan (日本)

No.	Name
193	Koto
205	Shamisen 2
206	Shami Attack
201	Biwa MENU
202	Biwa 1
203	Biwa 2
204	Biwa 3
385	Shakuhachi 2
386	Shaku Attack
387	Shaku Ornam
394	Hichiriki
395	Hichiriki Lp
493	Atarigane
678	Hyoshigi
657	JapanPrcMENU
662	Taiko
665	Sime Taiko
669	Tsuzumi Lo
670	Tsuzumi Hi
676	Ohkawa
438	Yyoo Dude
195	Sanshin A
196	Sanshin B
197	Sanshin C
482	Kane
483	Kane Side
542	Wind Bell
658	Japan MENU
663	Wadaiko
664	Wadaiko Rim
666	Shimedaiko 2
671	Tsuzumi 2 p
672	Tsuzumi 2 mf
673	Tsuzumi 2 Hi
677	Ohkawa 2
674	Mokugyo 1
675	Mokugyo 2
679	Hyoshigi 2
659	Ho
660	Yoh
661	iYooh

Korea (韓国)

No.	Name
194	Kayakeum
405	Piri
406	Piri Lp
484	Korea MENU
485	Ching Open
486	Ching Mute
487	Kwaengwari p
488	Kwaengwari f
489	KwaengwariMt
667	Buk
668	Buk Rim
683	Changgo
8	78:Korea Ph
2	Korean Ens

China (中国)

No.	Name
178	Yuehchin
179	Yangchin
280	Erhu
461	AsiaGng MENU
462	Asian Gong 1
463	Asian Gong 2
464	Asian Gong 3
465	Asian Gong 4
466	Asian Gong 5
467	Asian Gong 6
468	Asian Gong 7
469	REV Gong 5
470	REV Gong 7
531	AsiaCym MENU
503	Ban Gu 1
504	Ban Gu 2
505	Ban Gu 3
691	ChinaPrcMENU
692	Gu Roll
693	Gu Hi
198	Pi Pa A
199	Pi Pa B
200	Pi Pa C
186	Chung Ruan A
187	Chung Ruan B
188	Chung Ruan C
189	Gu Zheng A
190	Gu Zheng B
191	Gu Zheng C
180	Yang Qin 2 A
181	Yang Qin 2 B
182	Yang Qin 2 C
183	YangQinTrm A
184	YangQinTrm B
185	YangQinTrm C
281	Er Hu 2 A
282	Er Hu 2 B
283	Er Hu 2 C
362	Bang Di A
363	Bang Di B
364	Bang Di C
365	BangDi Vib A
366	BangDi Vib B
367	BangDi Vib C
368	Qu Di A
369	Qu Di B
370	Qu Di C
371	Qu Di Vib A
372	Qu Di Vib B
373	Qu Di Vib C
396	Sheng A
397	Sheng B
398	Sheng C
399	Suona A
400	Suona B
401	Suona C
494	China MENU
495	Xiao Bo
496	Nao Bo
497	Shou Luo 1
498	Shou Luo 2
499	HuYinLuoL Op

Waveform List (2) (By Region 地域別)

500	HuYinLuoL Mt
501	HuYinLuoH Op
502	HuYinLuoH Mt
684	Tang Gu Op
685	Tang Gu Mt
686	Shu Gu
687	Shu Gu Rim
687	Shu Gu Rim
688	Shu Ban 1
689	Shu Ban 2
292	Er Hu Phrase
248	GuZhengArpUp
249	GuZhengArpDn
9	118:ChinaPh1
10	132:ChinaPh2

Europe (ヨーロッパ)

No.	Name
167	Zither A
168	Zither B
169	Zither C
381	Ocarina
390	Bagpipes 1
391	Bagpipes 2
392	Bagpipes 3
393	Bagpipes 4

North America (北米)

No.	Name
176	HmrDulcimer

South America (南米)

No.	Name
150	Bandolim
151	Cavaquinho
212	Oct Harp
374	Zampona 1
375	Zampo Attack
376	Zampo Trem A
377	Zampo Trem B
378	Zampo Trem C
379	Sicu Pipe
380	Quena
523	Steel Dr 2
207	BerimbauMENU
208	Berimbau Opn
209	Berimbau Up
210	Berimbau Dn
211	Berimbau Mut
789	Rainstick
437	Hey Brazil
45	Samba MENU
460	SambaBateria
812	PandeiroMENU
813	PandeiroL Lo
814	PandeiroL Hi

815	PandeiroL Sp
816	PandeiroL Rm
817	PandeiroS Op
818	PandeiroS Sp
819	PandeiroS Rm
827	TamborimMENU
828	Tamborim Opn
829	Tamborim Mut
830	Tamborim Slp
738	Surdo MENU 1
743	Surdo MENU 2
739	Surdo Open L
740	Surdo Open H
741	Surdo Mute
747	Surdo Mute2
742	Surdo Rim
748	Surdo Rim 2
750	Caixa MENU 1
755	Caixa MENU 2
751	Caixa Open1
752	Caixa Open2
753	Caixa Roll
758	Caixa Roll2
754	Caixa Mute
757	Caixa Mute2
544	Agogo MENU
545	Agogo 2 Lo
546	Agogo 2 Hi
547	Agogo 3 Lo
548	Agogo 3 Hi
554	Cowbell 1
555	Cowbell 2
556	Cowbell 3
772	Cuica 2
773	Cuica 3
782	Shaker MENU
783	Shaker Ptn
784	Shaker 1
785	Shaker 2
810	Chekere 1
811	Chekere 2
841	SambaWhistle
790	Guiro Long
795	Guiro Long2
791	Guiro Short
796	Guiro Short2
722	Timbale MENU
723	Timbale Lo
724	Timbale Hi
725	Timbale Side
697	Bongo MENU 1
702	Bongo MENU 2
698	Bongo 1 Lo
699	Bongo 1 Hi
700	Bongo 2 Lo
701	Bongo 2 Hi

Africa (アフリカ)

No.	Name
213	Afro Harp
388	Hunt Pipe
389	Hunt Noise
524	Kalimba 1
525	Kalimba 2
526	Kalimba 3
527	Kalimba Glis
528	Kalim Gls Lp
529	Balaphone 1
530	Balaphone 2
695	Log Drum 2
696	Slit Drum
628	TalkingDr Up
629	TalkingDr Dn
630	AfroDrm MENU
631	AfroDrum Op1
632	AfroDrum Op2
633	AfroDrum Flm
634	AfroDrum Rat
177	Afro Zither
849	Afro Feet 1
850	Afro Feet 2
851	Afro Clap
435	Yoh Tribe
436	How Tribe
4	African Ens

Southeast Asia (東南アジア)

No.	Name
490	Bonang
506	Gender
507	Saron
537	Finger Cym
538	Ramacymbal
532	Chenchen Ptn
533	Chenchen Opn
534	Chenchen Cls
535	BaliCym Opn
536	BaliCym Cls
788	Angklung 2
214	JawHarp MENU
215	Jaw Harp Opn
216	Jaw Harp Wow

Australia (オーストラリア)

No.	Name
680	Clapstick
682	Boomerang
409	Didge MENU
410	Didgeridoo 1
411	Didgeridoo 2
412	Didgeridoo 3

Others (その他)

No.	Name
543	Blossom Bell
491	Spokes
694	Rot Drum
434	Voice MENU 1
442	Voice MENU 2
454	Voice MENU 3
441	Bull Scream
407	Conch Shell1
408	Conch Shell2
1	World Tour

Menu Waveform (1)

45 Samba MENU

Key	Wave#	WaveName	
C	4	Samba Phr1	*
D	4	Samba Phr2	*
E	4	Samba Phr3	*

46 BnjoPhs Menu

Key	Wave#	WaveName
C	4	120:Bnjo G
D	4	120:Bnjo A
E	4	120:Bnjo B
F	4	120:Bnjo Cm
G	4	120:Bnjo Cm+
A	4	120:Bnjo G-C
B	4	120:BnjoG-C+

54 EG Phs Menu 1

Key	Wave#	WaveName
C	4	95:EGtr1 G
D	4	95:EGtr1 C
E	4	95:EGtr1 D
F	4	95:EGtr2 G
G	4	95:EGtr2 D

60 EG Phs Menu 2

Key	Wave#	WaveName
C	4	140:EGtr3 G+
D	4	140:EGtr3 G
E	4	140:EGtr3 C+
F	4	140:EGtr3 C
G	4	140:EGtr3 D+
A	4	140:EGtr3 D

67 PdISteelMenu

Key	Wave#	WaveName
C	4	120:PdSt1 C
D	4	120:PdSt1 D
E	4	120:PdSt1 G
F	4	140:PdSt2 D
G	4	140:PdSt2 D+
A	4	140:PdSt2 G
B	4	140:PdSt2 G+

201 Biwa MENU

Key	Wave#	WaveName
C	4	Biwa 1
D	4	Biwa 2
E	4	Biwa 3

207 BerimbauMENU

Key	Wave#	WaveName
C	4	Berimbau Opn
D	4	Berimbau Up
E	4	Berimbau Dn
F	4	Berimbau Mut

214 JawHarp MENU

Key	Wave#	WaveName
C	4	Jaw Harp Opn
D	4	Jaw Harp Wow
E	4	Reverse ? *

222 EG Bend Menu

Key	Wave#	WaveName
C	4	223 EG C Bend 1
D	4	224 EG C Bend 2
E	4	225 EG D Bend 1
F	4	226 EG D Bend 2
G	4	227 EG D Bend 3
A	4	228 EG E Bend 1
B	4	229 EG E Bend 2
C	5	230 EG E Bend 3

231 EG SlideMenu

Key	Wave#	WaveName
C	4	232 EG Slide 1
D	4	233 EG Slide 2
E	4	234 EG Slide 3
F	4	235 EG Slide 4
G	4	236 EG Slide 5
A	4	237 EG Slide 6
B	4	238 EG Slide 7

239 EG Fx Menu

Key	Wave#	WaveName
C	4	240 EG Rake 1
D	4	241 EG Rake 2
E	4	242 EG Mute

243 BzkiChd Menu

Key	Wave#	WaveName
C	4	244 Bouzki Chd 1
D	4	244 Bouzki Chd 1
E	4	245 Bouzki Chd 2
F	4	245 Bouzki Chd 2
G	4	246 Bouzki Chd 3
A	4	246 Bouzki Chd 3

287 FiddleFxMenu

Key	Wave#	WaveName
C	4	288 Fdl 5th 1
D	4	289 Fdl 5th 2
E	4	290 Fdl Riff 6
F	4	291 Fdl Riff 8

409 Didge MENU

Key	Wave#	WaveName
C	4	410 Didgeridoo 1
D	4	411 Didgeridoo 2
E	4	412 Didgeridoo 3
F	4	Didgeridoo 4 *
G	4	Didgeridoo 5 *
A	4	Didgeridoo 6 *

434 Voice MENU 1

Key	Wave#	WaveName
C	4	435 Yoh Tribe
D	4	436 How Tribe
E	4	437 Hey Brazil
F	4	438 Yyoo Dude
G	4	439 ZaghrutaLoop
A	4	440 ZaghrutaStop
B	4	441 Bull Scream

442 Voice MENU 2

Key	Wave#	WaveName
C	4	443 Sabor!
D	4	444 Arriba!
E	4	445 Ole!
F	4	446 Uno!
G	4	447 Dos!
A	4	448 Tres!
B	4	449 Quatro!
C	5	450 Grito-Hahaha
D	5	451 Grito-Ahaha!
E	5	452 Grito-Haahai
F	5	453 Grito-Rrrrr!

454 Voice MENU 3

Key	Wave#	WaveName
C	4	455 Tiquitito!
D	4	456 Grito-Oa Oa!
E	4	457 Grito-Eh Eh!
F	4	458 Ama ya ahi!
G	4	459 Fuego!

461 AsiaGng MENU

Key	Wave#	WaveName
C	4	462 Asian Gong 1
D	4	463 Asian Gong 2
E	4	464 Asian Gong 3
F	4	465 Asian Gong 4
G	4	466 Asian Gong 5
A	4	467 Asian Gong 6
B	4	468 Asian Gong 7
C	5	REV Gong 4 *
D	5	REV Gong 5 *
E	5	REV Gong 6 *
F	5	REV Gong 7 *

471 Gong MENU

Key	Wave#	WaveName
C	4	472 Gamelan Gong
D	4	473 Kempur
E	4	474 Kajar
F	4	475 Kelontuk
G	4	476 Kelontuk Mt
A	4	477 Kelontuk Sid
B	4	478 Kemong
C	5	479 Ceng Ceng
D	5	480 Kopyak Op
E	5	481 Kopyak Mt
F	5	6 122:GamelnP1
G	5	7 78:GamelnP2

484 Korea MENU

Key	Wave#	WaveName
C	4	667 Buk
D	4	668 Buk Rim
E	4	683 Changgo
F	4	485 Ching Open
G	4	486 Ching Mute
A	4	487 Kwaengwari p
B	4	488 Kwaengwari f
C	5	489 KwaengwariMt

494 China MENU

Key	Wave#	WaveName
C	4	684 Tang Gu Op
D	4	685 Tang Gu Mt
E	4	686 Shu Gu
F	4	687 Shu Gu Rim
G	4	688 Shu Ban 1
A	4	689 Shu Ban 2
B	4	690 Ban Gu 4
C	5	495 Xiao Bo
D	5	496 Nao Bo
E	5	497 Shou Luo 1
F	5	498 Shou Luo 2
G	5	499 HuYinLuoL Op
A	5	500 HuYinLuoL Mt
B	5	501 HuYinLuoH Op
C	6	502 HuYinLuoH Mt
D	6	10 132:ChinaPh2

531 AsiaCym MENU

Key	Wave#	WaveName
C	4	532 Chenchen Ptn
D	4	533 Chenchen Opn
E	4	534 Chenchen Cls
F	4	535 BaliCym Opn
G	4	536 BaliCym Cls

544 Agogo MENU

Key	Wave#	WaveName
C	4	545 Agogo 2 Lo
D	4	546 Agogo 2 Hi
E	4	547 Agogo 3 Lo
F	4	548 Agogo 3 Hi
G	4	554 Cowbell 1
A	4	555 Cowbell 2
B	4	556 Cowbell 3

549 AggoCwblMenu

Key	Wave#	WaveName
C	4	550 BongoBell Op
D	4	551 BongoBell Mt
E	4	552 MamboBell Op
F	4	553 MamboBell Mt
G	4	558 Cowbell Op 1
A	4	559 Cowbell Mt 1
B	4	560 Cowbell Op 2
C	5	561 Cowbell Mt 2

562 TablaByMENU 1

Key	Wave#	WaveName
C	4	563 TablaBaya 1
D	4	564 TablaBaya 2
E	4	565 TablaBaya 3
F	4	566 TablaBaya 4
G	4	567 TablaBaya 5
A	4	568 TablaBaya 6
B	4	569 TablaBaya 7
C	5	570 TablaBaya 8
D	5	11 118:TablaByP

Menu Waveform (2)

571 TablaByMENU2

Key	Wave#	WaveName
C	4	TablaBayaP 1 *
D	4	TablaBayaP 2 *
E	4	TablaBayaP 3 *
F	4	TablaBayaP 4 *
G	4	TablaBayaP 5 *
A	4	572 TablaBayaSld
B	4	573 TablaBayaGin
C	5	574 TablaBaya Ge
D	5	575 TablaBaya Ka
E	5	576 TablaBaya Na
F	5	577 TablaBayaTin
G	5	578 TablaBayaTun
A	5	579 TablaBaya Te
B	5	580 TablaBaya Ti

581 Dholak MENU1

Key	Wave#	WaveName
C	4	582 Dholak 1
D	4	583 Dholak 2
E	4	584 Dholak 3
F	4	585 Dholak 4
G	4	586 Dholak 5
A	4	587 Dholak 6
B	4	588 Dholak 7
C	5	589 Dholak 8
D	5	590 Dholak 9
E	5	12 92:DholakPh

591 Dholak MENU2

Key	Wave#	WaveName
C	4	592 Dholak Ga
D	4	593 Dholak Ta
E	4	594 Dholak Tun
F	4	595 Dholak Na
G	4	Dholak Ga 2 *

596 Madal MENU

Key	Wave#	WaveName
C	4	597 Madal Da
D	4	598 Madal Din
E	4	599 Madal Ta

600 Dhol MENU

Key	Wave#	WaveName
C	4	601 Dhol 1
D	4	602 Dhol 2
E	4	603 Dhol 3
F	4	604 Dhol 4
G	4	605 Dhol 5
A	4	13 120:Dhol Ph

606 Udu Pot MENU

Key	Wave#	WaveName
C	4	Udu Pot Phr1 *
D	4	Udu Pot Phr2 *
E	4	Udu Pot Phr3 *
F	4	607 Udu Pot1 Lo
G	4	608 Udu Pot1 Hi
A	4	609 Udu Pot1 Slp
B	4	610 Udu Pot1 Acc
C	5	611 Udu Pot2 Lng
D	5	612 Udu Pot2 Sht
E	5	613 Udu Pot2 Mut

614 Kendang MENU

Key	Wave#	WaveName
C	4	615 Wadon 1
D	4	616 Wadon 2
E	4	617 Wadon 3
F	4	618 Wadon 4
G	4	619 Wadon 5
A	4	620 Wadon 6
B	4	621 Wadon 7
C	5	622 Bebarongan 1
D	5	623 Bebarongan 2
E	5	624 Bebarongan 3
F	5	625 Pelegongan 1
G	5	626 Pelegongan 2
A	5	627 Pelegongan 3

630 AfroDrm MENU

Key	Wave#	WaveName
C	4	631 AfroDrum Op1
D	4	632 AfroDrum Op2
E	4	633 AfroDrum Flm
F	4	634 AfroDrum Rat

635 Tablah MENU

Key	Wave#	WaveName
C	4	Tablah Phr1 *
D	4	Tablah Phr2 *
E	4	Tablah Phr3 *
F	4	Tablah Phr4 *
G	4	636 Tablah Bend
A	4	637 Tablah Dom
B	4	638 Tablah Tak
C	5	639 Tablah Rim
D	5	640 Tablah Roll

643 Doholla MENU

Key	Wave#	WaveName
C	4	644 Doholla Dom
D	4	645 Doholla Sak
E	4	646 Doholla Tak
F	4	647 Doholla Roll
G	4	648 Doholla Stop

649 Rek MENU

Key	Wave#	WaveName
C	4	650 Rek Dom
D	4	651 Rek Tek
E	4	652 Rek Open
F	4	653 Rek Trill

657 JapanPrcMENU

Key	Wave#	WaveName
C	4	662 Taiko
D	4	665 Sime Taiko
E	4	669 Tsuzumi Lo
F	4	670 Tsuzumi Hi
G	4	676 Ohkawa
A	4	678 Hyoshigi
B	4	493 Atarigane
C	5	438 Yyoo Dude

658 Japan MENU

Key	Wave#	WaveName
C	4	663 Wadaiko
D	4	664 Wadaiko Rim
E	4	666 Shimedaiko 2
F	4	671 Tsuzumi 2 p
G	4	672 Tsuzumi 2 mf
A	4	673 Tsuzumi 2 Hi
B	4	677 Ohkawa 2
C	5	674 Mokugyo 1
D	5	675 Mokugyo 2
E	5	679 Hyoshigi 2
F	5	482 Kane
G	5	483 Kane Side
A	5	542 Wind Bell
B	5	659 Ho
C	6	660 Yoh
D	6	661 iYooh

691 ChinaPrcMENU

Key	Wave#	WaveName
C	4	692 Gu Roll
D	4	693 Gu Hi
E	4	694 Rot Drum
F	4	695 Log Drum 2
G	4	696 Slit Drum
A	4	466 Asian Gong 5
B	4	467 Asian Gong 6
C	5	468 Asian Gong 7

697 Bongo MENU 1

Key	Wave#	WaveName
C	4	698 Bongo 1 Lo
D	4	699 Bongo 1 Hi
E	4	700 Bongo 2 Lo
F	4	701 Bongo 2 Hi

702 Bongo MENU 2

Key	Wave#	WaveName
C	4	703 Bongo LoOp f
D	4	704 Bongo Lo Hrd
E	4	705 Bongo Lo Sft
F	4	706 Bongo LoOpmf
G	4	707 Bongo LoSlap
A	4	708 Bongo Hi Hrd
B	4	709 Bongo HiOp f
C	5	710 BongoHiSlap1
D	5	711 BongoHiSlap2

712 Conga Menu

Key	Wave#	WaveName
C	4	713 CongaLoOp f
D	4	714 CongaLoOp mf
E	4	715 Conga Lo Mt
F	4	716 Conga Slap
G	4	717 Conga Hi Op
A	4	718 Conga Hi Mt
B	4	719 Conga Thumb
C	5	720 Conga Link
D	5	721 Conga Roll

722 Timbale MENU

Key	Wave#	WaveName
C	4	723 Timbale Lo
D	4	724 Timbale Hi
E	4	725 Timbale Side

726 TimbalesMenu

Key	Wave#	WaveName
C	4	727 Timbles LoOp
D	4	728 Timbles LoMt
E	4	729 Timbles HiOp
F	4	730 Timbles HiMt
G	4	731 TimbalesHand
A	4	732 Timbales Rim
B	4	733 TmbSideStick
C	5	734 TimbalesFil1
D	5	735 TimbalesFil2
E	5	736 TimbalesFil3
F	5	737 TimbalesFil4

738 Surdo MENU 1

Key	Wave#	WaveName
C	4	739 Surdo Open L
D	4	740 Surdo Open H
E	4	741 Surdo Mute
F	4	742 Surdo Rim

743 Surdo MENU 2

Key	Wave#	WaveName
C	4	744 Surdo Hard
D	4	745 Surdo Open1
E	4	746 Surdo Open2
F	4	747 Surdo Mute2
G	4	748 Surdo Rim 2
A	4	749 Surdo Soft

750 Caixa MENU 1

Key	Wave#	WaveName
C	4	751 Caixa Open1
D	4	752 Caixa Open2
E	4	753 Caixa Roll
F	4	754 Caixa Mute

755 Caixa MENU 2

Key	Wave#	WaveName
C	4	756 Caixa Open3
D	4	757 Caixa Mute2
E	4	758 Caixa Roll2
F	4	759 Caixa Rim

760 Rpnq&RppMenu

Key	Wave#	WaveName
C	4	761 RepiniqueHrd
D	4	762 RepiniqueSft
E	4	763 Repinique1
F	4	764 Repinique2
G	4	765 Repique Open
A	4	766 Repique Rim
B	4	767 Repique Roll

768 Clv&CucaMenu

Key	Wave#	WaveName
C	4	769 Clave!
D	4	770 Claves Lo 2
E	4	774 Cuica Lo 1
F	4	775 Cuica Lo 2
G	4	776 Cuica Hi 1
A	4	777 Cuica Hi 2

778 MrcsShkrMenu

Key	Wave#	WaveName
C	4	779 Maracas 2
D	4	780 MaracasUpDwn
E	4	786 Shaker Long
F	4	787 Shaker Short
G	4	Shaker Lite *

Menu Waveform (3)

782 Shaker MENU

Key	Wave#	WaveName
C 4	783	Shaker Ptn
D 4	784	Shaker 1
E 4	785	Shaker 2

792 Guiro Menu

Key	Wave#	WaveName
C 4	793	Quide Long
D 4	794	Quide Short
E 4	795	Guiro Long2
F 4	796	Guiro Short2
G 4	797	RecoRecoLNg
A 4	798	RecoRecoSht
B 4	799	MtlGuiroLNg
C 5	800	MtlGuiroSht
D 5		MtlGuiroAtc *
E 5		MtlGuiroMut *

801 CbsCxGnzMenu

Key	Wave#	WaveName
C 4	802	Real Cabasa1
D 4	803	Real Cabasa2
E 4	804	Cabasa Roll
F 4	807	Caxixi
G 4	808	Ganza Soft
A 4	809	Ganza Hard

812 PandeiroMENU

Key	Wave#	WaveName
C 4	813	PandeiroL Lo
D 4	814	PandeiroL Hi
E 4	815	PandeiroL Sp
F 4	816	PandeiroL Rm
G 4	817	PandeiroS Op
A 4	818	PandeiroS Sp
B 4	819	PandeiroS Rm

820 PandTambMenu

Key	Wave#	WaveName
C 4	821	PandeiroOpen
D 4	822	PandeiroMute
E 4	823	PandeiroHit
F 4	824	PandeiroRim
G 4	825	PandeiroCrsh
A 4	826	PandeiroRoll
B 4	831	TamborimOpen
C 5	832	TamborimRim
D 5	833	TamborimMute
E 5	834	TamborimRoll
F 5	835	Tambrin Hit
G 5	836	TambrinShake

827 TamborimMENU

Key	Wave#	WaveName
C 4	828	Tamborim Opn
D 4	829	Tamborim Mut
E 4	830	Tamborim Slp

838 Others Menu

Key	Wave#	WaveName
C 4	839	ApitoHiShort
D 4	840	ApitoLoShort
E 4	842	Quijada
F 4	843	Chekere 3

844 CajonClpMenu

Key	Wave#	WaveName
C 4	845	Cajon Lo
D 4	846	Cajon Hi
E 4	847	Cajon Rol Hi
F 4	848	Cajon Rol Lo
G 4	852	Hand Clap 2

855 BomboBbnMenu

Key	Wave#	WaveName
C 4		Bombo Open *
D 4		Bombo Mute *
E 4		Bombo Rol *
F 4		Bubans 1 *
G 4		Bubans Rol *

856 SoftSet Menu

Key	Wave#	WaveName
C 2	745	Surdo Open1
D 2	757	Caixa Mute2
E 2	822	PandeiroMute
F 2	762	RepiniqueSft
C 4	706	Bongo LoOpmf
D 4	714	CongaLoOp mf
E 4	730	Timbles HiMt
F 4	550	BongoBell Op
G 4	802	Real Cabasa1
A 4	786	Shaker Long
B 4	808	Ganza Soft
C 5	775	Cuica Lo 2
D 5	795	Guiro Long2

857 HardSet Menu

Key	Wave#	WaveName
C 2	746	Surdo Open2
D 2	756	Caixa Open3
E 2	821	PandeiroOpen
F 2	761	RepiniqueHrd
C 4	704	Bongo Lo Hrd
D 4	713	CongaLoOp f
E 4	729	Timbles HiOp
F 4	552	MamboBell Op
G 4	803	Real Cabasa2
A 4	787	Shaker Short
B 4	809	Ganza Hard
C 5	774	Cuica Lo 1
D 5	793	Quide Long

* Used only in the menu waveforms.

* このウェーブフォームはメニュー・ウェーブフォームのみで使用しています。

About the New Format

Expansion boards SRX-01-04 could only hold a maximum of 128 Patches. In order to make it possible to provide an even greater variety of sounds, a new format (implemented originally on the SRX-05) is now being employed. This new format is capable of handling more than 128 Patches.

If you are using one of the five models listed below, and are still using an older version of the system, you may need to upgrade its system to enable it to support the new SRX format. Check the system program version of your instrument; if your current version is the same as, or older than the corresponding one listed below, use the system update program on the included CD-ROM to upgrade to the latest version before using the SRX-09.

- Fantom: Update required for versions up to Ver. 1.12
- XV-5080: Update required for versions up to Ver. 1.24
- XV-3080: Update required for versions up to Ver. 1.08
- XV-88: Update required for versions up to Ver. 1.07
- RD-700: Update required for versions up to Ver. 1.04

For instructions on checking the system program version for each instrument, and upgrading the software, refer to the html files for the relevant instrument included on the CD-ROM.

About the Included CD-ROM

The included CD-ROM features:

- System update programs compatible with new-format SRX expansion boards (for Fantom, XV-5080, XV-3080, XV-88, and RD-700)
- Data Reproducing the SR-JV's Original Patches and Rhythm Sets (Compatible models: Fantom, XV-5080, XV-5050, XV-3080, XV-88, XV-2020)
- SRX-01-09 demo songs
- BPM Conversion Table

For more detailed information on each file, refer to index_e.html on the CD-ROM.

- * *Take proper care of the included CD-ROM; it will not be reissued.*
- * *The system programs on the included CD-ROM are the latest versions, as of September, 2002. For information regarding newer versions than those on this disk, you should contact the nearest Roland Service Center.*

新フォーマットに関して

エクспанション・ボード SRX-01 ~ 04 は、最大 128 パッチを収録していました。SRX-05 以降は、より多彩な音色をお客様に供給する為に、128 以上のパッチを扱えるよう、新フォーマットを採用しています。

これにより、以下の 5 機種において、現在お使いのバージョンによっては、新フォーマットに対応するためにバージョン・アップしていただく必要があります。システム・プログラム・バージョンをご確認の上、下記のバージョン、もしくはそれより古いバージョンの場合は、付属 CD-ROM に収録のシステム・アップデート・プログラムを使用して、製品をバージョン・アップしてから SRX-09 をお使いください。

- Fantom : Ver1.12 まではアップデートが必要
- XV-5080 : Ver1.24 まではアップデートが必要
- XV-3080 : Ver1.08 まではアップデートが必要
- XV-88 : Ver1.07 まではアップデートが必要
- RD-700 : Ver1.04 まではアップデートが必要

各機種のシステム・プログラム・バージョンの確認方法、およびバージョン・アップ方法は、付属 CD-ROM に収録の、各機種別ファイルを参照してください。

付属 CD-ROM について

付属 CD-ROM には

- SRX エクспанション・ボード新フォーマット対応システム・アップデート・プログラム (Fantom, XV-5080, XV-3080, XV-88, RD-700)
- SR-JV オリジナル Patch / Rhythm Set 再現データ (対応機種 : Fantom, XV-5080, XV-5050, XV-3080, XV-88, XV-2020)
- SRX-01 ~ 09 デモ・ソング
- BPM 変換テーブル

が収録されています。各ファイルの詳細な内容は、CD-ROM 内の index_j.html 参照してください。

- ※ 付属 CD-ROM は再発行しませんので、大切にお使いください。
- ※ 付属 CD-ROM に収録の各システム・プログラムは、2002 年 9 月時点での最新のものです。収録バージョンより新しいプログラムに関しては、もよりのローランド・サービスにお問い合わせください。

お客様	ご芳名	様
	ご住所	〒 ----- ☎

取扱販売店名・住所・☎	
保証期間	お買い上げ日 年 月 日より 本体は一年間 ただし、ソフトウェア、 付属品、消耗部品は除く

太枠内に記入または捺印の無い場合は、必ず販売店発行の領収書またはそのお買い上げ年月日・販売店等を証明するものを保証書に添付願います。記入もしくは添付の無い場合は無効となりますので、ご注意ください。

型名	SRX-09 "World Collection"
----	----------------------------------

- 本保証書は、本書記載内容で無料修理をさせていただきますことをお約束するものです。
- 保証期間中に故障が発生した場合は、製品と本書をご持参ご提示の上、お買上げの販売店にご依頼ください。
- ご転居・ご贈答品などの場合で、お買上げ販売店に修理を依頼することができない場合は、ローランドサービスステーションにお問い合わせください。
- 本書は再発行いたしません。所定事項の記入および内容をよくお読みの上、大切に保存してください。



ローランド株式会社

本社 〒530-0002 大阪市北区曽根崎新地1-4-20 桜橋 IMビル11F
電話 (06) 6345-9800

保証規定

- 保証期間内において、取扱説明書・本体貼付ラベルなどの注意書に従った正常なご使用状態で発生した故障については、第3項に示す場合を除き、無料修理いたします。
- 保証期間内に無料修理をお受けになる場合は、お買上げの販売店・又は最寄りのローランドサービスステーションにご依頼のうえ、修理の際に本書をご提示ください。お客様のご事情により出張修理を依頼された場合、保証期間中であっても出張料金を申し受けます。
- 保証期間内でも、次の場合には有料修理となります。
 - (イ) 本書のご提示が無い場合。
 - (ロ) 本書にお買い上げ年月日・販売店名の記入が無い場合、または字句を書き換えられた場合。
 - (ハ) ご使用上の誤り、又は当社の指定者以外の手により修理・改造された場合。
 - (ニ) 本製品に異常がなく、他の部分、他の機器に異常があり、点検及び改善した場合。
 - (ホ) お買い上げ後の輸送、移動、落下等による故障や損傷および使用中に生じたキズ・汚れなどの外観上の変化。
 - (ヘ) 地震、落雷、風水害、その他の天災地変、火災、公害、ガス、異常電圧による故障や損傷。
 - (ト) 消耗部品（例：電池など）の取り替えを要する場合、および消耗部品の摩耗や劣化に起因する故障や損傷。
- 本製品は日本国内でご使用いただくことを前提に製造・販売しております。従って本製品の保証は、日本国外ではお受けできませんので、ご了承ください。
This warranty is valid only in Japan.

修理メモ

- ※ 本保証書は以上の保証規定により無料修理をお約束するものです。従ってこの保証書によってお客様の法律上の権利を制限するものではありません。
- ※ 本製品の補修用性能部品（製品の機能を維持するために必要な部品）の最低保有期間は製造打切後6年です。この部品保有期間を修理可能の期間とさせていただきます。保有期間経過後も、故障内容によっては修理可能の場合がありますので、ローランドサービスステーションまでお問い合わせください。
- ※ 修理の際、交換した部品を再生、再利用、製品の品質向上等の目的で回収させていただくことがありますので、ご協力願います。