

HOHNER REED ORDER DATASHEET

Tuning Tables HOHNER CX-12

(shows physikal cross arrangement of reeds as built into reed plates)

For online orders, please click on the fitting notes in the tables

Fits the following models: HOHNER CX-12, CX-12 GOLD, CX-12 Jazz

12-hole Chromatic Harmonica Standard Solo Tuning **C**

upper/outside	D4	Gb F#4	A4	C5	D5	Gb F#5	A5	C6	D6	Gb F#6	A6	D7
upper/inside	C4	F4	G4	Db C#5	C5	F5	G5	Db C#6	C6	F6	G6	Db C#7
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	Db C#4	E4	Ab G#4	C5	Db C#5	E5	Ab G#5	C6	Db C#6	E6	Ab G#6	C7
lower/outside	Eb D#4	F4	Bb A#4	B4	Eb D#5	F5	Bb A#5	B5	Eb D#6	F6	Bb A#6	B6

A4=a=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **B**

upper/outside	Db C#4	F4	Ab G#4	B4	Db C#5	F5	Ab G#5	B5	Db C#6	F6	Ab G#6	Db C#7
upper/inside	B3	E4	Gb F#4	C5	B4	E5	Gb F#5	C6	B5	E6	Gb F#6	C7
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	C4	Eb D#4	G4	B4	C5	Eb D#5	G5	B5	C6	Eb D#6	G6	B6
lower/outside	D4	E4	A4	Bb A#4	D5	E5	A5	Bb A#5	D6	E6	A6	Bb A#6

A4=a=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **Bb**

upper/outside	C4	E4	G4	Bb A#4	C5	E5	G5	Bb A#5	C6	E6	G6	C7
upper/inside	Bb A#3	Eb D#4	F4	B4	Bb A#4	Eb D#5	F5	B5	Bb A#5	Eb D#6	F6	B6
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	B3	D4	Gb F#4	Bb A#4	B4	D5	Gb F#5	Bb A#5	B5	D6	Gb F#6	Bb A#6
lower/outside	Db C#4	Eb D#4	Ab G#4	A4	Db C#5	Eb D#5	Ab G#5	A5	Db C#6	Eb D#6	Ab G#6	A6

A4=a=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **A**

upper/outside	B3	Eb D#4	Gb F#4	A4	B4	Eb D#5	Gb F#5	A5	B5	Eb D#6	Gb F#6	B6
upper/inside	A3	D4	E4	Bb A#4	A4	D5	E5	Bb A#5	A5	D6	E6	Bb A#6
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	Bb A#3	Db C#4	F4	A4	Bb A#4	Db C#5	F5	A5	Bb A#5	Db C#6	F6	A6
lower/outside	C4	D4	G4	Ab G#4	C5	D5	G5	Ab G#5	C6	D6	G6	Ab G#6

A4=a=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **G**

upper/outside	A3	Db C#4	E4	G4	A4	Db C#5	E5	G5	A5	Db C#6	E6	A6
upper/inside	G3	C4	D4	Ab G#4	G4	C5	D5	Ab G#5	G5	C6	D6	Ab G#6
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	Ab G#3	B3	Eb D#4	G4	Ab G#4	B4	Eb D#5	G5	Ab G#5	B5	Eb D#6	G6
lower/outside	Bb A#3	C4	F4	Gb F#4	Bb A#4	C5	F5	Gb F#5	Bb A#5	C6	F6	Gb F#6

A4=a=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **F**

upper/outside	G3	B3	D4	F4	G4	B4	D5	F5	G5	B5	D6	G6
upper/inside	F3	Bb A#3	C4	Gb F#4	F4	Bb A#4	C5	Gb F#5	F5	Bb A#5	C6	Gb F#6
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	Gb F#3	A3	Db C#4	F4	Gb F#4	A4	Db C#5	F5	Gb F#5	A5	Db C#6	F6
lower/outside	Ab G#3	Bb A#3	Eb D#4	E4	Ab G#4	Bb A#4	Eb D#5	E5	Ab G#5	Bb A#5	Eb D#6	E6

A4=a=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **E**

upper/outside	D6	Bb A#3	Db C#4	E4	Gb F#4	Bb A#4	Db C#5	E5	Gb F#5	Bb A#5	Db C#6	Gb F#6
upper/inside	E3	A3	B3	F4	E4	A4	B4	F5	E5	A5	B5	F6
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	F3	Ab G#3	C4	E4	F4	Ab G#4	C5	E5	F5	Ab G#5	C6	E6
lower/outside	G3	A3	D4	Eb D#4	G4	A4	D5	Eb D#5	G5	A5	D6	Eb D#6

A4=a⁴=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **Eb**

upper/outside	F3	A3	C4	Eb D#4	F4	A4	C5	Eb D#5	F5	A5	C6	F6
upper/inside	Eb D#3	Ab G#3	Bb A#3	E4	Eb D#4	Ab G#4	Bb A#4	E5	Eb D#5	Ab G#5	Bb A#5	E6
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	E3	G3	B3	Eb D#4	E4	G4	B4	Eb D#5	E5	G5	B5	Eb D#6
lower/outside	Gb F#3	Ab G#3	Db C#4	D4	Gb F#4	Ab G#4	Db C#5	D5	Gb F#5	Ab G#5	Db C#6	D6

A4=a⁴=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **D**

upper/outside	E3	Ab G#3	B3	D4	E4	Ab G#4	B4	D5	E5	Ab G#5	B5	E6
upper/inside	D3	G3	A3	Eb D#4	D4	G4	A4	Eb D#5	D5	G5	A5	Eb D#6
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	Eb D#3	Gb F#3	Bb A#3	D4	Eb D#4	Gb F#4	Bb A#4	D5	Eb D#5	Gb F#5	Bb A#5	D6
lower/outside	F3	G3	C4	Db C#4	F4	G4	C5	Db C#5	F5	G5	C6	Db C#6

A4=a⁴=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)

12-hole Chromatic Harmonica Standard Solo Tuning **LC (TENOR)**

upper/outside	D3	Gb F#3	A3	C4	D4	Gb F#4	A4	C5	D5	Gb F#5	A5	D6
upper/inside	C3	F3	G3	Db C#4	C4	F4	G4	Db C#5	C5	F5	G5	Db C#6
hole	1	2	3	4	5	6	7	8	9	10	11	12
lower/inside	Db C#3	E3	Ab G#3	C4	Db C#4	E4	Ab G#4	C5	Db C#5	E5	Ab G#5	C6
lower/outside	Eb D#3	F3	Bb A#3	B3	Eb D#4	F4	Bb A#4	B4	Eb D#5	F5	Bb A#5	B5

A4=a⁴=443Hz, Cross Order, Manufactured beyond 2005 (X-mark on the reed plate close the data stamp)