

VIRTUAL DJ LIMITED EDITION

Video Controls

- 1 Video Transition section**
Push Select to choose video transition style
Push Launch to start transition
- 2 Video FX section**
Push Select to choose video effect
Push On/Off to activate / deactivate effect
- 3 Video FX parameter**
Adjust the level of effect parameter

Speed and tune controls

- 4 Pitch Bend +/-**
Momentary speed change of the playing track, to adjust manual beatmatch
- 5 Key adjust**
Sets the tune (key) of the playing deck.
Turn the knob to change the Key
Push reset to deactivate key. When turning Key, the reset status is cancelled

Audio Effects controls

- 6 P1, P2**
Adjusts sound parameters of the selected effect
- 7 Effect Select / Load**
Select the next effect by turning encoder; load the effect by pushing encoder
- 8 Effect On / Off**
Activate / deactivate the effect by pressing this button

Loop

- 9 Loop Size**
Adjust the size on the loop by turning encoder
- 10 Loop Move**
Move in / out loop points by turning encoder
- 11 Auto Loop**
Select the length and activate Autoloop by pushing pad. Each Pad has a different length as shown on the silk

- 12 Manual loop**
Sets in / out points of loop. To push Exit again will exit the loop. Push ReLoop to enter the loop again.
- 13 Smart Loop**
Smart Loop function is a perfect loop assistant. After pushing Smart Loop button, any manual loop will match perfectly with the beat grid.

Sampler

- L/S Loop / Sampler**
Switches between Loop mode and Sampler Mode for both sides decks. When Sampler mode is activate, all LEDs are ON
- S9 Level**
Sets the level of the last called sample
- S10 Size**
Sets the size of the last called sample, adjusted on beat grid
- S11 Sample Pads**
Launches the samples. When sample is playing, Pad light alternates on-off.

Virtual DJ Limited Function Layout

This diagram explains how VCI-400 is mapped with VirtualDJ VCI-400 Limited Edition



Serato DJ Intro Function Layout

This diagram explains how VCI-400 is mapped with Serato DJ Intro

serato dj intro

Audio Effects controls

- 1 Effect select**
Selects here the effect type for slot 1
- 2 Effects controls**
Rotary knobs adjust the parameters for FX slots 1 / 2 / 3
On buttons engages / disengages each effect slot

Beat setting

Sets the Beat parameter for all FX slots

Tap Tempo

Tap Tempo button to enter manual reference tempo for the effects

Auto Loop and Hot Cues

- 5 Auto Loop**
Selects the length and active Autoloop

Hot Cues

To press Hot Cue 1 / 2 / 3 / 4 sets new Cue point. To press Clear deletes it. When Cue Point is set, to push Hot Cue will return the playback to cue point (stutter) without stopping playback.

Transport

- 7 Cue / Play (transport)**
Push Play to start playback of loaded track
To push Cue while player is in Pause mode will create new Cue point.
To Push Cue while deck is playing will stop the playback and return to Cue point

Sampler

- 8 Sampler Pads**
Push Sampler Pads to start the playback of current loaded sample.

If you want to know more details on each function of the software, please refer to PDF Manual in Vestax web site.
URL : help.vestax.co.jp/en/

If you want to know about other functions of the hardware, please refer to pages 15 and 16 of Owner's Manual.



FAQ
<http://help.vestax.co.jp/en/>

Virtual DJ
<http://www.virtualdj.com/>

Serato dj intro
<http://serato.com/>

Vestax Corporation

1-18-6 Wakabayashi, Setagaya-ku, Tokyo
154-0023, JAPAN
WEB : <http://www.vestax.com>
twitter : @VestaxHQ

Multi mode Transport Pads Each Transport Pads can send 3 different midi notes (banks).

- 14 Pad Mode(bank)selector**
Selects the Transport Pads mode
Decks Mode: Deck transport and Hot Cue
Sampler Mode: Samples launch pads
FX+Decks Mode: performs multi-effects and deck transport

- 15 Cue / Play (transport)**
In Decks Mode, these buttons are Cue and Play for the selected deck.
To push Cue while player is in Pause mode will create new Cue point.
To Push Cue while deck is playing will stop the playback and return to Cue point

- 16 Hot Cues**
In Decks Mode, these buttons are Hot Cues for the selected deck.
Press Hot Cue 1, 2 or 3 to set new cue point.
When Cue Point is set, to push Hot Cue will return the playback to cue point (stutter) without stopping playback.

- 17 Clear**
Press Clear + Hot Cue 1, 2 or 3 to delete Hot Cue
- 18 Sampler Pads**
In Sampler Mode, the Pads launch samples. VDJ has a 12 Samples slot
Left side are Samples 1 - 6
Right side are Samples 7 - 12

- 19 Effects Pads**
Push Pads to activate effects. Set the effect parameter by turning P1 and P2 knobs (check function n°5)
Each Pad activates a different effect.

- 20 Cue / Play (transport)**
In Decks Mode, these buttons are Cue and Play for the selected deck.
To push Cue while player is in Pause mode will create new Cue point.
To Push Cue while deck is playing will stop the playback and return to Cue point

If you want to know more details on each function of the software, please refer to "PDF Manual" in Virtual DJ LE installation CD-R.
If you want to know about other functions of the hardware, please refer to pages 15 and 16 of Owner's Manual.

[About installation of Virtual DJ LE]
This installer CD-R includes "Windows installer", "Mac installer" and "PDF Manual".
Please start an installer according to the computer in use.

Windows : Double click "install_virtualdj_le_vci400_v7.0.5.msi" to start the installation.
Macintosh : Double click "install_virtualdj_le_vci400_v7.0.5.pkg" to start the installation.