



UD-BT01

Wireless MIDI Adaptor

Owner's Manual

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe and handy place for future reference.



WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

Do not open

- This product contains no user-serviceable parts. Do not open the product or attempt to disassemble or modify the internal components in any way. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.

Location

- Radio waves may affect electro-medical devices.
 - Do not use this product near medical devices or inside medical facilities.
 - Do not use this product within 22 cm (9 in.) of persons with a heart pacemaker implant or defibrillator implant.
- Before moving the product, remove all connected cables, to prevent damage to the cables or injury to anyone who might trip over them.

Water warning

- Do not expose the product to rain, use it near water or in damp or wet conditions, or place on it any containers (such as vases, bottles or glasses) containing liquids which might spill into any openings. If any liquid such as water seeps into the product, turn off the power of the instrument immediately and unplug the power cord from the AC outlet. Then have the product inspected by qualified Yamaha service personnel.

If you notice any abnormality

- If any of the following problems occur, immediately turn off the power switch of the instrument and disconnect the electric plug from the outlet.
 - It emits unusual smells or smoke.

Yamaha cannot be held responsible for damage caused by improper use or modifications to the instrument, or data that is lost or destroyed.

DMI-5

NOTICE


To avoid the possibility of malfunction/ damage to the product, damage to data, or damage to other property, follow the notices below.

■ Handling

- Do not use this product in the vicinity of a TV, radio, stereo equipment, or other electric devices. Otherwise, this product, TV, or radio may generate noise. When you use this product along with an application on your iPad, iPhone or iPod touch, we recommend that you set "Airplane Mode" to "ON" on that device in order to avoid noise caused by communication.
- Do not expose this product to excessive dust or vibrations, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day) to prevent the possibility of panel disfiguration, damage to the internal components or unstable operation.
- Follow local regulations and ordinances when disposing of this product.
- Regarding the USB cable, use the included USB cable (1.5m).
- When in use, this product may malfunction, significantly decrease in performance, or even stop working due to nearby radio waves of the same frequency or of a cellular phone.

Information

■ About this manual

- The illustrations as shown in this manual are for instructional purposes only, and may appear somewhat different from those on your instrument.
-  **Bluetooth®**
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Yamaha Corporation is under license.
- Mac, OS X, iPhone, iPad and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- The company names and product names in this manual are the trademarks or registered trademarks of their respective companies.

By using this product, you can enable wireless communication of the MIDI data between Yamaha products that are compatible with this product and your smart device, such as an iPhone, iPad and iPod touch. For details about compatible Yamaha products, applications and devices, access the website below, enter "UD-BT01" (for example) to the Model Name box, then click [SEARCH].

* In this manual, iPhone and iPod touch are hereafter collectively called iPhone.

NOTE

The latest firmware can be downloaded from the website below:

YAMAHA Downloads <http://download.yamaha.com/>

Included Accessories: USB cable


Connection procedure

Making a wireless connection between a musical instrument and an iPhone/iPad using the UD-BT01.

Prepare a USB AC adaptor beforehand.

Make sure to carefully read the owner's manual of the USB AC adaptor you are using.

- 1 Make sure that the power to the connected musical instrument is turned off.
Quit any open application software on your iPhone/iPad.
- 2 Connect the musical instrument, the included USB cable, the UD-BT01, and the USB AC adaptor in the order shown in the illustration below.
 - 2-1. Connect the UD-BT01 to the USB terminal of the USB AC adaptor.
 - 2-2. Connect the USB AC adaptor to an AC outlet.
The lamp of the UD-BT01 flashes.
 - 2-3. Connect the UD-BT01 to the USB TO HOST terminal using the included USB cable.



- 3 Turn on the instrument.
- 4 Tap the setting icon of iPhone/iPad, and then turn on "Bluetooth."
- 5 Start the iPhone/iPad compatible application, and then make the appropriate wireless connection settings.
If the wireless connection is successful, the lamp on the UD-BT01 lights continuously.

Specifications

Color	Black
Size	45 mm (W) x 12 mm (H) x 40 mm (D) (includes connector portion)
Weight	10 g
Indicator	LED x 2
Bluetooth standards	Bluetooth (Ver. 4.0; GATT compatible) Bluetooth Low Energy MIDI Specification -compliant
Connector	USB type-A male x 1 / female x 1 Male: <ul style="list-style-type: none"> • Power is supplied by connection to external power • No data communication capabilities Female: <ul style="list-style-type: none"> • Communication through connection with USB to Host terminal of a musical instrument
Power	USB bus-powered
Power Consumption	170 mW
Supported OS	iOS 8 or later OS X Yosemite or later
Hardware requirements	Mac, iPhone/iPod touch/iPad with Bluetooth 4.0 installed

* The contents of this manual apply to the latest specifications as of the printing date. To obtain the latest manual, access the Yamaha website then download the manual file. Since specifications, equipment or separately sold accessories may not be the same in every locale, please check with your Yamaha dealer.