BOOSTA GRANDE

Users Manual



IMPORTANT SAFEGUARDS

For your protection, please read these safety instructions completely before operating the appliance, and keep this manual for future reference

Carefully observe all warnings, precautions and instructions on the appliance and described in the operating instructions supplied with the appliance.



Water and Moisture - Do not install the appliance near water: for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.

Heat - Do not install the appliance near sources of heat such as radiators, heat registers, stoves, or other appliances that produce heat.

Ventilation - Situate the product so its location or position does not interfere with its proper ventilation. For example, you should not place the product on a bed, sofá, rug, or similar surface that might block the vent openings, or placed in a builtin installation, such as a bookcase or cabinet that might impede the flow of air through the ventilation openings.

Wall or Celling Mounting - If your appliance can be mounted to a wall or ceiling, mount it only as recommended

Accessories - Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should



SERVICING TO CUILLIPED STRICE PRINCIPAL

IISF

follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

Power Source - Connect the appliance to a power supply only of the type described in the operating instructions or as marked on the appliance.

Power-Cord Protection - Route the power cord so that it is not likely to be walked on or pinched by having objects placed on it, paving particular attention to the plugs, receptacles, and the point where the cord exits from the appliance.

Grounding or Polarization - Do not defeat the grounding or polarization feature of the AC power cord. If your AC receptacle will not accept the power cord plug, contact your electrician to install a proper AC receptacle.

When not in use - Unplug the power cord of the appliance from the outlet when left unused for a long period of time. To disconnect the cord, pull it out by grasping the plug. Never pull the plug out by the cord.

AC Recentacle - Check to make sure that the AC receptacle holds the power cord plug firmly and securely. If the power cord plug is loose, contact

WARNING

To prevent the or shock feather, the horsequest the part to extra properties.

ATTENTION: NAOUE DE CHOC DATE WHO HE PAS



erage with the products distinge the may be of exflicted magnitude to constitute a risk of Street, Street & problem. The conformation point, within a conductoral friends a interded to self the user to the presence it experient operating and maintenance benefits) mittalian is the Broket moonpaying the

your electrician to replace the defective and unsafe

Foreign Objects - Be careful that foreign objects and liquids do not enter the enclosure through openings.

Cleaning - unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning. SERVICE

Unplug the appliance from the wall outlet and consult qualified service personnel when:

- . the power cord or the plug has been damaged. · a solid object or liquid has fallen into the cabi-
- net.
- . the appliance has been exposed to rain or mois-
- the appliance does not appear to operate normally or exhibits a marked change in perform-
- . the appliance has been dropped, or the enclosure damaged.

Do not attempt to service the appliance beyond that described in the operating instructions. For all other servicing, refer to qualified service personnel only.

Before you begin, please check the contents of this box to insure that the following items are included:

- The BBE Boosta Grande
- The BBE Boosta Grande User's Manual
- 9VDC External Power Supply
- 9V Battery

If any of these items are found to be damaged or missing, immediately contact the BBE dealer from whom the unit was purchased.

This manual will help you to effectively utilize the BBE Boosta Grande. Should you have any questions, please feel free to contact us at 800-233-8346.

Thank you and congratulations on your purchase of the BBE Boosta Grande!

The Boosta Grande is a Clean Boost that produces up to 20dB of clean gain and was designed for the player that would like to add more gain to their signal without changing the original sound.


Features:

- 20 dB of Clean Boost
- Single Op-Amp Design
- True Bypass
- Powered by 9 Volt Battery/AC Adaptor (Included)

CONTENTS

Important Safeguards	i
Important	ii
Product Features	iii
Controls and Connections	1
Battery Replacement	2
Applications	3
Service	4
Maintenance	4
Warranty	5
Specifications	6

CONTROLS AND CONNECTORS



Grande effect.


your amplifier.

BATTERY REPLACEMENT

BATTERY COMPARTMENT

Pull the latch to the left with thumbnail to release the hinged battery compartment cover. Carefully unplug battery without straining cables. Replace with fresh battery in reverse order.

Use a standard 9Volt battery. Battery life is about 300 hours. Unplugging the input to the Boosta Grande will turn the unit off and conserve battery life.




POWER SUPPLY CONNECTOR

Connect the 9VDC power supply here.

APPLICATIONS

We recommend placing the Boosta Grande before your amplifier or after any overdrive/distortion pedal for the most desirable effect, but please feel free to experiment

Please Note: When using a BBE Sonic Stomp we recommend placing it last in the signal chain.



4

Should the Boosta Grande ever require service we recommend that it be sent to our facility in California. Please contact our Service Department at 800-233-8346 extension 116 for a "Return Authorization" and include a copy of the original sales receipt.

If this product was purchased outside of the United States, please contact your local distributor.

MAINTENANCE

Maintenance of the BBE Boosta Grande is limited to proper cleaning of the unit with mild household cleaner such as Formula 409TM or WindexTM.

There are no user replaceable parts and the unit should not be opened for any reason unless you are a qualified technician. Calibration should be performed if parts are replaced or if a performance check-out indicates a problem with calibration. Long term use has shown that over the life of this unit there is little or no drift of the components in the BBE Boosta Grande which would cause a change in calibration.

WARRANTY

Warranty registration of the unit to BBE Sound, Inc. is not necessary. It is strongly recommended that you retain a copy of the bill of sale for future reference.

IT IS THE SOLE RESPONSIBILITY OF THE END USER TO PROVIDE THE BILL OF SALE OR OTHER MEANS OF PROOF OF PUR-CHASE TO VALIDATE THE WARRANTY IF WARRANTY SERVICE IS REOUESTED.

The BBE Boosta Grande is warranted against defects in material and workmanship for a period of five (5) years from date of purchase from BBE Sound Inc. or from an authorized dealer. During this period, we will repair units free of charge providing that they are shipped prepaid to:

BBE Sound, Inc., 5381 Production Drive, Huntington Beach, CA 92649.

We will pay return UPS shipping charges within the USA. All charges related to non-UPS shipping, including customs clearance, will be billed. The warranty will be honored for the longer of either 90 days from the date of any service or the remainder of the original 5 Year factory warranty.

This warranty will be consider null and void by BBE Sound, Inc. if any of the following is found:

- 1. The equipment has been physically damaged.
- 2. The equipment shows signs of abuse.
- The equipment has been electrically damaged by improper connection or attempted repair by the customer or a third party.
- The equipment has been modified without authorization.
- The bill of sales indicates that the purchase date of the equipment is not within the warranty period.

All non-warranty repairs are warranted for a period of 90 days from the date of service.

BBE Sound, Inc. is NOT LIABLE FOR CONSE-QUENTIAL DAMAGES. Should the unit fail to operate for any reason, our sole obligation is to repair it as described above.

DO NOT RETURN ANY PRODUCT TO THE ABOVE ADDRESS WITHOUT INSTRUCTIONS AND AUTHORIZATION ISSUED BY THE ABOVE LOCATION.

SPECIFICATIONS

Shipping Weight:3.3 lbs.

Note: Due to continuing product improvement, specifications and design are subject to change without notice.





5381 Production Drive Huntington Beach, CA 92649 714-897-6766 • FAX 714-896-0736

www.bbesound.com

covered by U.S. Patent 4,482,866 and other U.S. and foreign patents pending. BBE is the registered trademark of BBE Sound, Inc.