



## **EW-95V VOLUME WAH**

The **MISTER CRYBABY SUPER** is a combined Wah and Volume pedal using the classic circuit design from the original European manufacturer. Its rugged construction and efficient design will give years of outstanding performance.

### **OPERATING INSTRUCTIONS-WAH**

- By rocking your foot back and forth on the pedal, you can change the effect that the CRYBABY® has on the tone of your instrument instantaneously. Toe down will give you more treble, heel down will give you more bass. The speed and amount of effect you use depends on your style of playing.
- When placing the pedal in one position, you will hear a boost in that particular frequency. This boost can be used to add sustain and create feedback of a desired overtone.

### **OPERATING INSTRUCTIONS-VOLUME**


- When the Wah is turned off, the MISTER CRYBABY SUPER pedal becomes an active volume controller with boost. Pressing the toe down on the rocker pedal increases the volume and pressing the heel down decreases the volume.

### **TIPS**

- Listen to the classic recordings of Jimi Hendrix and Eric Clapton. CRYBABY® is used extensively. After listening to the sound you will begin to recognize the CRYBABY® in just about every rock players repertoire.
- When using too much distortion, the effect will not be as prominent. Try setting the pedal in one position. This will help in making artificial harmonics and controlling the amount of feedback.



DUNLOP MFG., INC.  
P.O. Box 846 Benicia, CA 94510 U.S.A.  
Tel: (707) 745-2722  
Fax: (707) 745-2658  
<http://www.jimdunlop.com>  
E-mail: [dunlop @ a.crl.com](mailto:dunlop@a.crl.com)



## **EW-95V VOLUME WAH**

### **SET-UP INSTRUCTIONS**

---

**Notice:** This unit is shipped from the factory without a battery to prevent possible damage from leakage. A 9-volt transistor radio battery must be installed for operation if an AC adapter is not going to be used. We recommend a high quality alkaline battery. To install the battery, remove 4 screws from the rubber feet securing the bottom cover and insert the battery.

The adapter jack requires a Dunlop ECB-03 9-volt DC Regulated AC adapter @ 200ma. (5.5mm x 2.1mm coax).

1. Insert a 9 volt battery and/or plug in AC Adapter. The MISTER CRYBABY SUPER will operate on either power source.
2. Run a cord from your instrument to the CryBaby's instrument jack.
3. Run another cord from your amplifier input into the CryBaby's Amplifier jack.
4. Turn on the amplifier and begin playing.
5. To turn the Wah on, push the toe of the pedal all the way down firmly until you feel a "click", and the LED indicator comes on. To turn the Wah off and to activate the pedal as a volume controller, push the toe of the pedal down again, until you feel another "click" and the LED indicator turns off.

*Placing the Mr. Crybaby Super Volume Wah in front of or after the effects chain will alter the characteristics of the combined sound effect. Experiment with placement to achieve the desired effect.*