
LAUNCHPAD MINI

GETTING STARTED GUIDE

OVERVIEW


Launchpad Mini is a compact version of the celebrated Novation Launchpad for the iPad generation.

64 three-colour pads enable you to produce and perform music with your iPad by triggering samples and effects. The Novation Launchpad iPad app has been designed to get you making music straight away. It comes with pre-loaded samples and loops and the ability to import your own, which you can play on their own or with other loops to create performances.



USING LAUNCHPAD MINI WITH IPAD


Launchpad Mini can be connected to an Apple iPad. An Apple Camera Connection Kit is required (available from the Apple Store or online). Launchpad Mini will power from the iPad.



- 2 USB
- 3 Apple 30 pin Camera Connection Kit (not included)
- 4 iPad

Note that a 30 pin Camera Connection Kit is required for iPad, iPad 2, 3. A Lightning to USB Camera Adapter is required for iPad 4 and iPad Mini.


If using Launch Control alongside other hardware, connect the hardware to a powered USB hub, then connect the hub to the iPad.



- 1 Launchpad Mini
- 2 Powered USB hub (not included)
- 3 Apple 30 pin Camera Connection Kit (not included)
- 4 iPad
- 5 Launch Control

USING LAUNCHPAD MINI WITH THE LAUNCHPAD APP

The Novation Launchpad App is available for free on the App Store. Once downloaded, connect Launchpad Mini and start the app. Once a session is loaded, Launchpad Mini can be used to control all elements of the session as shown below.







Volume: each colum of 8 pads turns into a volume fader. press the pad on row B to reset volume





Filter: each column of 8 pads turns into a filter fader: Move up to remove bass, move down to remove treble. Press the pad on rows D or E to reset filter.


IPAD COMPATIBLE (LOW POWER) VS FULL POWER MODE

Launchpad Mini defaults to iPad compatible low-power mode. If Launchpad Mini is being used with a desktop or laptop computer then it can be switched to full-power mode with much brighter LEDs. The Launchpad Mini will not work with an iPad if it is in full-power mode unless a separate powered USB hub is used (see previous setup diagrams).



CONNECTING LAUNCHPAD MINI TO A PC

Launchpad Mini is a class compliant USB MIDI device, therefore no drivers are required for use with a computer. Simply connect Launchpad Mini to your computer as shown below.



LAUNCHPAD MINI WITH ABLETON LIVE

Launchpad Mini is fully integrated with Ableton Live. Please ensure that you have the most up to date version. Go to www.ableton.com to get the latest installers.

Documentation showing integration with Ableton Live is available at www.novationmusic.com/register

IIII Ableton Live Lite

We've included a free copy of Ableton Live Lite. Installers and unlock codes are available from the above web page.

LAUNCHPAD MINI WITH FL STUDIO 11

Launchpad Mini is fully integrated with FL Studio 11. Please ensure that you have the most up to date version. Go to www.image-line.com to get the latest installers. Documentation showing integration with FL Studio 11 is available at www.novationmusic.com/register

LAUNCHPAD MINI WITH OTHER SOFTWARE

Launchpad Mini can be used with any MIDI compatible software. Most software now has MIDI learn functionality, check the documentation with your software for more information.

REGISTRATION AND SUPPORT

THANK YOU FOR CHOOSING THE NOVATION LAUNCHPAD MINI!

Please register your Launchpad Mini online at: www.novationmusic.com/regsiter
For customer support, please contact us online: www.novationmusic.com/support

Novation is a registered trademark of Focusrite Audio Engineering Ltd. Launchpad Mini is a trademark of Focusrite Audio Engineering Ltd. 2013

© Focusrite Audio Engineering Ltd. All rights reserved.

iPad is a trademark of Apple Inc., registered in the U.S. and other countries

