



## **MIDI Implementation Chart**

Version: 1.0

Function		Transmitted	Recognised	Remarks
Basic Channel	Default Changed	1 1	× ×	
Mode	Default Messages Altered	Mode 4 X X	× × ×	
Note Number	True voice	21–76 X	× ×	
Velocity	Note On Note Off	O X	× ×	
After Touch	Key's Channel	× ×	× ×	
Pitch Bend		0	×	14-bit ±2 semitone range
Control Change	0–127	123 (All Notes Off)	×	Transmitted at power-on only
Program Change	True Number	X	X	
System Exclusive		X	X	
System Common	Song Position Song Select Tune Request	× × ×	× × ×	
System Real Time	Clock Commands	× ×	× ×	
Aux Messages	Local On/Off All Notes Off Active Sensing System Reset	× × × ×	× × ×	

Notes The unit does not receive MIDI, it is only a transmitter.

 Mode1: Omni On, Poly
 Mode2: Omni On, Mono
 O:Yes

 Mode3: Omni Off Poly
 Mode4: Omni Off, Mono
 X: No

www.sonuus.com — for the latest information and details on other sonuus products visit our web site.
sonuus, B2M are Trademarks or Registered Trademarks of Sonuus Limited.
The information contained herein is subject to change without notice.