TRAKTOR LE

DRY / WET CHAINED FX
FX 1 ON
FILTER ON
SELECT FLANGER
ROTATE: LIST SELECT UP / DOWN
PUSH: LOAD SELECTED
FX PARAM 1
FILTER
SELECT DELAY
SELECT REVERB
UNLOAD
DECK SEEK
TEMPO BEND
ONLY BROWSER
SYNC
SET CUE
CUE PLAY
LOOP LENGTH
FX CONTROL
JOG CONTROL
AUTO LOOP 4
LOOP OUT
AUTO LOOP 1
LOOP IN
LOOP ACTIVE
CUE / PAUSE
PLAY / PAUSE
JOG MODE TOGGLE
TEMPO
DENON
DN-HC4500
USB MIDI/AUDIO INTERFACE&CONTROLLER