

MicroD Instructions

Thank you for purchasing the Audix MicroD condenser microphone! The MicroD was designed for use in both live sound reinforcement and recording of acoustic instruments. A Dvice drum clamp is supplied with the microphone to attach it to any flanged or die cast drum hoop. To attach the microphone to the Dvice:

1. Begin by inserting the MicroD into the shock mount located on the top of the Dvice. Slowly twist the microphone back and forth to slide it into the mount.

Note: Make sure the holes on the side of the capsule are NOT covered by the shock mount.

2. Attach the cable to the back of the gooseneck using the supplied strain relief grommets. Leave slack in the cable as to prevent stress on the connection.



AUDIX

www.audixusa.com
503.682.6933

©2016 Audix Corporation All Rights Reserved. Audix and the Audix Logo are trademarks of Audix Corporation.