



## The Fast-Attach™ Two Tier Arm Set Instructions and Warranty Information



### This Kit Includes:

2 – Fast-Attach Two Tier Arms w/Height Memory Ring System

2 – Fast-Clamps

4 – Wire Management Clips



1 – Left Clamp Spacer/Insert



1 – Right Clamp Spacer/Insert



### Specifications:

- Adjustable from height 3.5" – 13" (from surface to back of arms).
- Arm support Length: 12.5"
- Weight capacity: up to 40 lbs/pair

**Warnings:** Clamps are designed with a slight back-leaning angle which becomes a side-lean when used on the sides of table, since the Arms are round, this should not affect the security of your devices. Only use the Fast-Attach Accessories with your devices over-hanging the table and not over-hanging the ground. Do not use the Fast-Clamp or Fast-Attach Accessories on any table except the New Fastset® Utility Table.

For Tips & Tricks on all Fastset Products watch videos located on the product pages at [www.fastsetusa.com](http://www.fastsetusa.com)

# Installing your Fast-Attach Accessory to the Fastset® Table

## STEP 1: Position the Fast-Clamps onto the Fastset® Table:

- Determine where you are going to locate your Fast-Attach Accessory and place the clamp on the table edge by squeezing it open & then releasing it into position - be sure the clamp is not located on a fastener on the underside of table (located approximately by small squares on picture below).
- **IMPORTANT:** If you are using your Fast-Attach Two Tier Arms on the sides or the far corners of the table, you **MUST** install the proper left/right spacer on to the Clamp prior to positioning it on the table.




Left Spacer Installed



No Spacer Needed



Right Spacer Installed



## STEP 2: Insert the vertical post of your Fast-Attach Accessory:

Before inserting the vertical post, make sure the locking cam lever on the clamp is in the down position. Insert the vertical post through the clamp opening and set the accessory to your preferred height/position then push the cam lever up until it clicks into the locked position.



UN-LOCKED



LOCKED

## Using the Features on your Fast-Attach Two Tier Arms

### Adjusting the Two-Tier Arms to equal Heights using the Memory Ring feature:


- Simply place the O-Rings on both vertical post of your Two-Tier arms at the same positions on each arm (in one of the 5 set grooves). Using the matched O-Rings as guides, insert each arm into the Fast-Clamp until the O-Ring meets the clamp. **Note:** O-Rings are for reference only, pushing the vertical post into the clamp too hard will cause the O-Ring to move out of the set groove. If this should happen, reposition the O-Ring back to the proper set groove before locking the Fast-Clamp.

### Adjusting the repositionable O-Rings on the Support Arms for smaller devices:

- When using the Two-Tier Arms for smaller gear that doesn't reach the rear support boot on the arm, you can reposition the front O-Ring up & down the support arm, placing it so your gear will rest on it and not the metal of the support arm.

### Adjusting the Gear Retention Tabs:

- The gear retention tabs on the front of your Two-Tier Arms can be rotated in either direction, effectively lowering the height of the tab. This is typically desirable when using the Arms to support thinner electronics (such as a laptop) so that the tabs don't interfere with your wrist.



## Fast Set Supports Limited Warranty Details

Fast Set Supports, LLC, herein referred to as "Fast Set Supports", warranty obligations are limited to the terms set forth as follows:

- Fast Set Supports warrants all Fastset® Tables and Fast-Attach Line of Accessories to be free from manufacturing defects under normal use for a period of Three Years from the date of retail purchase by the original end-user purchaser.
- Fast Set Supports warrants all soft products, such as cases, scrims, covers, etc. to be free from manufacturing defects under normal use for a period of One Year from the date of retail purchase by the original end-user purchaser.
- If the product is no longer manufactured by Fast Set Supports, and qualifies for repair under the warranty program, the product will be replaced with the closest comparable product as determined by Fast Set Supports.
- This warranty does not include damage to the product resulting from normal wear and tear, accident, misuse, improper installation or operation, or unauthorized repair or alterations.
- The Limited Warranty does not apply to any non-Fast Set Supports products or sub-brands even if packaged or sold with other products.
- Should the product become defective within the warranty provisions, Fast Set Supports will elect to repair or replace the product free of charge at our option, including free return postage, provided it is delivered prepaid to Fast Set Supports.
- Fast Set Supports may elect to send original end-user new or refurbished customer-installable replacement product or parts.
- Proof of purchase in the form of a dated receipt must be submitted with the returned product.
- All products needing to be sent to Fast Set Supports for repair or replacement must have a Return Authorization Number and will be returned to the sender un-repaired if one is not included. Please email your request (with explanation of problem) to Customer Support at [support@fastsetusa.com](mailto:support@fastsetusa.com) for a Return Authorization Number and return instructions.
- It is the sender's responsibility to pay for shipment to Fast Set Supports.
- If the product is determined to fall under warranty, Fast Set Supports will pay for return shipping to the customer within the contiguous 48 states.
- If a replacement product or part is provided, the original product or part becomes the property of Fast Set Supports.

Should Fast Set Supports deem a product non-warranty, repair services or replacement parts may be available. Fast Set Supports will contact the sender with repair options.

For answers to any questions regarding warranty and service, please email Customer Support at [support@fastsetusa.com](mailto:support@fastsetusa.com)

**To receive faster service & other benefits Please Register Your Product at:**

**[www.fastsetusa.com](http://www.fastsetusa.com)**

### **A note from Fastset inventor & founder Trace Van Dyne:**

Thank you for your trust in me and the Fastset Brand. I work very hard to create products that are reliable and that provide you an easier, unique way to set-up and perform, because that's what I believe in. When I used to do gigs, I never liked to tighten and loosen knobs, I didn't like things that wobbled or swayed and that could potentially come apart, and I hated the fact that everything seemed to be made in China. Some products usually worked fine for a while and some would come apart after only a few uses. They always seemed to be lacking one or two design features that would have made them work better and be more reliable. I could never understand why "they" wouldn't make a simple change to improve the quality and make it easier for us to use. I would have happily spent a few extra bucks to not have any worries. So, this is my motivation, and inspiration, to do things different. You'll find that Fastset doesn't do "knock-offs", we create our own solutions and work diligently to make products that make sense and, to give our customers the added value of multiple ways to set-up and play.

Thank You again and please don't hesitate to contact us at [support@fastsetusa.com](mailto:support@fastsetusa.com) if you ever have any questions or need assistance with our products. You can also contact me directly; my personal email is: [trace@fastsetusa.com](mailto:trace@fastsetusa.com)

P.S. If you like what I'm doing, please Share Fastset on Social Media, I appreciate your support!